

CATERPILLAR 6S

1DH / SEBP1898


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Power train	
Power train	
Fuel system	
Hydraulic system	
Power train	
Air inlet and exhaust	
Labels, kits and diagnostics	

7C-9335 GAUGE GP-OIL LEVEL (DIPSTICK)

7C9335 GAUGE GP-OIL LEVEL (DIPSTICK)

Drawing 1 of 1

	NOTE	REF NO	PART NUMBER	QTY	PART NAME
		1	4W4189	1	GAUGE AS-OIL LEVEL (DIPSTICK)
		2	4W4188	1	TUBE AS-GUIDE
		3	8S1326	1	CONNECTOR AS
			5P4443	1	SLEEVE-AIR BRAKE
			5P4448	1	NUT-AIR BRAKE
		4	5K9243	2	ELBOW-FLARED
		5	2P2697	1	TUBE AS-AIR VENT
	C	6	OS1588	1	BOLT
	C	7	5M2894	3	WASHER
	C	8	1D4717	1	NUT
		9	7E2964	1	GUARD AS-OIL LEVEL
		10	3B1915	1	BOLT
C-CHANGE FROM PREVIOUS TYPE					
R-487552 EP					

Ref.	Part number	Description	Qty	Code	Group page
1	4W-4189	GAUGE AS-OIL LEVEL	1		
2	4W-4188	TUBE AS-GUIDE	1		
3	8S-1326	CONNECTOR AS-SPECIAL	1		
	5P-4443	SLEEVE-AIR BRAKE	1		
	5P-4448	NUT-AIR BRAKE	1		
4	5K-9243	ELBOW-FLARED	2		
5	2P-2697	TUBE AS-AIR VENT	1		
6	OS-1588	BOLT	1	C	
7	5M-2894	WASHER	3	C	
8	1D-4717	NUT	1	C	
9	7E-2964	GUARD AS-OIL LEVEL	1		
10	3B-1915	BOLT	1		

CAT codes: C.

7C9336 FILLER GP-OIL

Diagram illustrating the assembly of the Air Cleaner Support (11) onto the Cylinder Head (CYL. HEAD). The assembly includes various fasteners and components labeled with numbers 1 through 13, corresponding to the parts list.


NOTE	REF NO	PART NUMBER	QTY	PART NAME
	1	4W4485	1	TUBE AS
	2	6N2985	1	CAP AS-FILLER
	3	2P2717	1	HASP-OIL FILLER
	4	4N6045	1	LUG
	5	8D9558	1	RIVET
	6	2A3211	1	WASHER
	7	0S1571	3	BOLT
	8	5M2894	3	WASHER
	9	1D4717	1	NUT
	10	2P2720	1	GASKET
	11	4W4187	1	BRACKET
	12	3B1915	1	BOLT
	13	8M6744	1	CLAMP

SEBP1898

4W-4268 PROTECTION GP-VANDALISM

4W4268 PROTECTION GP-VANDALISM OIL FILLER AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-4485	TUBE AS (OIL FILLER)	1		
2	6N-2985	CAP AS-FILLER	1		
3	8S-7566	RIVET-POP	1		
4	5S-7337	WASHER	1		
5	2P-2717	HASP-OIL FILLER	1		
6	8S-4212	RIVET	1		
7	4N-6045	LUG	1		
8	5P-8502	PADLOCK GP	1		
	5P-8500	KEY	1	A	
	8Y-6364	SLEEVE	1		
9	2P-2720	GASKET	1		

1W-1421 PROTECTION GP-VANDALISM

1W1421 PROTECTION GP-VANDALISM OIL LEVEL GAUGE AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	8N-5937	GUARD AS	1		
2	6N-2011	RIVET	1		
3	0S-1594	BOLT	1		
	1D-4717	NUT	1		
	5M-2894	WASHER	2		
4	5P-8502	PADLOCK GP	1		
	5P-8500	KEY	2	A	

CAT codes: A.

2P-1784 PUMP GP-ENGINE OIL

2P1784 PUMP GP-ENGINE OIL 6N2642-PAGE 26

Drawing 1 of 1




Ref.	Part number	Description	Qty .	Code	Group page
1	3B-1915	BOLT	2		
2	0S-1619	BOLT	1		
3	4N-5353	ELBOW-LINE	1		
	2P-8746	GASKET	1		
4	0S-1590	BOLT	3		
5	6N-2642	PUMP GP-ENGINE OIL	1	CY	
6	5M-2894	WASHER	4		

CAT codes: C, Y.

1P-4244 BREATHER GP

1P4244 BREATHER GP-CRANKCASE

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	3H-3243	BOLT	1		
2	9N-0869	WASHER	1	C	
3	2W-9162	BREATHER AS-CRANKCASE (CRANKCASE)	1	C	
4	4L-9564	SEAL-O-RING	1	C	

CAT codes: C.

6N-2642 PUMP GP-ENGINE OIL

6N2642 PUMP GP-ENGINE OIL ENGINE S/N 8Z66851-UP 6I1346-PAGE 27.02 PART OF 2P1784 PUMP-ENGINE OIL

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	6I-1346	PUMP GP-ENGINE OIL	1	YR	
2	7W-0507	GEAR-OIL PUMP DRIVE	1		
3	0S-1590	BOLT	1		
4	1P-7346	WASHER	1		

CAT codes: R, Y.

6N-2642 PUMP GP-ENGINE OIL

6N2642 PUMP GP-ENGINE OIL ENGINE S/N 8Z58900-8Z66850 PART OF 2P1784 PUMP-ENGINE OIL

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4P-4020	PUMP GP-ENGINE OIL	1	Y	
2	7W-0507	GEAR-OIL PUMP DRIVE	1		
3	8M-5599	KEY-WOODRUFF	1		
4	1P-7346	WASHER (6.0MM THK)	1		
5	0S-1590	BOLT (3/8-16X2IN)	1		

CAT codes: Y.

4W-2448 PUMP GP-ENGINE OIL

4W2448 PUMP GP-ENGINE OIL*R ENGINE S/N 8Z58900-61483-TWO SECTION GEAR PART OF 6N2642 PUMP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4W-2322	BODY AS-OIL PUMP	1		
2	2P-1170	SHAFT AS-GEAR	1		
3	4B-9782	BALL	1		
4	4B-9880	BALL	1		
5	1F-1006	DOWEL	1		
6	8S-6511	BEARING-SLEEVE	2		
7	2P-1781	SPACER-OIL PUMP	1		
8	4N-8385	VALVE AS-RELIEF	1		
9	2B-2694	BOLT	1		
	9M-1974	WASHER	1		
10	4N-3732	COVER-VALVE	1		
11	6N-1036	GEAR-OIL PUMP (8 TEETH)	2		
12	0T-0065	BOLT	3		
13	8S-0493	SHAFT AS-PUMP	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

1DH-SEBP1898

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99