

CATERPILLAR E120

1LF / XEBP9905


Contents

Section	Page
Hydraulic system	2
Fuel system	

BASE FRAME

BASE FRAME

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E120-1LF	
1	967639	BASE FRAME	1		
2	860708	STAY	2		
3	*	STEP	4	1-09060	
	7Y2481	STEP	4	09051-	


Ref.	Part number	Description	Qty	Code	Group page
1	096-7639	BASE FRAME	1		
2	086-0708	STAY	2		
	7Y-2481	STEP	4		

CAT codes: N.

LOWER STRUCTURE COVER

LOWER STRUCTURE COVER

Drawing 1 of 1




Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E300-2CF	EL300-4NF
1-9	956684	BY-PASS FILTER ASSY. See Page 2-58	1		
1	962917	BOLT, HEXAGON SOCKET	4		
2	956687	HEAD	1		
3	955483	VALVE	1		
4	955481	ELEMENT	1		
5	962918	SPRING	1		
6	955482	O-RING	1		
7	956685	CASE, FILTER	1		
8	956686	WASHER, SEAL	1		
9	962919	BOLT	1		

Ref.	Part number	Description	Qty	Code	Group page
1	096-2917	BOLT, HEXAGON SOCKET	4		
2	095-6687	HEAD	1		
3	095-5483	VALVE	1		
4	095-5481	ELEMENT	1		
5	096-2918	SPRING	1		
6	095-5482	O-RING	1		
7	095-6685	CASE, FILTER	1		
8	095-6686	WASHER, SEAL	1		
9	096-2919	BOLT	1		

IDLER WHEEL

IDLER WHEEL

Drawing 1 of 1




Key No.	Part No.	Part Name-Description	Qty	Serial No.
1-9	937787	IDLER WHEEL ASSY.	2	E120-1LF
1	950965	PLUG	4	
2	950901	PIN	4	
3	937788	BEARING	4	
4	967210	O-RING	8	
5	957100	SEAL, FLOATING	4	
6	931844	BUSHING	4	
7	936037	WHEEL	2	
8	951545	O-RING	4	
9	931697	SHAFT	2	

Ref.	Part number	Description	Qty	Code	Group page
1-9	093-7787	IDLER WHEEL ASSY.	2		
1	095-0965	PLUG	4		
2	095-0901	PIN	4		
3	093-7788	BEARING	4		
4	096-7210	O-RING	8		
5	095-7100	SEAL, FLOATING	4		
6	093-1844	BUSHING	4		
7	093-6037	WHEEL	2		
8	095-1545	O-RING	4		
9	093-1697	SHAFT	2		

YOKE AND TENSION

YOKE AND TENSION

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E120-1LF	
1	950817	WASHER, SPRING	8		
2	950506	BOLT	8		
11-27	932113	TENSION ASSY.	2		
11	950506	BOLT	8		
12	950817	WASHER, SPRING	8		
13	937793	YOKE	2		
21-27	957139	SPRING ASSY.	2		
21	951225	NUT	4		
22	950806	WASHER	2		
23	967211	SUPPORT A	2		
24	932103	SPRING	2		
25	930560	PIPE	2		
26	930411	SUPPORT B	2		
27	931714	ROD	2		
	855739	ROD	2		

Supply only

Ref.	Part number	Description	Qty	Code	Group page
1	095-0817	WASHER, SPRING	8		
2	095-0506	BOLT	8		
11-27	093-2113	TENSION ASSY.	2		
11	095-0506	BOLT	8		
12	095-0817	WASHER, SPRING	8		
13	093-7793	YOKE	2		
21-27	095-7139	SPRING ASSY.	2		
21	095-1225	NUT	4		
22	095-0806	WASHER	2		
23	096-7211	SUPPORT A	2		
24	093-2103	SPRING	2		
25	093-0560	PIPE	2		


YOKE AND TENSION (continued)

Ref.	Part number	Description	Qty	Code	Group page
26	093-0411	SUPPORT B	2		
27	093-1714	ROD	2		
	085-5739	ROD	2		

ADJUSTER CYLINDER

ADJUSTER CYLINDER

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.
1-12	961494	ADJUSTER CYLINDER ASSY.	2	E120-1LF
1	931557	PISTON	2	
6-8	939266	REPAIR KIT	2	
6	952777	SEAL	2	
7	931515	RING	4	
8	936940	O-RING	4	
11	937795	CYLINDER	2	
12	959291	VALVE	2	
16	950506	BOLT	4	
17	950817	WASHER, SPRING	8	
18	950502	BOLT	4	
21-24	966768	STOPPER PLATE ASSY., L. H.	1	1-09256
	967946	STOPPER PLATE ASSY., L. H.	1	09257
	966769	STOPPER PLATE ASSY., R. H.	1	1-09256
	967947	STOPPER PLATE ASSY., R. H.	1	09257
21	6V9669	SCREW	8	
22	950760	NUT	8	
23	966762	PLATE	2	
24	966770	PLATE, CAUTION	2	1-09256
	967948	PLATE, WARNING	2	09257

Ref.	Part number	Description	Qty	Code	Group page
1-12	096-1494	ADJUSTER CYLINDER ASSY.	2		
1	093-1557	PISTON	2		
6-8	093-9266	REPAIR KIT	2		
6	095-2777	SEAL	2		
7	093-1515	RING	4		
8	093-6940	O-RING	4		
11	093-7795	CYLINDER	2		
12	095-9291	VALVE	2		
16	095-0506	BOLT	4		
17	095-0817	WASHER, SPRING	8		
18	095-0502	BOLT	4		
21-24	096-6768	STOPPER PLATE ASSY., L. H.	1		
4	096-7946	STOPPER PLATE ASSY., L. H.	1		
	096-6769	STOPPER PLATE ASSY., R. H.	1		


ADJUSTER CYLINDER (continued)

Ref.	Part number	Description	Qty	Code	Group page
	096-7947	STOPPER PLATE ASSY., R. H.	1		
21	6V-9669	SCREW	8		
22	095-0760	NUT	8		
23	096-6762	PLATE	2		
24	096-6770	PLATE, CAUTION	2		
	096-7948	PLATE, WARNING	2		

CARRIER ROLLER

CARRIER ROLLER

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E120-1LF	
1	967698	BOLT	4		
11-27	960277	CARRIER ROLLER ASSY.	2		
11	8T4241	RING	2		
12	6V7660	O-RING	2		
13	*	SHAFT	2		
14	950884	PIN	4		
15	936949	SUPPORT	2		
16	931361	O-RING	4		
17	931411	SEAL, FLOATING	2		
18	936951	BUSHING	4		
19	936947	ROLLER	2		
20	936950	WASHER	2		
21	950831	WASHER	2		
22	952935	BOLT	2		
23	6V7609	O-RING	2		
24	934886	COVER	2		
25	950967	PLUG	2		
26	950486	BOLT	6		
27	950816	WASHER, SPRING	6		

Ref.	Part number	Description	Qty	Code	Group page
1	096-7698	BOLT	4		
11-27	096-0277	CARRIER ROLLER ASSY.	2		
11	8T-4241	RING	2		
12	6V-7660	O-RING	2		
14	095-0884	PIN	4		
15	093-6949	SUPPORT	2		
16	093-1361	O-RING	4		
17	093-1411	SEAL, FLOATING	2		
18	093-6951	BUSHING	4		
19	093-6947	ROLLER	2		
20	093-6950	WASHER	2		
21	095-0831	WASHER	2		
22	095-2935	BOLT	2		
23	6V-7609	O-RING	2		

CARRIER ROLLER (continued)

Ref.	Part number	Description	Qty	Code	Group page
24	093-4986	COVER	2		
25	095-0967	PLUG	2		
26	095-0486	BOLT	6		
27	095-0816	WASHER, SPRING	6		

CAT codes: N.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

1LF-XEBP9905

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99