

CATERPILLAR E140

1NF / XEBP9906


Contents

Section	Page
Hydraulic system	2
Fuel system	

BASE FRAME

BASE FRAME

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E140-1NF	
1	994940	BASE FRAME	1		
2	C43304900	STAY	2		
3	*	STEP	4	1-09020	
	7Y2481	STEP	4	09021-	


Ref.	Part number	Description	Qty	Code	Group page
1	099-4940	BASE FRAME	1		
2	C4330-4900	STAY	2		
	7Y-2481	STEP	4		

CAT codes: J.

LOWER STRUCTURE COVER

LOWER STRUCTURE COVER

Drawing 1 of 1




Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E140-1NF	
1	967959	COVER	1		
2	950800	WASHER	26		
3	950817	WASHER, SPRING	16		
4	950502	BOLT	4		
5	950503	BOLT	22		
6	967958	COVER, R. H.	1		
7	967957	COVER, L. H.	1		
8	967960	COVER, L. H.	1		
9	967961	COVER, R. H.	1		

Ref.	Part number	Description	Qty	Code	Group page
1	096-7959	COVER	1		
2	095-0800	WASHER	26		
3	095-0817	WASHER, SPRING	16		
4	095-0502	BOLT	4		
5	095-0503	BOLT	22		
6	096-7958	COVER, R. H.	1		
7	096-7957	COVER, L. H.	1		
8	096-7960	COVER, L. H.	1		
9	096-7961	COVER, R. H.	1		

IDLER WHEEL

IDLER WHEEL

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1-9	093-6937	IDLER WHEEL ASSY.	2		
1	095-0965	PLUG	4		
2	095-0902	PIN	4		
3	093-6938	BEARING	4		
4	096-6279	O-RING	8		
5	096-0883	SEAL, FLOATING	4		
6	093-1837	BUSHING	4		
7	096-0272	WHEEL	2		
8	8T-6346	O-RING	4		
9	093-1696	SHAFT	2		

YOKE AND TENSION

YOKE AND TENSION

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E140-1NF	
1	950818	WASHER, SPRING	8		
2	958528	BOLT	8		
11-27	968014	TENSION ASSY.	2		
11	958528	BOLT	8		
12	950818	WASHER, SPRING	8		
13	968015	YOKE	2		
21-27	968013	SPRING ASSY.	2		
21	951225	NUT	4		
22	950806	WASHER	2		
23	968012	SUPPORT A	2		
24	932104	SPRING	2		
25	930560	PIPE	2		
26	930411	SUPPORT B	2		
27	931714	ROD	2		

Ref.	Part number	Description	Qty	Code	Group page
1	095-0818	WASHER, SPRING	8		
2	095-8528	BOLT	8		
11-27	096-8014	TENSION ASSY.	2		
11	095-8528	BOLT	8		
12	095-0818	WASHER, SPRING	8		
13	096-8015	YOKE	2		
21-27	096-8013	SPRING ASSY.	2		
21	095-1225	NUT	4		
22	095-0806	WASHER	2		
23	096-8012	SUPPORT A	2		
24	093-2104	SPRING	2		


YOKE AND TENSION (continued)

Ref.	Part number	Description	Qty	Code	Group page
25	093-0560	PIPE	2		
26	093-0411	SUPPORT B	2		
27	093-1714	ROD	2		

ADJUSTER CYLINDER

ADJUSTER CYLINDER

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E140-1NF	
1-12	968016	ADJUSTER CYLINDER ASSY.	2		
1	931557	PISTON	2		
6-8	939266	REPAIR KIT	2		
6	931435	SEAL	2		
7	931515	RING	4		
8	936940	O-RING	4		
11	957095	CYLINDER	2		
12	959291	VALVE	2		
16	950560	BOLT	4		
17	950821	WASHER, SPRING	4		
18	950502	BOLT	4		
19	950817	WASHER, SPRING	4		
21-24	966768	STOPPER PLATE ASSY., L. H.	1	1-09015	
	967946	STOPPER PLATE ASSY., L. H.	1	09016-	
	966769	STOPPER PLATE ASSY., R. H.	1	1-09015	
	967947	STOPPER PLATE ASSY., R. H.	1	09016-	
21	6V9669	SCREW	8		
22	950760	NUT	8		
23	966762	PLATE	2		
24	966770	PLATE, CAUTION	2	1-09015	
	967948	PLATE, WARNING	2	09016-	

Ref.	Part number	Description	Qty	Code	Group page
1-12	096-8016	ADJUSTER CYLINDER ASSY.	2		
1	093-1557	PISTON	2		
6-8	093-9266	REPAIR KIT	2		
6	093-1435	SEAL	2		
7	093-1515	RING	4		
8	093-6940	O-RING	4		
11	095-7095	CYLINDER	2		
12	095-9291	VALVE	2		
16	095-0560	BOLT	4		
17	095-0821	WASHER, SPRING	4		
18	095-0502	BOLT	4		
19	095-0817	WASHER, SPRING	4		
21-24	096-6768	STOPPER PLATE ASSY., L. H.	1		
4	096-7946	STOPPER PLATE ASSY., L. H.	1		


ADJUSTER CYLINDER (continued)

Ref.	Part number	Description	Qty	Code	Group page
	096-6769	STOPPER PLATE ASSY., R. H.	1		
	096-7947	STOPPER PLATE ASSY., R. H.	1		
21	6V-9669	SCREW	8		
22	095-0760	NUT	8		
23	096-6762	PLATE	2		
24	096-6770	PLATE, CAUTION	2		
	096-7948	PLATE, WARNING	2		

CARRIER ROLLER

CARRIER ROLLER

Drawing 1 of 1



Key No.	Part No.	Part Name-Description	Qty	Serial No.	
				E140-1NF	
1	967698	BOLT	4		
11-27	936946	CARRIER ROLLER ASSY.	2		
11	8T4241	RING	2		
12	6V7660	O-RING	2		
13	936948	SHAFT	2		
14	950884	PIN	4		
15	936949	SUPPORT	2		
16	931361	O-RING	4		
17	931411	SEAL, FLOATING	2		
18	936951	BUSHING	4		
19	936947	ROLLER	2		
20	936950	WASHER	2		
21	950831	WASHER	2		
22	952935	BOLT	2		
23	6V7669	O-RING	2		
24	934986	COVER	2		
25	950967	PLUG	2		
26	950486	BOLT	6		
27	950816	WASHER, SPRING	6		

Ref.	Part number	Description	Qty	Code	Group page
1	096-7698	BOLT	4		
11-27	093-6946	CARRIER ROLLER ASSY.	2		
11	8T-4241	RING	2		
12	6V-7660	O-RING	2		
13	093-6948	SHAFT	2		
14	095-0884	PIN	4		
15	093-6949	SUPPORT	2		
16	093-1361	O-RING	4		
17	093-1411	SEAL, FLOATING	2		
18	093-6951	BUSHING	4		
19	093-6947	ROLLER	2		
20	093-6950	WASHER	2		
21	095-0831	WASHER	2		
22	095-2935	BOLT	2		

CARRIER ROLLER (continued)

Ref.	Part number	Description	Qty	Code	Group page
23	6V-7609	O-RING	2		
24	093-4986	COVER	2		
25	095-0967	PLUG	2		
26	095-0486	BOLT	6		
27	095-0816	WASHER, SPRING	6		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

1NF-XEBP9906

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99