

CATERPILLAR CB-525B

1NL / KEBP4127


Contents

Section	Page
Basic engine	2
Lubrication system	3
Air inlet and exhaust	4
Fuel system	8
Fuel system	
Basic engine	
Basic engine	
Electrical and electronics	
Power train	
Hydraulic system	
Undercarriage	
Hydraulic system	
Power train	
Hydraulic system	
Cooling system	
Catalog items	

5E-6940 ENGINE GP

5E6940 ENGINE GP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	082-7022	ALTERNATOR	1		
2	081-5209	BELT	1		
3	081-4660	BELT	1		
4	082-7172	PLUG	1		
5	082-6848	SEAL	1		
6	081-4662	FILTER (FUEL)	1		
7	081-4661	FILTER (OIL)	1		
8	081-8209	BOLT	1		
9	085-2253	GUIDE	1		
	081-5261	SENSOR	1	F	
	082-8867	THERMOSTAT	1	F	
	082-6940	STARTING MOTOR	1	F	
	082-7629	BOX	1	F	

CAT codes: F.

5E-7616 LINES GP-COOLER

5E7616 LINES GP-COOLER

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	081-2523	SEAL	1		
2	081-3806	REDUCER	1		
3	081-2442	ELBOW	4		
4	081-2576	CLIP	4		
5	5E-7312	SEAL	2		
6	5E-7313	ADAPTER	2		
7	082-9176	HOSE	1		
8	081-2547	HOSE	1		

5E-7589 AIR CLEANER GP

5E7589 INTAKE GP-AIR

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-4136	BOLT	4	M	
2	081-2801	LOCKWASHER	4		
3	4B-4278	WASHER	4		
4	5E-6943	SUPPORT	1		
5	084-9104	CLAMP	3		
6	084-9600	HOSE	1		
7	081-3754	TUBE	1		
8	081-3439	CLAMP	1		
9	8T-4908	BOLT	4	M	
10	9M-1974	WASHER	4		

5E-7589 AIR CLEANER GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
11	081-2600	LOCKWASHER	4		
12	5C-7261	NUT	4	M	
13	082-7299	CLAMP	2		
14	082-7690	SCREW	2		
15	082-9580	NUT	2		
16	083-1005	PROTECTOR	1		
17	081-3760	INDICATOR (SERVICE)	1		
18	082-9649	FILTER AS-AIR	1		
19	081-4648	CARTRIDGE	1		
20	081-4647	CARTRIDGE	1		
21	082-8088	VALVE	1		
22	085-2125	SCREW	1		
23	081-3825	NUT	1		
	081-3973	SEAL	2		
24	081-4704	SEAL (.3M)		BD	

CAT codes: B, D, M.

5E-7587 EXHAUST GP

5E7587 EXHAUST GP

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	083-0580	SUPPORT (RH)	1		
2	084-6916	SUPPORT (LH)	1		
3	081-4835	SILENCER	1		
4	081-4985	COLLAR	1		
5	104-4337	CLAMP	1		
6	6B-3771	CLAMP	1		
7	082-7540	PIPE-EXHAUST	1		
8	081-5315	PIPE	1		
9	5E-6942	SUPPORT	1		
10	8T-4956	BOLT (M12X1.75X35MM)	6	M	
11	081-2811	LOCKWASHER	4		
12	8T-4244	NUT (M12X1.75 THD)	4	M	
13	081-5199	NUT	5		
14	8T-4186	BOLT (M10X1.50X40MM)	3	M	
15	8T-4183	BOLT (M12X1.75X40MM)	3	M	
16	8T-4121	WASHER (2.5MM THK)	6		
17	8T-4133	NUT (M10X1.50 THD)	3	M	

5E-7587 EXHAUST GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
18	8T-7547	BOLT (M8X1.25X30MM)	1	M	
19	081-2868	NUT	1		
20	8T-4133	NUT (M10X1.50 THD)	1	M	
21	081-2891	BOLT	1		
22	081-2801	LOCKWASHER	1		

CAT codes: M.

5E-7591 TANK GP-FUEL

5E7591 TANK GP-FUEL S/N 1NL1-75

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	085-3453	TANK-FUEL	1		
2	8T-4183	BOLT	3	M	
3	081-2811	LOCKWASHER	3		
4	084-6614	WASHER	4		
5	081-2800	NUT	1		
6	081-2754	PLUG	1		
7	5E-6462	CAP-FUEL TANK	1		
8	081-3729	STRAINER	1		
9	084-4504	GAUGE (FUEL LEVEL)	1		
10	085-3017	SLEEVE	2		
11	083-1292	ELBOW	1		

5E-7591 TANK GP-FUEL (continued)


Ref.	Part number	Description	Qty	Code	Group page
12	082-8000	HOSE	1		
13	082-8866	HOSE	1		
14	081-2399	ELBOW	1		

CAT codes: M.

5E-7591 TANK GP-FUEL

5E7591 TANK GP-FUEL S/N 1NL76-UP

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	085-3453	TANK-FUEL	1		
2	8T-4183	BOLT (M12X1.75X40MM)	3	M	
3	1G-4054	COCK	2	C	
4	084-6614	WASHER	4		
5	081-2800	NUT	1		
6	081-2754	PLUG	1		
7	085-2119	PLUG	1	C	
8	081-3729	STRAINER	1		
9	084-4504	GAUGE (FUEL LEVEL)	1		
10	083-2087	REDUCER	2	C	
11	083-1292	ELBOW	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

1NL-KEBP4127

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99