

CATERPILLAR 3412

38S / SEBP1101


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Power train	
Power train	

6N-6938 GAUGE GP-OIL LEVEL (DIPSTICK)

6N6938 OIL LEVEL GAUGE GROUP Serial No. 38S1 to 38S4311 inclusive

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0S-1608	BOLT	1		
2	5M-2894	WASHER	3		
3	6N-2982	BRACKET	1		
4	0L-1351	BOLT	1		
	1D-4717	NUT	1		
5	6N-6292	GAUGE ASSEM.	1		
6	6N-6293	GUIDE ASSEM.	1		
7	8M-5260	SEAL	1		
8	4N-0999	PLUG	3		
(Use to Plug Optional Dipstick Locations)					

6N-6938 GAUGE GP-OIL LEVEL (DIPSTICK)

6N6938 OIL LEVEL GAUGE GROUP Serial No. 38S4312-Up

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0S-1608	BOLT	1		
2	5M-2894	WASHER	3		
3	7N-7504	BRACKET	1	C	
4	0L-1351	BOLT	1		
	1D-4717	NUT	1		
5	8N-2079	GAUGE AS-OIL LEVEL	1	C	
6	8N-2077	GUIDE AS-OIL LEVEL	1	C	
7	8M-5260	SEAL-O-RING	1		
8	4N-0999	PLUG (USE TO PLUG	3		
OPTIONAL DIPSTICKS					
LOCATIONS)					

CAT codes: C.

6N-6888 OIL LEVEL GAUGE GROUP--L.H.

6N6888 OIL LEVEL GAUGE GROUP--L.H. Rear Serial No. 38S1 to 38S4311 inclusive AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0L-1351	BOLT	1		
	1D-4717	NUT	1		
2	5M-2894	WASHER	3		
3	3S-7189	BRACKET	1		
4	0S-1588	BOLT	1		
5	6B-0933	SPACER	1		
6	4N-0999	PLUG	1		
7	8M-5260	SEAL	1		
8	6N-6889	GUIDE ASSEM.	1		
9	0T-0065	BOLT	1		

7N-0863 OIL LEVEL GAUGE GROUP--L.H.

7N863 OIL LEVEL GAUGE GROUP--L.H. Rear Serial No. 38S1 to 38S4311 inclusive FOR USE WITH 3N8904 ALARM CONTACTOR GROUP LISTED ON PAGE 313 AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0L-1351	BOLT	1		
	1D-4717	NUT	1		
2	5M-2894	WASHER	3		
3	7N-0862	BRACKET	1		
4	0S-1588	BOLT	1		
5	6B-0933	SPACER	1		
6	4N-0999	PLUG	1		
7	8M-5260	SEAL	1		
8	6N-6889	GUIDE ASSEM.	1		
9	0T-0065	BOLT	1		

8N-3919 OIL LEVEL GAUGE GROUP

8N3919 OIL LEVEL GAUGE GROUP--L.H. Rear Serial No. 38S4312-Up. AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0L-1351	BOLT	1		
	1D-4717	NUT	1		
2	5M-2894	WASHER	3		
3	3S-7189	BRACKET	1		
4	0S-1588	BOLT	1		
5	6B-0933	SPACER	1		
6	4N-0999	PLUG	1		
7	8M-5260	SEAL	1		
8	8N-2081	GUIDE ASSEM.	1		
9	0T-0065	BOLT	1		

8N-3920 GAUGE GP-OIL LEVEL

8N3920 OIL LEVEL GAUGE GROUP--L.H. Rear Serial No. 38S4312-Up FOR USE WITH 3N8904 ALARM CONTACTOR GROUP LISTED ON PAGE 313 AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0L-1351	BOLT	1		
	1D-4717	NUT	1		
2	5M-2894	WASHER	3		
3	7N-0862	BRACKET	1		
4	0S-1588	BOLT	1		
5	6B-0933	SPACER	1		
6	4N-0999	PLUG	1		
7	8M-5260	SEAL-O-RING	1		
8	8N-2081	GUIDE AS-OIL LEVEL	1		
9	0T-0065	BOLT	1		

2W-6537 FILLER GP-OIL

2W6537 OIL FILLER GROUP Serial No. 38S12759 To 38S12810 Inclusive

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	2W-6694	TUBE AS	1		
2	6N-2206	CAP AS-FILLER	1		
3	4F-7390	SEAL	1		
4	2N-8109	CLAMP	1		

2W-6537 FILLER GP-OIL

2W6537 OIL FILLER GROUP Serial No. 38S12558 To 38S12758 inclusive

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	1A-9579	BOLT	1		
	9M-1974	WASHER	1		
2	0S-1594	BOLT	1		
	5M-2894	WASHER	2		
	1D-4717	NUT	1		
3	2W-6694	TUBE AS	1		
4	6N-2206	CAP AS-FILLER	1		
5	2W-6693	STRIP	1		
6	4F-7390	SEAL	1		
7	2N-8109	CLAMP	1		

2W-6537 FILLER GP-OIL

2W6537 OIL FILLER GROUP Serial No. 38S12811-Up

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	6N-2206	CAP AS-FILLER	1	C	
2	2W-6692	TUBE AS	1	C	
3	3F-6156	HOOK	1	C	
4	4F-7390	SEAL	1		
5	2N-8109	CLAMP	1		

CAT codes: C.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

38S-SEBP1101

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99