

CATERPILLAR SR4B

3FN / SEBP2414


Contents

Section	Page
Electrical and electronics	2
Lubrication system	
Air inlet and exhaust	
Air inlet and exhaust	
Fuel system	
Basic engine	
Basic engine	

122-1194 BOX & MOUNTING GP -CABLE ACCESS

122-1194 BOX & MOUNTING GP -CABLE ACCESS S/N AAD1-UP; AAJ1-UP; 8HM1-UP; 1BN1-UP; 1HN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 2HN1-UP; 2SN1-UP; 3EN1-UP; 3FN1-UP; 2DM1-UP; 3GN1-UP; 3HN1-UP; 4EN1-UP; 4FN1-UP; 4GN1-UP; 4WN1-UP; 5SN1-UP; 5WN1-UP; 6SN1-UP; 7DN1-UP; 2GM1-UP; 7TN1-UP; 8NN1-UP; 9CN1-UP; 9EN1-UP; AAR1-UP; 8XS1-UP; 5JW1-UP; 6DW1-UP; 8GW1-UP; AAY1-UP; 3BM1-UP; 2GZ1-UP; 4DM1-UP; 5DM1-UP; 6GM1-UP; 7GM1-UP; 8DM1-UP PART OF 122-3487 CONVERSION GP-GENERATOR AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4F-8711	PLUG-BUTTON	2		
2	4V-2027	PLUG-BUTTON	8		
3	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	10		
4	123-0833	FRAME AS-BOX	1		
5	123-0835	COVER-TOP	1		
6	123-0836	COVER-BOTTOM	1		
7	1B-7182	BOLT (5/16-18X1.25-IN)	10		
8	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	10		

357-3040 BOX & MOUNTING GP -CABLE ACCESS

357-3040 BOX & MOUNTING GP -CABLE ACCESS S/N AAD1-UP; AAJ1-UP; 8HM1-UP; 1BN1-UP; 1HN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 2HN1-UP; 2SN1-UP; 3EN1-UP; 3FN1-UP; 2DM1-UP; 3GN1-UP; 3HN1-UP; 4EN1-UP; 4FN1-UP; 4GN1-UP; 4WN1-UP; 5SN1-UP; 5WN1-UP; 6SN1-UP; 7DN1-UP; 2GM1-UP; 7TN1-UP; 8NN1-UP; 9CN1-UP; 9EN1-UP; AAR1-UP; 8XS1-UP; 5JW1-UP; 6DW1-UP; 8GW1-UP; AAY1-UP; 3BM1-UP; 2GZ1-UP; 4DM1-UP; 5DM1-UP; 6GM1-UP; 7GM1-UP; 8DM1-UP PART OF 361-2595 BOX GP-EXTENSION TERMINAL AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	10		
2	123-0835	COVER-TOP	1		
3	123-0836	COVER-BOTTOM	1		
4	235-8354	FASTENER	4		
5	357-3039	FRAME AS-BOX	1		
6	361-3326	PLATE	4		
7	1B-7182	BOLT (5/16-18X1.25-IN)	10		
8	3E-4337	RIVET-POP	8		
9	4F-8711	PLUG-BUTTON	2		
10	4V-2027	PLUG-BUTTON	8		
11	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	10		

115-2513 BOX GP-EXTENSION TERMINAL -CIRCUIT BREAKER

115-2513 BOX GP-EXTENSION TERMINAL -CIRCUIT BREAKER S/N AAD1-UP; AAJ1-UP; 8HM1-UP; 1BN1-UP; 1HN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 2HN1-UP; 2SN1-UP; 3EN1-UP; 3FN1-UP; 2DM1-UP; 3GN1-UP; 3HN1-UP; 4EN1-UP; 4FN1-UP; 4GN1-UP; 4WN1-UP; 5SN1-UP; 5WN1-UP; 6SN1-UP; 7DN1-UP; 2GM1-UP; 7TN1-UP; 8NN1-UP; 9CN1-UP; 9EN1-UP; AAR1-UP; 8XS1-UP; 6DW1-UP; 8GW1-UP; 2GZ1-UP; 3BM1-UP; 4DM1-UP; 5DM1-UP; 6GM1-UP; 7GM1-UP; 8DM1-UP PART OF 216-7933 BOX GP-EXTENSION TERMINAL, 122-0319, 122-3488, 252-7525 MOUNTING GP-CIRCUIT BREAKER FOR USE WITH 690-FRAME, 820-FRAME AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	104-3045	BOLT-FLANGE HEAD (5/16-18X0.625-IN)	10		
2	124-5634	COVER AS-TOP	1		
3	124-5635	FRAME AS-EXTENSION	1		
4	124-5637	COVER-BOTTOM	1		
5	1B-7182	BOLT (5/16-18X1.25-IN)	10		
6	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	10		

361-2595 BOX GP-EXTENSION TERMINAL -LOW VOLTAGE

361-2595 BOX GP-EXTENSION TERMINAL -LOW VOLTAGE S/N AAD1-UP; AAJ1-UP; 8HM1-UP; 1BN1-UP; 1HN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 2HN1-UP; 2SN1-UP; 3EN1-UP; 3FN1-UP; 2DM1-UP; 3GN1-UP; 3HN1-UP; 4EN1-UP; 4FN1-UP; 4GN1-UP; 4WN1-UP; 5SN1-UP; 5WN1-UP; 6SN1-UP; 7DN1-UP; 2GM1-UP; 7TN1-UP; 8NN1-UP; 9CN1-UP; 9EN1-UP; AAR1-UP; 8XS1-UP; 5JW1-UP; 6DW1-UP; 8GW1-UP; AAY1-UP; 3BM1-UP; 2GZ1-UP; 4DM1-UP; 5DM1-UP; 6GM1-UP; 7GM1-UP; 8DM1-UP PART OF 361-2453 CONVERSION GP-GENERATOR AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	6		
2	123-0837	PANEL AS	1		
3	357-3040	BOX & MOUNTING GP (CABLE ACCESS)	1	Y	

CAT codes: Y.

141-1808 BOX GP-GENERATOR CONNECTION

141-1808 BOX GP-GENERATOR CONNECTION S/N 2DM1-UP; 2GM1-UP; 3EN1-UP; 3FN1-UP; 3GN1-UP; 3HN1-UP; 4WN1-UP; 6SN1-UP; 7DN1-UP; 9EN1-UP; 5JW1-UP; 6DW1-UP; 3BM1-UP; 8GW1-UP; 4DM1-UP; 5DM1-UP; 8HM1-UP; 1BN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP 690-FRAME AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	60		
2	115-2508	COVER GP-GENERATOR (TOP)	1	Y	
3	115-9550	BRACKET	1		
4	121-9641	BRACKET	1		
5	126-7605	SCREEN AS-AIR	1		
6	128-1480	FRAME GP-GENERATOR CONNECTION	1	Y	
7	128-3344	PANEL	2		
8	128-5952	PANEL-BACK	1		
9	128-6149	COVER GP-GENERATOR (FRONT)	1	Y	
10	129-1895	PANEL AS-LOWER	1		
11	141-4812	BRACKET-MOUNTING (RH)	1		
12	141-4813	BRACKET-MOUNTING (LH)	1		
13	5M-3062	BOLT (3/8-16X0.75-IN)	6		

141-1808 BOX GP-GENERATOR CONNECTION (continued)


Ref.	Part number	Description	Qty	Code	Group page
14	4L-6454	BOLT (3/8-16X1-IN)	18		
16	8T-9364	BOLT (1/4-20X0.625-IN)	5		
17	8T-4896	WASHER-HARD (10.2X18.5X2.5-MM THK)	24		
18	8T-4205	WASHER-HARD (7.2X14.5X2-MM THK)	5		

CAT codes: Y.

357-6837 BOX GP-GENERATOR CONNECTION

357-6837 BOX GP-GENERATOR CONNECTION S/N 2DM1-UP; 2GM1-UP; 3FN1-UP; 3GN1-UP; 3HN1-UP; 4WN1-UP; 6SN1-UP; 7DN1-UP; 9EN1-UP; 5JW1-UP; 6DW1-UP; 8GW1-UP; 3BM1-UP; 4DM1-UP; 8HM1-UP; 1BN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 3EN1-UP FOR USE WITH 690-FRAME AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	60		
2	115-2508	COVER GP-GENERATOR	1	Y	
3	115-9550	BRACKET	1		
4	121-9641	BRACKET	1		
5	126-7605	SCREEN AS-AIR	1		
6	128-6149	COVER GP-GENERATOR	1	Y	
7	141-4812	BRACKET-MOUNTING (RH)	1		
8	141-4813	BRACKET-MOUNTING (LH)	1		
9	155-2001	RETAINER	16		
10	308-9260	FASTENER-SPECIAL	16		
11	357-3042	PANEL	2		
12	357-6833	FRAME GP-GENERATOR CONNECTION	1	Y	
13	357-6834	PANEL	1		

357-6837 BOX GP-GENERATOR CONNECTION (continued)


Ref.	Part number	Description	Qty	Code	Group page
14	357-6835	PANEL AS-LOWER	1		
15	4L-6454	BOLT (3/8-16X1-IN)	18		
16	5M-3062	BOLT (3/8-16X0.75-IN)	6		
17	8T-4205	WASHER-HARD (7.2X14.5X2-MM THK)	5		
18	8T-4896	WASHER-HARD (10.2X18.5X2.5-MM THK)	24		
19	8T-8908	BOLT (1/4-20X1-IN)	2		
20	8T-9364	BOLT (1/4-20X0.625-IN)	3		

CAT codes: Y.

252-7458 BUS BAR AS

252-7458 BUS BAR AS S/N 2DM1-UP; 2GM1-UP; 1HN1-UP; 2DN1-UP; 2FN1-UP; 2GN1-UP; 2HN1-UP; 2SN1-UP; 3EN1-UP; 3FN1-UP; 3GN1-UP; 3HN1-UP; 3BM1-UP; 4EN1-UP; 4FN1-UP; 4GN1-UP; 4WN1-UP; 5SN1-UP; 5WN1-UP; 6SN1-UP; 7DN1-UP; 7TN1-UP; 8NN1-UP; 4DM1-UP; 9CN1-UP; 5DM1-UP; 6GM1-UP; 7GM1-UP; 8DM1-UP; 8HM1-UP; 1BN1-UP 1600-AMPERE TO 2500-AMPERE PART OF 252-7531, 252-7532 CIRCUIT BREAKER GP FOR USE WITH R-FRAME BREAKERS AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	272-6635	PLATE	2		
2	272-6636	PLATE	2		
3	272-6637	PLATE	2		
4	272-6638	BRACKET	6		
5	1F-7958	NUT-FULL (1/2-13-THD)	6		
6	206-5143	BOLT (M12X1.75X50-MM)	12	M	
7	8T-4184	BOLT (M12X1.75X45-MM)	6	M	
8	8T-4223	WASHER-HARD (13.5X25.5X3-MM THK)	30		
9	8T-4244	NUT (M12X1.75-THD)	18	M	
10	8T-8919	BOLT (1/2-13X1.75-IN)	6		

CAT codes: M.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

3FN-SEBP2414

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99