

CATERPILLAR SR4

5EA / SEBP1537


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Basic engine	
Basic engine	

107-3057 BOX GP-EXTENSION TERMINAL

107-3057 BOX GP-EXTENSION TERMINAL PART OF 3N-5566, 3N-5567 BOX GP-GENERATOR CONNECTION FOR USAGE REFER TO CHART 4W-8145 AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	3N-6712	BOX AS-EXTENSION	1		
	4K-9097	NUT-WELD (5/16-18-THD)	22		
2	7W-7310	COVER-BOTTOM	1		
3	104-3045	BOLT-FLANGE HEAD (5/16-18X0.625-IN)	8		

3N-6710 BOX GP-EXTENSION TERMINAL

3N-6710 BOX GP-EXTENSION TERMINAL RH MOUNTED PART OF 3N-5566, 3N-5567 BOX GP-GENERATOR CONNECTION AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	1P-5121	SCREW-HEAD (5/16-18X1-IN)	22	C	
2	3N-6713	COVER AS-EXTENSION BOX	1		
3	3N-6712	BOX AS-EXTENSION	1		
4	7W-7310	COVER-BOTTOM	1	C	

CAT codes: C.

3N-5567 BOX GP-GENERATOR CONNECTION

3N-5567 BOX GP-GENERATOR CONNECTION S/N 5EA3771-UP; 5FA3948-UP Type 1 AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0S-0509	BOLT (3/8-16X0.75-IN)	4		
	3N-6734	NUT-SPRING (3/8-16-THD)	4		
	9F-5644	LOCKWASHER	4		
2	3N-6710	BOX GP-EXTENSION TERMINAL	1	Y	
3	3N-7309	CONNECTION AS	1		

CAT codes: Y.

3N-5567 BOX GP-GENERATOR CONNECTION

3N-5567 BOX GP-GENERATOR CONNECTION S/N 5EA3771-UP; 5FA3948-UP Type 2 AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	0S-0509	BOLT (3/8-16X0.75-IN)	4		
	3N-6734	NUT-SPRING (3/8-16-THD)	4		
	9F-5644	LOCKWASHER	4		
2	107-3057	BOX GP-EXTENSION TERMINAL	1	Y	
3	3N-7309	CONNECTION AS	1		
4	3N-6713	COVER AS-EXTENSION BOX	1	Y	
5	106-1771	FASTENER GP-EXTENSION BOX	1	Y	

CAT codes: Y.

4W-8148 CIRCUIT BREAKER AS

4W-8148 CIRCUIT BREAKER AS 125 AMPERE FOR USE WITH 4W-8214 CANNOT BE USED WITH TERMINAL STRIP AN ATTACHMENT

Kit / parts list. The current source card does not provide a separate drawing.

Ref.	Part number	Description	Qty	Code	Group
	7W-0167	CIRCUIT BREAKER AS	1		page

4W-8149 CIRCUIT BREAKER AS

4W-8149 CIRCUIT BREAKER AS 125 AMPERE. WITH SHUNT TRIP FOR USE WITH 4W-8214, OR CANNOT BE USED WITH TERMINAL STRIP AN ATTACHMENT

Kit / parts list. The current source card does not provide a separate drawing.

Ref.	Part number	Description	Qty	Code	Group
	4W-9617	CIRCUIT BREAKER AS (125-AMPERE)	1		page

4W-8150 CIRCUIT BREAKER AS

4W-8150 CIRCUIT BREAKER AS 150 AMPERE FOR USE WITH 4W-8214 CANNOT BE USED WITH TERMINAL STRIP AN ATTACHMENT

Kit / parts list. The current source card does not provide a separate drawing.

Ref.	Part number	Description	Qty	Code	Group
	7W-0168	CIRCUIT BREAKER AS	1		page

4W-8151 CIRCUIT BREAKER AS

4W-8151 CIRCUIT BREAKER AS 150 AMPERE. WITH SHUNT TRIP FOR USE WITH 4W-8214 CANNOT BE USED WITH TERMINAL STRIP AN ATTACHMENT


Kit / parts list. The current source card does not provide a separate drawing.

Ref.	Part number	Description	Qty	Code	Group
	4W-9618	CIRCUIT BREAKER AS (150-AMPERE)	1		page

104-4379 CIRCUIT BREAKER GP

104-4379 CIRCUIT BREAKER GP 125 AMPERE FOR USAGE REFER TO CHART 4W-8145 AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	100-5954	BAR (T1, 250-AMPERE)	1		
2	100-5955	BAR AS (T2, 250-AMPERE)	1		
3	100-5956	BAR (T3, 250-AMPERE)	1		
4	104-7614	CIRCUIT BREAKER GP (125-AMPERE)	1		
	104-8679	SHUNT	1		
5	9Y-4275	FILM-INFORMATION (TERMINAL STRIP)	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

5EA-SEBP1537

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99