

CATERPILLAR PR-1000C

5XC / KEBP0082


Contents

Section	Page
Basic engine	2
Lubrication system	
Air inlet and exhaust	
Fuel system	
Fuel system	
Basic engine	
Basic engine	
Electrical and electronics	
Hydraulic system	
Frame, guards and enclosure	
Undercarriage	
Power train	
Hydraulic system	
Hydraulic system	
Cooling system	
Cooling system	
Catalog items	
Catalog items	

3N-2915 ADAPTER GP-SEAL

3N-2915 ADAPTER GP-SEAL S/N 79V25019-UP PART OF 130-4005 ENGINE AR

Drawing 1 of 1



VIEWED FROM
UPPER RIGHT REAR
OF ENGINE


Ref.	Part number	Description	Qty	Code	Group page
1	3N-2902	ADAPTER-AIR CLEANER	1		
2	3N-2903	GASKET	1	B	
3	2B-2695	BOLT (5/16-18X0.875-IN)	6		
4	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		

CAT codes: B.

122-8962 AIR COMPRESSOR GP

122-8962 AIR COMPRESSOR GP S/N 5XC155-UP 13.5 CFM. MOUNTED ON RH TOP OF FRONT COVER PART OF 7R-4319 SUPPLY GP-AIR FOR USE WITH HIGH MOUNTED ALTERNATOR, HIGH OR LOW MOUNTED COMPRESSOR DRIVE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	6K-1972	ELBOW-FLARED	1		
2	061-6750	HOSE AS	1	I	
3	2N-1287	ELBOW-FLARED	1		
4	2N-3378	ELBOW-FLARED	2		
5	122-8966	AIR COMPRESSOR GP	1	Y	
6	4N-6708	PULLEY-AIR COMPRESSOR	1		
7	9M-5082	STUD-TAPERLOCK	4		
8	4S-9191	WASHER (12X22.5X5-MM THK)	4		
9	3S-1546	NUT-FULL (7/16-14-THD)	4		
10	6N-9042	GASKET	1		

122-8962 AIR COMPRESSOR GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
11	4N-6662	PLATE	1		
12	9N-1828	GASKET	1		
13	7L-7262	ELBOW-FLARED	1		
14	0T-0772	BOLT (7/16-14X1.5-IN)	4		
15	9N-6473	BRACKET-LIFTING	1		
16	4F-8965	BOLT (7/16-14X1.125-IN)	2		
17	5P-8244	WASHER-HARD (12X22.5X2.5-MM THK)	6		
18	1H-5166	CLIP	1		
19	2N-1343	HOSE AS	1	I	
20	3B-4618	PIN-COTTER	1		
21	5P-4295	CLIP	1		
22	3R-5387	CONNECTOR	1		
23	4N-8470	HOSE AS	1	I	
24	8T-6764	PLUG-PIPE (1/8-27-THD)	1		
25	5P-8248	WASHER-HARD (20X36.5X3.5-MM THK)	1		

CAT codes: I, Y.

122-8966 AIR COMPRESSOR GP

122-8966 AIR COMPRESSOR GP S/N 5XC155-UP PART OF 122-8962 AIR COMPRESSOR GP FIELD REPLACEMENT ORDER 126-6110

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-6764	PLUG-PIPE (1/8-27-THD)	2		
2	3F-5289	KEY-CRANKSHAFT	1		
3	6V-0387	PLUG-PIPE	1		
4	8M-7065	GASKET (AIR INLET)	1		
5	9M-0397	ADAPTER	1		
6	7F-6547	NUT	1		
7	3B-4505	LOCKWASHER	2		
8	2B-2695	BOLT (5/16-18X0.875-IN)	2		
9	4P-3966	PISTON & ROD AS	1		
10	124-5572	VALVE AS-RELIEF (AIR COMPRESSOR)	1		
AVAILABLE REPAIR KIT(S):					
	7E-8923	KIT-CRANKSHAFT BEARING (AIR COMPRESSOR)	1		
(INCLUDES SEALS, BEARING WASHERS, INSERTS, & GASKETS)					
	7E-8925	KIT-STANDARD RING (AIR COMPRESSOR)	1		


122-8966 AIR COMPRESSOR GP (continued)

Ref.	Part number	Description	Qty.	Code	Group page
(INCLUDES RINGS & INSTRUCTION SHEET)					
	164-7572	KIT-RING (AIR COMPRESSOR)	1		
(INCLUDES GASKET, SPRINGS, VALVES, SEATS, PISTON, STOPS, & O-RINGS)					
	150-5146	KIT-UNLOADER (AIR COMPRESSOR)	1		

126-6110 AIR COMPRESSOR GP

126-6110 AIR COMPRESSOR GP S/N 5XC155-UP FIELD REPLACEMENT FOR 122-8966

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-6764	PLUG-PIPE (1/8-27-THD)	2		
2	3F-5289	KEY-CRANKSHAFT	1		
3	6V-0387	PLUG-PIPE	1		
4	8M-7065	GASKET (AIR INLET)	1		
5	9M-0397	ADAPTER	1		
6	7F-6547	NUT	1		
7	3B-4505	LOCKWASHER	2		
8	2B-2695	BOLT (5/16-18X0.875-IN)	2		
9	4P-3966	PISTON & ROD AS	1		
10	124-5572	VALVE AS-RELIEF (AIR COMPRESSOR)	1		
AVAILABLE REPAIR KIT(S):					
	7E-8923	KIT-CRANKSHAFT BEARING (AIR COMPRESSOR)	1		
(INCLUDES SEALS, BEARINGS, WASHERS, INSERTS, & GASKETS)					
	164-7572	KIT-RING (AIR COMPRESSOR)	1		
(INCLUDES RINGS & INSTRUCTION SHEET)					


126-6110 AIR COMPRESSOR GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
	7E-8926	KIT-CYLINDER HEAD (AIR COMPRESSOR)	1		
(INCLUDES GASKET, SPRINGS, VALVES, SEATS, PISTONS, STOPS & O-RINGS)					
	150-5146	KIT-UNLOADER (AIR COMPRESSOR)	1		

6N-6090 AIR COMPRESSOR GP

6N-6090 AIR COMPRESSOR GP S/N 5XC138-UP PART OF 6N-8895 AIR COMPRESSOR GP

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	3F-5289	KEY-CRANKSHAFT	1		
2	6N-5877	COVER-FRONT	1		
3	8T-6757	PLUG-PIPE	1		
4	6N-2099	CRANKCASE AS-AIR COMPRESSOR	1		
6	7W-6492	PLUG-PIPE (1/2-14-THD)	2		
7	6N-2098	GASKET-CYLINDER HEAD	1		
8	3L-0526	BOLT (7/16-14X0.875-IN)	4	C	
9	6N-5878	CRANKSHAFT	1		
10	7F-6547	NUT	1		

6N-6090 AIR COMPRESSOR GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
11	7N-4837	PISTON AS-COMPRESSOR	2		
12	8T-6764	PLUG-PIPE (1/8-27-THD)	1		
13	6N-2100	COVER AS-REAR	1		
14	6N-2106	ROD AS-CONNECTING	2		
15	2F-0194	STUD	2		
	9S-8751	NUT-FULL (5/16-24-THD)	2		
	3B-4505	LOCKWASHER	2		
16	9M-0384	ADAPTER	1		
	1S-7107	GASKET	1		
17	0S-1619	BOLT (3/8-16X3-IN)	6	C	
18	8M-7065	GASKET (AIR INLET)	1		
19	5P-0060	BOLT (7/16-14X0.75-IN)	4	C	
20	3B-4507	LOCKWASHER	8		
21	7N-0243	LOCK-ROD BOLT	2		
22	6N-5876	GASKET-FRONT COVER	1		
23	8N-3665	KIT-SEAL	1	C	
(INCL SEALS & INSTR)					
24	5M-6509	SEAL-O-RING	1		
25	2H-5021	SEAL-LIP TYPE	1		
26	8H-9789	BALL BEARING	1		
27	9L-1518	WASHER-THRUST	1		
AVAILABLE REPAIR KIT(S):					
	8N-3666	KIT-AIR COMPRESSOR	1		
(INCLUDES PISTONS, GUIDE, PLUNGER, SEAT, SPRING, SADDLE, RINGS, BOLTS, LOCKWASHERS, WASHERS, LOCK, BEARING, VALVES, GASKETS & INSTRUCTIONS)					
	6I-1220	KIT-UNLOADER (AIR COMPRESSOR)	1		

CAT codes: C.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

5XC-KEBP0082

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99