

CATERPILLAR 3056

7AK / SEBP2216


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Electrical and electronics	

6I-4038 FILLER GP-ENGINE OIL

6I-4038 FILLER GP-ENGINE OIL

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	6I-0513	CAP (ENGINE OIL FILL)	1		
2	6I-0514	SEAL (ENGINE OIL FILLER CAP)	1		
3	6I-0217	BOLT (M8X1.25X20-MM)	1	M	
4	6I-0512	GASKET	1		
5	6I-4037	PLATE	1		

CAT codes: M.

100-3736 FILTER GP-ENGINE OIL

100-3736 FILTER GP-ENGINE OIL

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	6I-0654	BOLT (M10X1.5X25-MM)	5	M	
2	7W-2327	FILTER AS-ENGINE OIL	2		
3	121-3415	HEAD AS-OIL FILTER	1		
4	6I-4786	GASKET	1		

CAT codes: M.

126-6980 FUMES DISPOSAL GP

126-6980 FUMES DISPOSAL GP S/N 7AK1685-3377

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	2S-3440	CLAMP-HOSE	2		
2	112-7018	PIPE	1		
3	112-7019	HOSE (CRANKCASE BREATHER)	1		
4	126-6978	BREATHER AS	1		
5	113-4606	SEAL-O-RING	1		
6	124-0506	SEAL	1		
7	126-6979	SEPARATOR (FUMES DISPOSAL)	1		

126-6980 FUMES DISPOSAL GP

126-6980 FUMES DISPOSAL GP S/N 7AK3378-4357

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	2S-3440	CLAMP-HOSE	2		
2	112-7018	PIPE	1		
3	112-7019	HOSE (CRANKCASE BREATHER)	1		
4	160-0525	BREATHER AS (CRANKCASE)	1		
5	124-0506	SEAL	1		
6	160-0526	SEAL-O-RING	1		
7	126-6979	SEPARATOR (FUMES DISPOSAL)	1		

126-6980 FUMES DISPOSAL GP

126-6980 FUMES DISPOSAL GP S/N 7AK4358-UP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	2S-3440	CLAMP-HOSE	2		
2	112-7018	PIPE	1		
3	278-4695	HOSE	1		
4	184-4610	BREATHER GP (CRANKCASE)	1		
5	124-0506	SEAL	1		
6	160-0526	SEAL-O-RING	1		
7	185-3159	FILTER ELEMENT-BREATHER (CRANKCASE)	1		

6I-0515 FUMES DISPOSAL GP

6I-0515 FUMES DISPOSAL GP

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	101-3450	CLAMP-HOSE	1		
2	6I-0516	HOSE (FUMES DISPOSAL)	1		
3	6I-0517	SPRING (CRANKCASE BREATHER HOSE)	1		
4	7C-1281	BRACKET	1		

118-5050 GAUGE GP-OIL LEVEL (DIPSTICK) -ENGINE

118-5050 GAUGE GP-OIL LEVEL (DIPSTICK) -ENGINE


Kit / parts list. The current source card does not provide a separate drawing.

Ref.	Part number	Description	Qty	Code	Group page
	130-1161	GAUGE AS-OIL LEVEL (DIPSTICK) (ENGINE)	1		
	6I-1497	SEAL	1		
	124-7702	TUBE AS	2		

6I-4372 LINES GP-ENGINE OIL

6I-4372 LINES GP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	6I-0260	BOLT (M8X1.25X25-MM)	2	M	
2	6I-0291	NUT (M8X1.25-THD)	1	M	
3	6I-4373	HOUSING AS	1		
4	6I-0787	RING-RETAINING	1		
5	7W-4648	SEAT-SPRING	1		
6	7W-4650	SPRING	1		
7	7W-4782	PLUNGER	1		
8	6I-4374	BOLT (M8X1.25X60-MM)	2	M	
9	307-9589	TUBE-OIL SUCTION	1		
10	214-5974	BRACKET	1		
11	6I-4681	GASKET	1		
12	7W-4655	GASKET	1		

6I-4372 LINES GP-ENGINE OIL (continued)

Ref.	Part number	Description	Qty	Code	Group page
13	8R-3270	BOLT	1	M	
14	132-8848	WASHER	1		
15	6I-0217	BOLT (M8X1.25X20-MM)	1	M	

CAT codes: M.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

7AK-SEBP2216

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99