

CATERPILLAR 235D

8TJ / SEBP2033


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Power train	
Power train	
Hydraulic system	
Hydraulic system	
Air inlet and exhaust	
Hydraulic system	

2P-1784 PUMP GP-ENGINE OIL

2P1784 PUMP GP-ENGINE OIL 6N2642-PAGE 24.01

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	3B-1915	BOLT	2		
2	0S-1619	BOLT	1		
3	4N-5353	ELBOW-LINE	1		
	2P-8746	GASKET	1		
4	0S-1590	BOLT	3		
5	6N-2642	PUMP GP-ENGINE OIL	1	CY	
6	5M-2894	WASHER	4		

CAT codes: C, Y.

6N-2642 PUMP GP-ENGINE OIL

6N2642 PUMP GP-ENGINE OIL TYPE 2 6I1346-PAGE 26 PART OF 2P1784 PUMP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	6I-1346	PUMP GP-ENGINE OIL	1	YR	
2	7W-0507	GEAR-OIL PUMP DRIVE	1		
3	0S-1590	BOLT	1		
4	1P-7346	WASHER	1		

CAT codes: R, Y.

6N-2642 PUMP GP-ENGINE OIL

6N2642 PUMP GP-ENGINE OIL TYPE 1 PART OF 2P1784 PUMP-ENGINE OIL

Arrangement composition. Follow the table links to the component drawings.


Ref.	Part number	Description	Qty	Code	Group page
	4P-4020	PUMP GP-ENGINE OIL	1	Y	5
	0S-1590	BOLT	1		
	8S-0497	GEAR-OIL PUMP INPUT	1		
	8M-5599	KEY-SPECIAL WOODRUFF	1		
	1P-7346	WASHER	1		

CAT codes: Y.

4P-4020 PUMP GP-ENGINE OIL

4P4020 PUMP GP-ENGINE OIL TWO SECTION GEAR PART OF 6N2642 PUMP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4W-2322	BODY AS-OIL PUMP	1		
2	2P-1170	SHAFT AS-GEAR	1		
3	4B-9782	BALL	1		
4	4B-9880	BALL	1		
5	1F-1006	DOWEL	1		
6	8S-6511	BEARING-SLEEVE	2		
7	2P-1781	SPACER-OIL PUMP	1		
8	4P-3546	VALVE AS-RELIEF	1		
9	2B-2694	BOLT	1		
	9M-1974	WASHER-HARD	1		
10	4N-3732	COVER-VALVE	1		
11	6N-1036	GEAR-OIL PUMP (8 TEETH)	2		
12	0T-0065	BOLT	3		
13	8S-0493	SHAFT AS-PUMP	1		
14	6I-1345	SHAFT AS-OIL PUMP	1		


4P-4020 PUMP GP-ENGINE OIL (continued)

Ref.	Part number	Description	Qty	Code	Group page
15	4W-2321	BODY AS-PUMP	1		
16	8S-6511	BEARING-SLEEVE	2		
17	1B-8709	KEY-WOODRUFF	1		

6I-1346 PUMP GP-ENGINE OIL

6I1346 PUMP GP-ENGINE OIL*R TWO SECTION GEAR PART OF 6N2642 PUMP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4W-2322	BODY AS-OIL PUMP	1		
2	2P-1170	SHAFT AS-GEAR	1		
3	4B-9782	BALL	1		
4	4B-9880	BALL	1		
5	1F-1006	DOWEL	1		
6	8S-6511	BEARING-SLEEVE	2		
7	2P-1781	SPACER-OIL PUMP	1		
8	4P-3546	VALVE AS-RELIEF	1		
9	2B-2694	BOLT	1		
	9M-1974	WASHER-HARD	1		
10	4N-3732	COVER-VALVE	1		
11	6N-1036	GEAR-OIL PUMP (8 TEETH)	2		
12	0T-0065	BOLT	3		
13	8S-0493	SHAFT AS-PUMP	1		
14	6I-1345	SHAFT AS-OIL PUMP	1		


6I-1346 PUMP GP-ENGINE OIL (continued)

Ref.	Part number	Description	Qty	Code	Group page
15	4W-2321	BODY AS-PUMP	1		
16	8S-6511	BEARING-SLEEVE	2		
17	1B-8709	KEY-WOODRUFF	1		

2P-6105 LINES GP-ENGINE OIL

2P6105 LINES GP-ENGINE OIL

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	6C-5381	TUBE AS	1	C	
2	5M-6213	PLUG	1		
3	114-2687	SEAL-O-RING	3		
4	126-7010	TUBE AS	1		
5	0S-1594	BOLT (3/8-16X1IN)	3		
6	4J-8997	SEAL	1		
7	0S-1571	BOLT (3/8-16X1.75IN)	1		
	1L-5081	SPACER (.562IN THK)	1		
8	4L-3641	CLIP	1		
9	2P-1739	TUBE AS-PUMP	1		
10	0T-0102	BOLT (3/8-16X.625IN)	2		
	0L-0364	LOCK	2		
11	7W-9020	BELL AS-PUMP SUCTION	1	C	
12	8S-8874	LOCK-NUT	1		
13	8M-0904	GASKET	1		

2P-6105 LINES GP-ENGINE OIL (continued)

Ref.	Part number	Description	Qty	Code	Group page
14	0L-2070	BOLT (3/8-16X2.25IN)	1		
15	2S-1541	ORIFICE-JET	6		
16	1A-2029	BOLT (3/8-16X1.125IN)	1		
17	2M-5407	GASKET	1		
18	5M-2894	WASHER (2.5MM THK)	1		

CAT codes: C.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

8TJ-SEBP2033

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99