

CATERPILLAR SR4B

9XZ / SEBP2922


Contents

Section	Page
Air inlet and exhaust	2
Cooling system	
Air inlet and exhaust	
Basic engine	
Electrical and electronics	

154-3413 ADAPTER GP-GENERATOR COUPLING

154-3413 ADAPTER GP-GENERATOR COUPLING S/N 8LZ1-UP; 8TZ1-UP; 9GZ1-UP; 9MZ1-UP; 9RZ1-UP; 9WZ1-UP; 9XZ1-UP PART OF 158-6413, 158-6415, 158-6417, 158-6419, 158-6421, 158-6423, 158-6425, 158-6427, 158-6429, 158-6431, 238-2691, 238-2693, 290-1519, 318-5157, 318-5159, 318-5161, 318-5165, 347-1821, 347-1823, 386-1359, 441-4867, 448-5545, 448-5547 GENERATOR GP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	0S-1588	BOLT (3/8-16X1.25-IN)	4		
2	0S-1625	BOLT (5/8-11X2.5-IN)	8		
3	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	4		
4	5P-8247	WASHER-HARD (17X32X3.5-MM THK)	8		
	127-4374	SEAL	1	F	
	152-5183	SLEEVE-WEAR	1	F	
	7M-5130	PIN-SPRING	1	F	
AVAILABLE REPAIR KIT(S):					
	342-2409	KIT-BEARING	1		
(INCLUDES COUPLINGS, NIPPLES, PLUGS & FITTING)					

CAT codes: F.

121-5423 AIR FILTER GP-GENERATOR

121-5423 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP; 8LZ1-UP; 8PZ1-UP; 8TZ1-UP; 9DZ1-UP; 9GZ1-UP; 9MZ1-UP; 9RZ1-UP; 9WZ1-UP; 9XZ1-UP FOR USE WITH 820-FRAME AN ATTACHMENT

Drawing 1 of 1




LEFT SIDE VIEW

Ref.	Part number	Description	Qty	Code	Group page
1	128-1110	FRAME AS-FILTER	1		
2	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		
3	128-1114	SHIELD AS-FILTER	1		
4	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
5	1D-4541	BOLT (5/16-18X3-IN)	6		
6	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		
AVAILABLE REPAIR KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)	1		
(INCLUDES GASKETS)					

361-4913 AIR FILTER GP-GENERATOR

361-4913 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP; 8LZ1-UP; 8PZ1-UP; 8TZ1-UP; 9DZ1-UP; 9GZ1-UP; 9MZ1-UP; 9RZ1-UP; 9WZ1-UP; 9XZ1-UP FOR USE WITH 820-FRAME AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		
2	128-1114	SHIELD AS-FILTER	1		
3	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
4	155-2001	RETAINER	4		
5	308-9260	FASTENER-SPECIAL	4		
6	361-4914	FRAME AS-FILTER	1		
7	1D-4541	BOLT (5/16-18X3-IN)	6		
8	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		


361-4913 AIR FILTER GP-GENERATOR (continued)

Ref.	Part number	Description	Qty.	Code	Group page
AVAILABLE GASKET KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)			
(INCLUDES GASKETS)					

361-7004 AIR FILTER GP-GENERATOR

361-7004 AIR FILTER GP-GENERATOR S/N 9DZ1-UP; 9RZ1-UP; 9XZ1-UP FOR USE WITH PETROLEUM, 820-FRAME AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	49		
2	115-9550	BRACKET	1		
3	116-9991	COVER GP-EXTENSION BOX	1	Y	
4	141-4812	BRACKET-MOUNTING (RH)	1		
5	141-4813	BRACKET-MOUNTING (LH)	1		
6	155-2001	RETAINER	16		
7	357-3041	FRAME GP-GENERATOR CONNECTION	1	Y	
8	357-3042	PANEL (SLIDE)	2		
9	357-3044	PANEL-LOWER	1		
10	381-9394	PANEL (FRONT)	1		
11	384-5553	FASTENER-SPECIAL	16		
12	4L-6454	BOLT (3/8-16X1-IN)	18		
13	5M-3062	BOLT (3/8-16X0.75-IN)	4		
14	8T-4205	WASHER-HARD (7.2X14.5X2-MM THK)	3		

361-7004 AIR FILTER GP-GENERATOR (continued)


Ref.	Part number	Description	Qty	Code	Group page
15	8T-4896	WASHER-HARD (10.2X18.5X2.5-MM THK)	22		
16	8T-9364	BOLT (1/4-20X0.625-IN)	3		
	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1	F	
	128-1114	SHIELD AS-FILTER	1	F	
	361-4914	FRAME AS-FILTER	1	F	
	4M-6424	BOLT (5/16-18X3-IN)	6	F	
	8T-4224	WASHER-HARD (8.8X16X2-MM THK)	6	F	

CAT codes: F, Y.


381-9401 AIR FILTER GP-GENERATOR

381-9401 AIR FILTER GP-GENERATOR S/N 8PZ1-UP; 9DZ1-UP; 9RZ1-UP; 9XZ1-UP FOR USE WITH PETROLEUM, 820/860-FRAME AN ATTACHMENT

Drawing 1 of 2




REFER TO ALL ILLUSTRATIONS OF THIS GROUP FOR AUXILIARY VIEWS




381-9401 AIR FILTER GP-GENERATOR (continued)

Drawing 2 of 2



VIEW C-C



SECTION B-B

Ref.	Part number	Description	Qty	Code	Group page
1	106-1746	FASTENER	4		
2	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	66		
3	115-9550	BRACKET	1		
4	116-9991	COVER GP-EXTENSION BOX	1	Y	
5	123-0835	COVER-TOP	1		
6	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		

381-9401 AIR FILTER GP-GENERATOR (continued)

Ref.	Part number	Description	Qty	Code	Group page
7	128-1114	SHIELD AS-FILTER	1		
8	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
9	141-4812	BRACKET-MOUNTING (RH)	1		
10	141-4813	BRACKET-MOUNTING (LH)	1		
11	155-2001	RETAINER	16		
12	357-3039	FRAME AS-BOX	1		
13	357-3041	FRAME GP-GENERATOR CONNECTION	1	Y	
14	357-3042	PANEL	2		
15	357-3044	PANEL-LOWER	1		
16	361-3326	PLATE	4		
17	361-4914	FRAME AS-FILTER	1		
18	367-6823	BRACKET AS	1		
19	381-9394	PANEL	1		
20	381-9396	PANEL-BOTTOM	1		
21	384-5553	FASTENER-SPECIAL	16		
22	397-8931	PLUG-CAP	2		
23	0S-0509	BOLT (3/8-16X0.75-IN)	4		
24	0S-1594	BOLT (3/8-16X1-IN)	18		
25	0S-1616	BOLT (1/4-20X1-IN)	2		
26	2A-0762	BOLT (1/4-20X0.625-IN)	3		
27	4M-6424	BOLT (5/16-18X3-IN)	6		
28	4V-2027	PLUG-BUTTON	8		
29	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	22		
30	5P-0537	WASHER-HARD (7.2X14.5X2-MM THK)	5		
31	6V-8918	BOLT (5/16-18X1.25-IN)	10		
32	8M-7758	RIVET-POP	8		
33	8T-4224	WASHER-HARD (8.8X16X2-MM THK)	16		
AVAILABLE REPAIR KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)	1		
(INCLUDES GASKETS)					

CAT codes: Y.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

9XZ-SEBP2922

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99