

CATERPILLAR G3516

E6R / SEBP6611


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Basic engine	
Air inlet and exhaust	
Frame, guards and enclosure	
Air inlet and exhaust	
Steering and brakes	

381-6877 ADAPTER GP-OIL LINE

381-6877 ADAPTER GP-OIL LINE S/N E6R1-UP FOR USE WITH RH MANUAL PRELUBRICATION PUMP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	7N-6570	ADAPTER AS	1		
	6T-7034	PIN-VALVE SPRING	1		
	3H-3433	PIN-SPRING	1		
	9H-2367	SPRING-VALVE	1		
	9L-0672	VALVE-CHECK	1		
2	0L-1351	BOLT (3/8-16X0.875-IN)	2		
3	5P-5846	SEAL-O-RING	1		

381-7040 ADAPTER GP-TURBOCHARGER OIL

381-7040 ADAPTER GP-TURBOCHARGER OIL S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	359-4123	ADAPTER (TURBOCHARGER OIL)	1		
2	0L-1143	BOLT (3/8-16X2.5-IN)	4		
3	6V-4368	SEAL-O-RING	2		
4	8T-6762	PLUG-PIPE (1/2-14-THD)	1		

384-9189 BREATHER GP -CRANKCASE

384-9189 BREATHER GP -CRANKCASE S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	1		
2	4W-3034	CLAMP-HOSE	1		
3	213-4518	COVER AS-VALVE MECHANISM	1		
4	272-0757	SEAL-VALVE COVER (BREATHER)	1		
5	033-6031	SEAL-O-RING	1		
6	1A-9579	BOLT (5/16-18X1.5-IN)	4		
7	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	4		

384-9208 BREATHER GP

384-9208 BREATHER GP S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	1L-4490	TUBE	2		
2	2W-0752	GASKET	2		
3	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	16		
4	5P-2230	CLAMP-HOSE	10		
5	7N-5337	HOSE-ELBOW	1		
6	7N-5339	HOSE-TEE	3		
7	9S-8752	NUT-FULL (3/8-16-THD)	8		
8	151-2617	ELBOW AS	2		
(EACH INCLUDES)					
	5H-9671	SHIELD	2		
9	154-3730	BREATHER AS (CRANKCASE)	4		
(EACH INCLUDES)					
	6H-6095	FILTER ELEMENT-BREATHER (CRANKCASE)	1		
	9M-9549	COVER AS	1		
	5S-6371	GASKET	1		


384-9208 BREATHER GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
10	191-3556	TUBE	1		
11	261-7958	GASKET	4		
12	05-1588	BOLT (3/8-16X1.25-IN)	8		

394-8097 BREATHER GP -CRANKCASE

394-8097 BREATHER GP -CRANKCASE S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	1		
2	4W-3034	CLAMP-HOSE	1		
3	033-6031	SEAL-O-RING	1		

394-8098 BREATHER GP -CRANKCASE

394-8098 BREATHER GP -CRANKCASE S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	2		
2	4W-3034	CLAMP-HOSE	2		
3	033-6031	SEAL-O-RING	2		

394-8099 BREATHER GP -CRANKCASE

394-8099 BREATHER GP -CRANKCASE S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	2		
2	4W-3034	CLAMP-HOSE	2		
3	033-6031	SEAL-O-RING	2		

379-2103 COVER GP-ENGINE OIL LINE

379-2103 COVER GP-ENGINE OIL LINE S/N E6R1-UP AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	0S-1594	BOLT (3/8-16X1-IN)	2		
2	4B-3140	COVER	1		
3	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	2		
4	5P-5846	SEAL-O-RING	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

E6R-SEBP6611

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99