

CATERPILLAR CX31

EBW / SEBP5074


Contents

Section	Page
Power train	2
Power train	
Cooling system	
Power train	
Power train	
Power train	
Cooling system	
Power train	

266-3683 DRIVE GP-PUMP -REAR

266-3683 DRIVE GP-PUMP -REAR S/N EBW1-UP PART OF 340-7042, 362-0712 TRANSMISSION AR-COMPLETE

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	266-3685	SHAFT AS	1		
2	096-5516	RING-RETAINING (EXTERNAL)	1		
3	2D-5658	BALL BEARING	1		
4	6V-5203	RING-RETAINING (INTERNAL)	1		

282-5927 DRIVE GP-PUMP -REAR PTO

282-5927 DRIVE GP-PUMP -REAR PTO S/N EBW1-UP PART OF 344-7154, 347-7162 TRANSMISSION AR-COMPLETE

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	391-2980	SHAFT AS	1		
2	096-5516	RING-RETAINING (EXTERNAL)	1		
3	2D-5658	BALL BEARING	1		
4	6V-5203	RING-RETAINING (INTERNAL)	1		

282-9537 PLANETARY GP-TRANSMISSION

282-9537 PLANETARY GP-TRANSMISSION S/N EBW1-999 PART OF 282-9536 TRANSMISSION AR-CORE

Drawing 1 of 4


REFER TO ALL ILLUSTRATIONS OF
THIS GROUP FOR AUXILIARY VIEWS



282-9537 PLANETARY GP-TRANSMISSION (continued)


Drawing 2 of 4

REFER TO ALL ILLUSTRATIONS OF
THIS GROUP FOR AUXILIARY VIEWS




282-9537 PLANETARY GP-TRANSMISSION (continued)

Drawing 3 of 4



282-9537 PLANETARY GP-TRANSMISSION (continued)

Drawing 4 of 4



REFER TO ALL ILLUSTRATIONS OF THIS GROUP FOR AUXILIARY VIEWS

Ref.	Part number	Description	Qty	Code	Group page
1	2S-0669	BEARING	12		
2	5M-6126	BEARING AS-ROLLER	4		
3	139-9313	BEARING-SPECIAL	4		
4	257-8660	BEARING-THRUST	1		
5	264-7794	BEARING-THRUST	2		
6	265-7969	CONE-TAPERED	1		

282-9537 PLANETARY GP-TRANSMISSION (continued)

Ref.	Part number	Description	Qty	Code	Group page
7	265-7970	CUP-TAPERED ROLLER	1		
8	269-6932	BEARING-THRUST	2		
9	2M-0849	WASHER-HARD (13.5X25.5X5-MM THK)	8		
10	3S-2708	PIN-SPRING	14		
11	4D-7889	RING	1		
12	6Y-5888	RING-SEAL	2		
13	7G-4822	RING-SEAL	4		
14	7T-5601	PLATE	1		
15	8E-8300	DISC-THRUST	12		
16	8E-8304	DISC-THRUST	8		
17	8E-8306	DISC-THRUST	8		
18	8E-8313	DISC-THRUST	1		
19	8S-3370	RING-SEAL	1		
20	8T-1178	BEARING-ROLLER	2		
21	9F-8477	RING-METAL SEAL	1		
22	9U-1741	RING-RETAINING	1		
23	134-8361	PLATE-CLUTCH	5		
24	140-9842	RING-LOCK	2		
25	140-9843	DISC-THRUST	1		
26	177-5241	RING-RETAINING	1		
27	177-5246	RING-SPACER	1		
28	177-6797	RING-SEAL	1		
29	189-2089	RING-LOCK	1		
30	222-5203	DISC-FRICTION	18		
31	223-7519	DISC-FRICTION	5		
32	261-4721	PLATE-CLUTCH	1		
33	261-4730	HUB AS	1		
	9W-0717	PLUG	6		
34	294-7963	GEAR-PLANETARY (18-TEETH)	6		
35	263-2821	GEAR-RING (69/68-TEETH)	1		
36	294-7968	GEAR-PLANETARY (24-TEETH)	4		
37	263-2838	HUB-CLUTCH	1		
38	263-2840	GEAR-RING (68-TEETH)	1		
39	294-7964	GEAR-SUN (24-TEETH)	1		
40	294-7965	GEAR-PLANETARY (22-TEETH)	4		
41	294-7966	SHAFT-CENTER	1		

282-9537 PLANETARY GP-TRANSMISSION (continued)

Ref.	Part number	Description	Qty	Code	Group page
42	263-2844	CARRIER-PLANETARY	1		
43	263-2846	CARRIER-BEARING	1		
44	263-2847	MANIFOLD AS	1		
	183-3407	PLUG AS	2		
(EACH INCLUDES)					
	9S-8004	PLUG (9/16-18-THD)	1		
	214-7568	SEAL-O-RING	1		
	277-0439	INSERT-THREADED	6		
45	264-4794	SPRING-WAVE	1		
46	264-4795	SPRING-WAVE	1		
47	264-4798	PISTON	1		
48	351-8893	PISTON-BALANCE	1		
49	264-4804	PLATE-CLUTCH	3		
50	264-4805	PLATE-CLUTCH	12		
51	264-7792	HUB	1		
52	264-7793	BEARING-NEEDLE	1		
53	350-8540	SPRING-WAVE	1		
54	294-7962	GEAR-SUN (27-TEETH)	1		
55	349-9156	HOUSING-SEAL	1		
56	265-7028	PLATE-CLUTCH	1		
57	266-3667	PISTON	2		
58	335-9139	PISTON	1		
59	266-3670	RING-SEAL	2		
60	266-3671	RING-SEAL	2		
61	266-3673	RING-SEAL	1		
62	266-3675	RING-SEAL	1		
63	317-4571	CASE AS-TRANSMISSION	1		
63A	1A-2223	DOWEL	4		
63B	3H-0703	DOWEL	2		
63C	9M-4355	DAMPER-BOLT	8		
63D	265-6991	INSERT-THREADED (M16X2-THD)	6	M	
63E	2H-1190	PIN-DOWEL	1		
64	350-3700	PISTON	1		
65	266-4193	RING-SEAL	2		
66	266-7072	SHAFT AS-PLANETARY	6		
(EACH INCLUDES)					

282-9537 PLANETARY GP-TRANSMISSION (continued)

Ref.	Part number	Description	Qty	Code	Group page
	2A-3746	PLUG-CUP	1		
67	266-7073	SHAFT AS-PLANETARY	4		
(EACH INCLUDES)					
	0T-0200	PLUG-CUP	1		
68	266-7074	SHAFT AS-PLANETARY	4		
(EACH INCLUDES)					
	0T-0200	PLUG-CUP	1		
69	266-7077	SPRING-WAVE	2		
70	335-9140	SPRING-WAVE	1		
71	272-3616	GASKET	1		
72	339-5397	SEAL-INTEGRAL	1		
73	273-5098	COUPLING	1		
74	353-0277	CARRIER-PLANETARY	1		
75	273-9146	SHAFT	1		
76	274-3961	BEARING AS-TAPERED ROLLER	1		
77	274-6110	BEARING-INNER (RACE)	1		
78	274-7437	SEAL-LIP TYPE	1		
79	275-3585	HOUSING	1		
80	275-5519	CARRIER AS	1		
	277-3456	BUSHING	1		
81	275-5737	RING-RETAINING	1		
82	275-5738	ROTOR-SENSOR (OUTPUT SPEED)	1		
83	277-6899	SHAFT AS	1		
	9W-0717	PLUG	3		
84	283-6363	PLATE-CLUTCH	6		
85	340-9914	SPRING	8		
86	340-9915	SPRING	4		
87	284-6012	PIN	8		
88	284-6013	PIN	4		
90	9X-4576	SEAL-O-RING	1		
91	183-3409	PLUG AS	3		
(EACH INCLUDES)					
	9S-8002	PLUG (7/16-20-THD)	1		
	033-5853	SEAL-O-RING	1		
92	1K-6984	RING-RETAINING	1		
93	346-8576	SEAL-O-RING	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

EBW-SEBP5074

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99