

CATERPILLAR 306E

FHL / SEBP6411


Contents

Section	Page
Basic engine	2
Lubrication system	
Cooling system	
Air inlet and exhaust	
Fuel system	
Basic engine	
Basic engine	
Electrical and electronics	
Power train	
Hydraulic system	
Power train	
Hydraulic system	
Hydraulic system	
Labels, kits and diagnostics	
Air inlet and exhaust	
Catalog items	

418-1662 CAMSHAFT GP

418-1662 CAMSHAFT GP PART OF 380-1782, 470-1078 ENGINE AR-PRIMARY

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	387-9830	TAPPET	8		
2	393-7576	BOLT-FLANGE HEAD	1		
3	418-1006	COVER-CAMSHAFT	1		
4	418-1007	PUSHROD	8		
5	418-1008	CAMSHAFT AS	1		
5A	388-7494	BEARING	1		
5B	418-1010	GEAR-CAM	1		
5C	383-0227	KEY-FEATHER	1		
5D	418-1012	STOPPER (CAMSHAFT)	1		
5E	418-1013	PIN	1		
6	418-1014	BOLT-FLANGE HEAD	4		
7	418-1015	SHAFT-IDLER GEAR	1		
8	418-1016	PIN-SPRING	2		


418-1662 CAMSHAFT GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
9	418-1018	COLLAR-CAMSHAFT	1		
10	418-1019	GEAR AS-IDLER	1		
10A	418-1020	BEARING	1		

418-0971 COVER GP-OIL PUMP

418-0971 COVER GP-OIL PUMP PART OF 418-1611 HOUSING GP-FRONT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	418-0972	SPRING	1		
2	388-7440	VALVE	1		
3	383-0291	GASKET	1		
4	389-5163	PLUG	1		
5	418-0973	ROTOR	1		
6	418-0974	ROTOR	1		
7	383-0358	CAP	1		
8	418-0975	COVER-OIL PUMP	1		
9	418-0976	SCREW-SPECIAL	6		
10	388-7445	PLUG	4		

418-0968 COVER GP-VALVE MECHANISM

418-0968 COVER GP-VALVE MECHANISM PART OF 418-1610 COVER GP-VALVE MECHANISM

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	383-0382	PIPE	1		
2	418-0969	COVER-BREATHER	1		
3	388-7490	SEAL-O-RING	1		
4	383-0203	SCREW	4		
5	388-7492	SEAL	4		
6	388-7488	ELEMENT (BREATHER)	3		

418-1610 COVER GP-VALVE MECHANISM

418-1610 COVER GP-VALVE MECHANISM PART OF 380-1782, 470-1078 ENGINE AR-PRIMARY

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	453-4160	TUBE-BREATHER	1		
2	383-0257	CLIP	1		
3	418-0966	CLAMP	1		
4	418-0967	BOLT-FLANGE HEAD	1		
5	418-0968	COVER GP-VALVE MECHANISM	1	Y	
6	418-0970	GASKET-VALVE	1		
7	383-0574	BOLT	10		

CAT codes: Y.

418-1614 CRANKSHAFT GP

418-1614 CRANKSHAFT GP PART OF 380-1782, 470-1078 ENGINE AR-PRIMARY

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	418-0989	CRANKSHAFT AS	1		
1A	388-7502	GEAR	1		
2	418-0990	GEAR AS (CRANKSHAFT)	1		
2A	418-0992	SLEEVE	1		
2B	383-0220	PIN	1		
2C	418-0993	SEAL	1		
3	387-9842	KEY (STRAIGHT)	1		
4	418-0994	BEARING (STANDARD)(MAIN)	5		
	418-0995	BEARING (0.20-MM US)		AB	
	418-0996	BEARING (0.40-MM US)		AB	
5	418-0997	BEARING-MAIN (STANDARD)(BOTTOM)	2		
	418-0998	BEARING-MAIN (0.20-MM OS)		AB	
	418-0999	BEARING-MAIN (0.40-MM OS)		AB	
6	418-1000	BEARING-MAIN (STANDARD)(TOP)	2		
	418-1001	BEARING-MAIN (0.20-MM OS)		AB	

418-1614 CRANKSHAFT GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
	418-1002	BEARING-MAIN (0.40-MM OS)		AB	
AVAILABLE REPAIR KIT(S):					
	418-1003	KIT-BEARING (STANDARD)	1		
	418-1004	KIT-BEARING (0.20-MM US, 0.20-MM OS)	1	AB	
	418-1005	KIT-BEARING (0.40-MM US, 0.40-MM OS)	1	AB	

CAT codes: A, B.

418-0927 CYLINDER BLOCK AS

418-0927 CYLINDER BLOCK AS PART OF 418-1603 CYLINDER BLOCK GP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	418-0929	BOLT	10		
2	387-9893	BOLT-FLANGE HEAD	16		
3	389-5106	PIN	2		
4	418-0930	CAP	6		
5	388-7434	CAP	4		
6	383-0262	CAP	2		
7	418-0931	CAP	2		
8	383-0303	PLUG	1		
9	383-0427	PLUG	1		

418-1603 CYLINDER BLOCK GP

418-1603 CYLINDER BLOCK GP PART OF 380-1782 ENGINE AR-PRIMARY

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	418-0927	CYLINDER BLOCK AS	1	Y	
2	389-5106	PIN	2		
3	387-9779	PIN	4		
4	383-0230	CAP	1		

CAT codes: Y.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

FHL-SEBP6411

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99