

CATERPILLAR 907M

H77 / SEBP7496


Contents

Section	Page
Basic engine	2
Lubrication system	
Cooling system	
Air inlet and exhaust	
Fuel system	
Basic engine	
Basic engine	
Electrical and electronics	
Power train	
Electrical and electronics	
Power train	
Hydraulic system	
Hydraulic system	
Labels, kits and diagnostics	
Air inlet and exhaust	
Catalog items	
Catalog items	

436-2823 CAMSHAFT GP

436-2823 CAMSHAFT GP PART OF 416-6088 ENGINE AR-PRIMARY Type 1 AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	387-9780	CUP-SEAL	1		
2	387-9785	BOLT-FLANGE HEAD	3		
3	387-9830	TAPPET	8		
4	387-9831	PUSHROD	8		
5	418-1063	BOLT-FLANGE HEAD	2		
6	436-1076	GEAR AS-IDLER	1		
6A	436-1078	BEARING	1		
7	436-1077	SHAFT-IDLER GEAR	1		
8	436-1079	COLLAR	1		
9	436-1080	COLLAR	1		
10	436-1919	CAMSHAFT AS	1		
10A	383-0227	KEY-FEATHER	1		
10B	388-7494	BEARING	1		
10C	388-7496	STOP	1		
10D	436-0857	GEAR-CAM	1		

436-2823 CAMSHAFT GP

436-2823 CAMSHAFT GP PART OF 416-6088 ENGINE AR-PRIMARY Type 2 AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	387-9780	CUP-SEAL	1		
2	387-9785	BOLT-FLANGE HEAD	3		
3	387-9830	TAPPET	8		
4	387-9831	PUSHROD	8		
5	418-1063	BOLT-FLANGE HEAD	2		
6	436-1076	GEAR AS-IDLER	1		
6A	436-1078	BEARING	1		
7	436-1077	SHAFT-IDLER GEAR	1		
8	436-1079	COLLAR	1		
9	436-1080	COLLAR	1		
10	473-5093	CAMSHAFT AS	1	C	
10A	383-0227	KEY-FEATHER	1		

436-2823 CAMSHAFT GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
10B	388-7494	BEARING	1		
10C	388-7496	STOP	1		
10D	473-5094	GEAR-CAMSHAFT	1		

CAT codes: C.

473-5086 COVER GP-VALVE MECHANISM

473-5086 COVER GP-VALVE MECHANISM PART OF 473-9251 COVER GP-VALVE MECHANISM AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	389-5153	ADAPTER	1		
2	388-7492	SEAL	4		
3	436-1103	SEAL-INJECTOR	4		
4	436-0814	CLAMP	1		
5	393-7502	BOLT-FLANGE HEAD	1		

473-9251 COVER GP-VALVE MECHANISM

473-9251 COVER GP-VALVE MECHANISM PART OF 416-6088 ENGINE AR-PRIMARY AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	473-5086	COVER GP-VALVE MECHANISM	1	Y	
2	383-0574	BOLT	10		
3	387-9829	GASKET	1		

CAT codes: Y.

387-9070 CRANKSHAFT GP

387-9070 CRANKSHAFT GP PART OF 416-6088 ENGINE AR-PRIMARY Type 1 AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	387-9840	CRANKSHAFT AS	1		
1A	388-7502	GEAR	1		
2	387-9841	GEAR AS-CRANKSHAFT	1		
2A	383-0220	PIN	1		
2B	388-7504	SLEEVE	1		
3	387-9842	KEY (STRAIGHT)	1		
4	393-2914	KIT-CRANKSHAFT BEARING (STANDARD)	5	J	
	393-2915	KIT-CRANKSHAFT BEARING (0.20-MM US)		ABL	
	393-2916	KIT-CRANKSHAFT BEARING (0.40-MM US)		ABN	
5	387-9846	BEARING (STANDARD)	2	J	
	393-2903	BEARING (0.20-MM OS)		ABL	
	393-2904	BEARING (0.40-MM OS)		ABN	
6	387-9845	BEARING (STANDARD)	2	J	
	393-2901	BEARING (0.20-MM OS)		ABL	
	393-2902	BEARING (0.40-MM OS)		ABN	

387-9070 CRANKSHAFT GP (continued)


Ref.	Part number	Description	Qty.	Code	Group page
AVAILABLE REPAIR KIT(S):					
	393-2911	KIT-BEARING (STANDARD)	1	J	
(INCLUDES BEARINGS)					
	393-2912	KIT-BEARING	1	L	
(INCLUDES BEARINGS)					
	393-2913	KIT-BEARING	1	N	
(INCLUDES BEARINGS)					

CAT codes: A, B, J, L, N.

387-9070 CRANKSHAFT GP

387-9070 CRANKSHAFT GP PART OF 416-6088 ENGINE AR-PRIMARY Type 2 AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	387-9840	CRANKSHAFT AS	1		
1A	388-7502	GEAR	1		
2	387-9841	GEAR AS-CRANKSHAFT	1		
2A	383-0220	PIN	1		
2B	388-7504	SLEEVE	1		
3	387-9842	KEY (STRAIGHT)	1		
4	393-2914	KIT-CRANKSHAFT BEARING (STANDARD)	5		
	393-2915	KIT-CRANKSHAFT BEARING (0.20-MM US)		AB	
	393-2916	KIT-CRANKSHAFT BEARING (0.40-MM US)		AB	
5	524-6737	BEARING	2	CJ	
	524-6738	BEARING (0.20-MM OS)		ABCL	
	524-6739	BEARING (0.40-MM OS)		ABCN	
6	524-6734	BEARING	2	CJ	
	524-6735	BEARING (0.20-MM OS)		ABCL	
	524-6736	BEARING (0.40-MM OS)		ABCN	

387-9070 CRANKSHAFT GP (continued)

Ref.	Part number	Description	Qty.	Code	Group page
AVAILABLE REPAIR KIT(S):					
	393-2911	KIT-BEARING (STANDARD)	1	J	
(INCLUDES BEARINGS)					
	393-2912	KIT-BEARING	1	L	
(INCLUDES BEARINGS)					
	393-2913	KIT-BEARING	1	N	
(INCLUDES BEARINGS)					

CAT codes: A, B, C, J, L, N.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

H77-SEBP7496

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99