

CATERPILLAR TH35-E81

MSB / SEBP4926


Contents

Section	Page
Air inlet and exhaust	2
Fuel system	
Power train	
Power train	
Frame, guards and enclosure	
Power train	
Basic engine	

157-6239 COVER GP-TORQUE CONVERTER

157-6239 COVER GP-TORQUE CONVERTER S/N MSB1-UP; TZM1-UP; PZT1-UP PART OF 251-1615 COVER GP-TORQUE CONVERTER

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	6V-5217	BOLT (M8X1.25X20-MM)	12	M	
2	299-3263	PLATE	1		
3	8T-0640	BOLT (M6X1X30-MM)	2	M	
4	9X-8267	WASHER (6.6X12X2-MM THK)	2		
5	157-2651	COVER AS	1		
6	6V-3822	BOLT (M10X1.5X35-MM)	8	M	
7	6V-5839	WASHER (11X21X2.5-MM THK)	8		
8	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	12		

CAT codes: M.

251-1615 COVER GP-TORQUE CONVERTER -WITH MANIFOLD

251-1615 COVER GP-TORQUE CONVERTER -WITH MANIFOLD S/N MSB1-UP; TZM1-UP; PZT1-UP PART OF 251-1623, 263-8314, 275-0801 TRANSMISSION AR-CORE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	1S-6119	SEAL-O-RING	1		
2	3S-2093	STRAP-CABLE	1		
3	6V-0852	CAP-DUST	2		
4	134-2252	SENSOR GP-TEMPERATURE (TRANSMISSION LUBRICATION OIL)	1	Y	
5	157-6239	COVER GP-TORQUE CONVERTER	1	Y	
6	165-9167	MANIFOLD	1		
7	183-7264	VALVE AS-FLUID SAMPLING (TRANSMISSION)	1		
8	230-3166	VALVE GP-RELIEF (TORQUE CONVERTER OUTLET)	1		
9	250-6026	BLOCK-HYDRAULIC	1		
10	130-5301	CLIP	1		
11	5P-8245	WASHER-HARD (13.5X25.5X3-MM THK)	4		
12	6F-0249	SEAL-O-RING	1		
13	6V-0484	ELBOW	1		
14	6V-3965	FITTING (QUICK DISCONNECT)	1		

251-1615 COVER GP-TORQUE CONVERTER -WITH MANIFOLD
(continued)


Ref.	Part number	Description	Qty	Code	Group page
15	6V-5049	SEAL-O-RING	4		
16	6V-8675	BOLT (M12X1.75X35-MM)	4	M	
17	8M-1112	SEAL-O-RING	1		
18	8M-4432	SEAL-O-RING	1		
19	8M-4986	SEAL-O-RING	1		

CAT codes: M, Y.

251-5861 DRIVE GP-PUMP

251-5861 DRIVE GP-PUMP S/N MSB1-UP; TZM1-UP; PZT1-UP PART OF 255-6433, 275-5345, 278-0970, 278-1320, 280-7737, 284-6054, 286-0453, 286-0454, 286-0455, 286-0456, 286-0458, 286-0459, 286-0460, 288-7893, 288-7894, 288-7895, 288-7896, 290-1614, 305-6687 TRANSMISSION AR-COMPLETE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	7K-5448	CUP-BEARING	4		
2	7K-5449	CONE-BEARING	4		
3	2K-2939	SEAL-O-RING	2		
4	7S-3036	RING-SEAL	2		
5	102-4232	BEARING AS-ROLLER	1		
6	135-0332	GEAR-IDLER (62-TEETH)	1		
7	135-0333	GEAR-PUMP DRIVE (51-TEETH)	2		
8	138-3114	ADAPTER-PUMP	2		
9	138-3116	SHAFT-IDLER	1		
10	140-7544	SHIM PACK (INCLUDES 12-SHIMS)	2	B	
11	4P-7429	CLIP	1		
12	6V-1820	BOLT (M10X1.5X30-MM)	16	M	

251-5861 DRIVE GP-PUMP (continued)


Ref.	Part number	Description	Qty	Code	Group page
13	6V-5839	WASHER (11X21X2.5-MM THK)	16		
14	8T-0207	BOLT (M16X2X100-MM)	1	M	
15	9X-8268	WASHER (17.5X30.0X3.5-MM THK)	1		

CAT codes: B, M.

233-7682 HOUSING GP-TORQUE CONVERTER

233-7682 HOUSING GP-TORQUE CONVERTER S/N MSB1-UP; PZT1-UP PART OF 251-1620 HOUSING GP-TORQUE CONVERTER

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	1A-2223	DOWEL	2		
2	4K-8603	PLUG-CUP	2		
3	9G-9506	PLUG	1		
4	207-5231	PIN	1		
5	1S-2199	DOWEL	4		
6	8T-5353	DOWEL	2		
7	205-9013	HOUSING	1		

251-1620 HOUSING GP-TORQUE CONVERTER


251-1620 HOUSING GP-TORQUE CONVERTER S/N MSB1-UP; PZT1-UP PART OF 251-1623 TRANSMISSION AR-CORE

Drawing 1 of 2



251-1620 HOUSING GP-TORQUE CONVERTER (continued)

Drawing 2 of 2



Ref.	Part number	Description	Qty	Code	Group page
1	2R-0098	SEAL-O-RING	1		
2	9G-5127	BREATHER (TRANSMISSION)	1		
3	129-1609	SEAL-O-RING	1		
4	140-2186	PLATE	1		
5	140-3133	PLATE-SEPARATOR	1		
6	140-9494	TUBE AS	1		

251-1620 HOUSING GP-TORQUE CONVERTER (continued)

Ref.	Part number	Description	Qty	Code	Group page
7	140-9855	TUBE AS	1		
8	164-5619	PLUG AS	1		
	2M-9780	SEAL-O-RING	1		
	9S-8006	PLUG-O-RING	1		
9	191-3519	BOLT-SPECIAL	4		
10	233-7682	HOUSING GP-TORQUE CONVERTER	1	Y	
11	256-4444	ADAPTER AS	1		
	3P-1823	ADAPTER-PIPE	1		
12	135-3198	SEAL-LIP TYPE	1		
13	148-8347	ELBOW AS	2		
(EACH INCLUDES)					
	3D-2824	SEAL-O-RING	1		
	6V-9007	ELBOW	1		
	6V-9746	SEAL-O-RING	1		
14	148-8406	PLUG AS	1		
	7M-8485	SEAL-O-RING	1		
	9S-9334	PLUG-O-RING	1		
15	162-0177	PLUG AS	1		
	3J-1907	SEAL-O-RING	1		
	9S-8004	PLUG-O-RING	1		
16	183-7262	PLUG AS	1		
	2S-4078	SEAL-O-RING	1		
	9S-8010	PLUG	1		
17	2H-3931	SEAL-O-RING	1		
18	2S-2251	SEAL-O-RING	1		
19	3H-1461	SEAL-O-RING	1		
20	5F-8000	SEAL-O-RING	1		
21	5H-2767	SEAL-O-RING	1		
22	5P-7213	WASHER-HARD (13.5X20.5X2-MM THK)	8		
23	5P-7530	SEAL-O-RING	1		
24	5P-8245	WASHER-HARD (13.5X25.5X3-MM THK)	4		
25	6F-6673	SEAL-O-RING	1		
26	6V-3668	BOLT (M12X1.75X30-MM)	4	M	
27	6V-4248	BOLT (M10X1.5X25-MM)	2	M	
28	6V-5839	WASHER (11X21X2.5-MM THK)	2		
29	7J-8611	ELBOW-PIPE	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

MSB-SEBP4926

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99