

CATERPILLAR 3508B

PTJ / SEBP3454


Contents

Section	Page
Basic engine	2
Air inlet and exhaust	5
Cooling system	
Air inlet and exhaust	
Electrical and electronics	
Basic engine	

115-2508 COVER GP-GENERATOR -TOP

115-2508 COVER GP-GENERATOR -TOP S/N 6ZZ1-UP PART OF 389-9269 AIR FILTER GP-GENERATOR FOR USE WITH 690-FRAME AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	5N-3176	PLUG-BUTTON	3		
2	8P-7065	PLUG-BUTTON	2		
3	030-2284	PLUG-BUTTON	4		
4	5N-3167	SEAL-RING	3		
5	6D-7128	SEAL-O-RING	4		
6	8T-9587	SEAL-O-RING	2		

141-4987 COVER GP-GENERATOR -COUPLING

141-4987 COVER GP-GENERATOR -COUPLING S/N 6ZZ1-UP PART OF 158-6433, 203-5749 GENERATOR GP FOR USE WITH 2-BEARING, 820-FRAME, 690-FRAME

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	1D-4540	BOLT (5/16-18X2.75-IN)	6		
2	7E-4475	TUBE-SPACER (8.3X11.9X50.8-MM THK)	6		
3	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		
4	128-0594	COVER-DRIP	1		

367-6825 COVER GP-GENERATOR -TOP

367-6825 COVER GP-GENERATOR -TOP S/N 6ZZ1-UP PART OF 361-2454 BOX GP-GENERATOR CONNECTION FOR USE WITH 690 FRAME AN ATTACHMENT


Drawing unavailable in the current source. The parts list is preserved below.

Ref.	Part number	Description	Qty	Code	Group page
1	030-2284	PLUG-BUTTON	4		
2	5N-3167	SEAL-RING	3		
3	5N-3176	PLUG-BUTTON	3		
4	6D-7128	SEAL-O-RING	4		
5	8P-7065	PLUG-BUTTON	2		
6	8T-9587	SEAL-O-RING	2		

121-5423 AIR FILTER GP-GENERATOR

121-5423 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP FOR USE WITH 820-FRAME SIZE AN ATTACHMENT

Drawing 1 of 1




LEFT SIDE VIEW

Ref.	Part number	Description	Qty	Code	Group page
1	128-1110	FRAME AS-FILTER	1		
2	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		
3	128-1114	SHIELD AS-FILTER	1		
4	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
5	1D-4541	BOLT (5/16-18X3-IN)	6		
6	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		
AVAILABLE REPAIR KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)	1		
(INCLUDES GASKETS)					

361-4913 AIR FILTER GP-GENERATOR

361-4913 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP FOR USE WITH 820-FRAME AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		
2	128-1114	SHIELD AS-FILTER	1		
3	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
4	155-2001	RETAINER	4		
5	308-9260	FASTENER-SPECIAL	4		
6	361-4914	FRAME AS-FILTER	1		
7	1D-4541	BOLT (5/16-18X3-IN)	6		
8	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	6		
AVAILABLE GASKET KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)			
(INCLUDES GASKETS)					

389-9268 AIR FILTER GP-GENERATOR

389-9268 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP FOR USE WITH 820-FRAME GENERATOR, 860-FRAME GENERATOR AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	65		
2	115-9550	BRACKET	1		
3	116-9991	COVER GP-EXTENSION BOX	1	Y	
4	123-0835	COVER-TOP	1		

389-9268 AIR FILTER GP-GENERATOR (continued)

Ref.	Part number	Description	Qty	Code	Group page
5	123-0837	PANEL AS	1		
6	128-1112	FILTER ELEMENT-AIR (GENERATOR)	1		
7	128-1114	SHIELD AS-FILTER	1		
8	128-1117	SWITCH AS-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	4P-8767	SWITCH-PRESSURE (AIR DIFFERENTIAL, GENERATOR)	1		
	6V-8185	NUT (1/4-20-THD)	8		
	7C-6121	MOUNT-FLEXIBLE	4		
	178-3339	SCREW (8-32X0.5-IN)	2		
9	128-7260	PANEL AS	1		
	4F-8711	PLUG-BUTTON	2		
	5P-0537	WASHER-HARD (7.2X14.5X2-MM THK)	8		
	5V-0770	BOLT-CARRIAGE (1/4-20X0.74-IN)	8		
	6V-8185	NUT (1/4-20-THD)	8		
10	141-4812	BRACKET-MOUNTING (RH)	1		
11	141-4813	BRACKET-MOUNTING (LH)	1		
12	155-2001	RETAINER	16		
13	357-3039	FRAME AS-BOX	1		
14	357-3041	FRAME GP-GENERATOR CONNECTION	1	Y	
15	357-3042	PANEL	2		
16	357-3044	PANEL-LOWER	1		
17	361-3326	PLATE	4		
18	361-4914	FRAME AS-FILTER	1		
19	381-9396	PANEL-BOTTOM	1		
20	384-5553	FASTENER-SPECIAL	16		
21	397-8931	PLUG-CAP	2		
22	0S-0509	BOLT (3/8-16X0.75-IN)	4		
23	0S-1594	BOLT (3/8-16X1-IN)	18		
24	0S-1616	BOLT (1/4-20X1-IN)	2		
25	2A-0762	BOLT (1/4-20X0.625-IN)	3		
26	4M-6424	BOLT (5/16-18X3-IN)	6		
27	4V-2027	PLUG-BUTTON	8		
28	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	22		
29	5P-0537	WASHER-HARD (7.2X14.5X2-MM THK)	5		
30	6V-8918	BOLT (5/16-18X1.25-IN)	10		
31	8M-7758	RIVET-POP	8		
32	8T-4224	WASHER-HARD (8.8X16X2-MM THK)	16		

389-9268 AIR FILTER GP-GENERATOR (continued)


Ref.	Part number	Description	Qty.	Code	Group page
AVAILABLE REPAIR KIT(S):					
	128-1116	KIT-GASKET (AIR FILTER)	1		
(INCLUDES GASKETS)					

CAT codes: Y.

389-9269 AIR FILTER GP-GENERATOR

389-9269 AIR FILTER GP-GENERATOR S/N 6ZZ1-UP FOR USE WITH 660/690 FRAME PETROLEUM GENERATORS AN ATTACHMENT

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	8T-0023	BOLT-HEAD LOCKING (5/16-18X1-IN)	65		
2	115-2508	COVER GP-GENERATOR	1	Y	
3	115-9550	BRACKET	1		
4	123-0835	COVER-TOP	1		

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

PTJ-SEBP3454

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99