

CATERPILLAR 3512C

PXX / SEBP6639


Contents

Section	Page
Lubrication system	2
Cooling system	
Air inlet and exhaust	
Fuel system	
Electrical and electronics	
Basic engine	
Basic engine	
Electrical and electronics	
Power train	
Frame, guards and enclosure	
Basic engine	

381-6877 ADAPTER GP-OIL LINE

381-6877 ADAPTER GP-OIL LINE FOR USE WITH RH MANUAL PRELUBRICATION PUMP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	7N-6570	ADAPTER AS	1		
	6T-7034	PIN-VALVE SPRING	1		
	3H-3433	PIN-SPRING	1		
	9H-2367	SPRING-VALVE	1		
	9L-0672	VALVE-CHECK	1		
2	0L-1351	BOLT (3/8-16X0.875-IN)	2		
3	5P-5846	SEAL-O-RING	1		

425-0831 ADAPTER GP-OIL LINE -PRELUBRICATION

425-0831 ADAPTER GP-OIL LINE -PRELUBRICATION FOR USE WITH RH MANUAL PRELUBRICATION PUMP AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty .	Code	Group page
1	7N-6570	ADAPTER AS	1		
	6T-7034	PIN-VALVE SPRING	1		
	3H-3433	PIN-SPRING	1		
	9H-2367	SPRING-VALVE	1		
	9L-0672	VALVE-CHECK	1		
2	0L-1351	BOLT (3/8-16X0.875-IN)	2		
3	7X-7731	PLUG-PIPE (3/4-14-THD)	1		

381-0521 ADAPTER GP-TURBOCHARGER OIL

381-0521 ADAPTER GP-TURBOCHARGER OIL AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	359-4123	ADAPTER (TURBOCHARGER OIL)(TURBOCHARGER OIL)	1		
2	0L-1143	BOLT (3/8-16X2.5-IN)	4		
3	6V-4368	SEAL-O-RING	2		
4	6V-4589	SEAL-O-RING	1		
5	8T-6762	PLUG-PIPE (1/2-14-THD)	1		
6	9S-4190	PLUG-O-RING (7/8-14-THD)	1		

432-1165 ADAPTER GP-TURBOCHARGER OIL

432-1165 ADAPTER GP-TURBOCHARGER OIL FOR USE WITH ENGINE WITH OIL TEMPERATURE SENSOR AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	359-4123	ADAPTER (TURBOCHARGER OIL)	1		
2	0L-1143	BOLT (3/8-16X2.5-IN)	4		
3	6V-4368	SEAL-O-RING	2		
4	6V-4589	SEAL-O-RING	1		
5	9S-4190	PLUG-O-RING (7/8-14-THD)	1		

380-8380 BREATHER GP -CRANKCASE

380-8380 BREATHER GP -CRANKCASE CHROME AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3034	CLAMP-HOSE	1		
2	033-6031	SEAL-O-RING	1		
3	126-0577	BREATHER AS (CHROME)(CRANKCASE)	1		
4	133-6265	WASHER (8.8X16X2-MM THK)	4		
5	155-2572	COVER AS	1		
6	272-0760	SEAL-VALVE COVER (BASE)	1		
7	133-6270	BOLT (5/16-18X1.5-IN)	4		

394-8126 BREATHER GP -CRANKCASE

394-8126 BREATHER GP -CRANKCASE AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	4		
2	4W-3034	CLAMP-HOSE	4		
3	217-6692	HOSE-TEE	2		
4	033-6031	SEAL-O-RING	4		
5	5P-0597	CLAMP-HOSE	4		

394-8127 BREATHER GP -CRANKCASE

394-8127 BREATHER GP -CRANKCASE AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	4W-3027	BREATHER AS (CRANKCASE)	4		
2	4W-3034	CLAMP-HOSE	4		
3	217-6692	HOSE-TEE	2		
4	033-6031	SEAL-O-RING	4		
5	5P-0597	CLAMP-HOSE	4		

387-0798 CONNECTION GP-OIL -EMERGENCY

387-0798 CONNECTION GP-OIL -EMERGENCY AN ATTACHMENT

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	7C-4716	SCREEN AS-SUCTION (ENGINE OIL PAN)	1		
2	7N-5796	ELBOW-CONNECTOR	1		
3	149-9297	ADAPTER	1		
4	0S-1571	BOLT (3/8-16X1.75-IN)	4		
5	0S-1591	BOLT (3/8-16X1.5-IN)	1		
6	0S-1614	BOLT (1/4-20X0.5-IN)	2		
7	109-2332	SEAL-O-RING	2		
8	5M-2894	WASHER-HARD (10.2X18.5X2.5-MM THK)	8		
9	5P-0537	WASHER-HARD (7.2X14.5X2-MM THK)	2		
10	5P-8872	SEAL-O-RING	1		
11	6V-0973	SEAL-O-RING	2		
12	7G-1239	SPACER (10.5X19X4.5-MM THK)	1		
13	7N-5798	FLANGE	2		

486-2768 CONNECTION GP-OIL -EMERGENCY

486-2768 CONNECTION GP-OIL -EMERGENCY AN ATTACHMENT

Drawing 1 of 2

REFER TO ALL ILLUSTRATIONS OF
THIS GROUP FOR AUXILIARY VIEWS



MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

PXX-SEBP6639

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99