

CATERPILLAR TH35-E81

PZT / SEBP4926


Contents

Section	Page
Power train	2
Power train	
Power train	
Power train	
Power train	
Power train	
Power train	
Basic engine	
Power train	

275-0802 GEAR GP-TRANSFER

275-0802 GEAR GP-TRANSFER S/N TZM1-UP; PZT1-UP PART OF 286-0458, 286-0459, 286-0460, 290-1614
TRANSMISSION AR-COMPLETE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4S-8598	SCREEN-SUCTION (TRANSFER GEAR)	1		
2	240-8259	SCREEN GP-MAGNETIC (TRANSFER GEAR)	1		
	8M-7160	MAGNET	3		
3	6Y-0809	COVER	1		
4	275-0815	DRIVE GP-TRANSFER	3	Y	
5	275-0818	GEAR GP-TRANSFER	1	Y	
6	275-0826	SHAFT	1		
7	275-0834	LINES GP-POWER TRAIN OIL (TRANSFER GEAR)	1	Y	
8	275-1022	FILTER & MTG GP-OIL (OUTPUT TRANSFER GEAR)	1	Y	
9	2M-0849	WASHER-HARD (13.5X25.5X5-MM THK)	23		
10	6V-3940	BOLT (M8X1.25X25-MM)	3	M	

275-0802 GEAR GP-TRANSFER (continued)


Ref.	Part number	Description	Qty	Code	Group page
11	8H-7521	SEAL-O-RING	1		
12	8T-0162	BOLT (M12X1.75X160-MM)	23	M	
13	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	3		

CAT codes: M, Y.

275-0818 GEAR GP-TRANSFER

275-0818 GEAR GP-TRANSFER S/N TzM1-UP; PZT1-UP PART OF 275-0802, 286-0450 GEAR GP-TRANSFER

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	9G-5127	BREATHER (TRANSFER GEAR)	1		
2	9S-7698	ELBOW-FLARED	3		
3	155-6647	CUP-BEARING	4		
4	176-0184	PLUG AS-DRAIN (MAGNETIC)	1		
	2S-4078	SEAL-O-RING	1		

275-0818 GEAR GP-TRANSFER (continued)

Ref.	Part number	Description	Qty	Code	Group page
	6V-0439	PLUG-MAGNETIC (DRAIN, POWER TRAIN OIL)	1		
5	240-3658	SHIM (2.65-MM THK)	1		
6	275-0797	TUBE AS	1		
7	275-0809	CASE AS	1		
	9G-9506	PLUG	7		
	9W-6068	PLUG	10		
8	275-0827	CAGE	2		
9	308-0742	MANIFOLD AS	1		
	9G-9506	PLUG	4		
10	280-3942	SHIM PACK (INCLUDES 11-SHIMS)(INCLUDES 11-SHIMS)	2	B	
11	283-0157	COVER	1		
12	283-0161	GEAR-TRANSFER (55-TEETH)(55-TEETH)	1		
13	283-0162	GEAR-TRANSFER (58-TEETH)(58-TEETH)	1		
14	283-0163	GEAR-TRANSFER (56-TEETH)(56-TEETH)	1		
15	286-4508	CAGE AS	1		
	9G-9506	PLUG	1		
16	295-4692	BLOCK	1		
17	297-7940	PLUG-ORIFICE	3		
18	148-8408	PLUG AS	3		
(EACH INCLUDES)					
	3D-2824	SEAL-O-RING	1		
	9S-4183	PLUG	1		
19	155-6648	CONE-BEARING	4		
20	1J-9671	SEAL-O-RING	10		
21	2K-2939	SEAL-O-RING	3		
22	2N-3253	CUP-BEARING	2		
23	2N-3254	CONE-BEARING	2		
24	4J-0520	SEAL-O-RING	1		
25	4J-5140	SEAL-O-RING	2		
26	4S-5971	COVER	1		
27	5P-8245	WASHER-HARD (13.5X25.5X3-MM THK)	24		
28	6V-4248	BOLT (M10X1.5X25-MM)	25	M	
29	6V-4429	BOLT (M16X2X40-MM)	10	M	
30	6V-5218	BOLT (M8X1.25X35-MM)	4	M	
31	6V-5219	BOLT (M8X1.25X40-MM)	8	M	
32	6V-5684	BOLT (M12X1.75X45-MM)	24	M	

275-0818 GEAR GP-TRANSFER (continued)


Ref.	Part number	Description	Qty	Code	Group page
33	6V-5839	WASHER (11X21X2.5-MM THK)	25		
34	7F-8268	SEAL-O-RING	1		
35	8B-4967	SEAL-O-RING	2		
36	8T-0639	BOLT (M6X1X12-MM)	4	M	
37	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	12		
38	9X-8267	WASHER (6.6X12X2-MM THK)	4		
39	9X-8268	WASHER (17.5X30X3.5-MM THK)	10		
40	1U-8846	SEALANT-GASKET		B	
41	8M-8659	DOWEL	2		

CAT codes: B, M.

286-0450 GEAR GP-TRANSFER

286-0450 GEAR GP-TRANSFER S/N TZM1-UP; PZT1-UP PART OF 286-0453, 286-0454, 286-0455, 286-0456
TRANSMISSION AR-COMLETE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	3K-0360	SEAL-O-RING	1		
2	4S-8598	SCREEN-SUCTION (TRANSFER GEAR)	1		
3	240-8259	SCREEN GP-MAGNETIC (TRANSFER GEAR)	1		
	8M-7160	MAGNET	3		
4	6Y-0809	COVER	1		
5	275-0815	DRIVE GP-TRANSFER	2	Y	
6	275-0818	GEAR GP-TRANSFER	1	Y	
7	275-1021	SHAFT	1		
8	275-1022	FILTER & MTG GP-OIL (OUTPUT TRANSFER GEAR)	1	Y	
9	280-3947	COVER GP-ACCESS (TRANSFER GEAR)	1	Y	
10	280-3949	LINES GP-POWER TRAIN OIL (TRANSFER GEAR)	1	Y	
11	2M-0849	WASHER-HARD (13.5X25.5X5-MM THK)	23		
12	6V-3940	BOLT (M8X1.25X25-MM)	3	M	
13	8H-7521	SEAL-O-RING	1		

286-0450 GEAR GP-TRANSFER (continued)


Ref.	Part number	Description	Qty	Code	Group page
14	8T-0162	BOLT (M12X1.75X160-MM)	23	M	
15	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	3		
16	9S-4185	PLUG-O-RING	1		

CAT codes: M, Y.

227-8965 PLANETARY GP-TRANSMISSION

227-8965 PLANETARY GP-TRANSMISSION S/N MSB1-UP; TZM1-UP; PZT1-UP PART OF 251-1623, 263-8314
TRANSMISSION AR-CORE


Drawing 1 of 4



REFER TO ALL ILLUSTRATIONS OF
THIS GROUP FOR AUXILIARY VIEWS

227-8965 PLANETARY GP-TRANSMISSION (continued)

Drawing 2 of 4



MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

PZT-SEBP4926

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99