

CATERPILLAR CX31

S4H / SEBP5959


Contents

Section	Page
Basic engine	2
Lubrication system	
Power train	
Power train	
Fuel system	
Power train	
Power train	

262-7071 COUPLING GP-TORSIONAL -TORQUE CONVERTER

262-7071 COUPLING GP-TORSIONAL -TORQUE CONVERTER S/N T9G1-UP; S4H1-UP; S7H1-UP; T1P1-UP; T5P1-UP; T8S1-UP PART OF 288-2663, 366-9004, 366-9006, 376-7525 TORQUE CONVERTER GP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	247-0866	SPRING	12		
2	247-0867	SPRING	6		
3	247-0868	SPRING	6		
4	1A-2029	BOLT (3/8-16X1.125-IN)	12		
5	9S-8752	NUT-FULL (3/8-16-THD)	12		

418-7982 HOUSING GP-TORQUE CONVERTER

418-7982 HOUSING GP-TORQUE CONVERTER S/N D9F1394-UP; S4H1-UP PART OF 361-4012 TRANSMISSION AR-CORE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	1B-6161	LOCK	1		
2	2P-8986	CUP-BEARING	1		
3	2P-8987	CONE-BEARING	1		
4	4H-6112	BREATHER (TORQUE CONVERTER)	1		

418-7982 HOUSING GP-TORQUE CONVERTER (continued)


Ref.	Part number	Description	Qty	Code	Group page
5	4H-7859	LOCKNUT-BEARING	1		
6	5P-8245	WASHER-HARD (13.5X25.5X3-MM THK)	20		
7	6V-3551	SEAL-O-RING	1		
8	6V-5839	WASHER (11X21X2.5-MM THK)	1		
9	416-6337	BEARING	2		
10	416-6338	BEARING-CUP	2		
11	7L-9061	SEAL-O-RING	2		
12	8H-7801	CONE-BEARING	1		
13	8H-7803	CUP-BEARING	1		
14	9M-1974	WASHER-HARD (8.8X16X2-MM THK)	2		
15	136-3378	SEAL-O-RING	1		
16	265-5834	MANIFOLD	1		
17	265-5840	GEAR (70-TEETH)	1		
18	274-4252	RING-RETAINING	1		
19	274-4254	RING-SEAL	1		
20	274-6111	RACE-BEARING	1		
21	419-0034	CARRIER AS	1		
	1A-2223	DOWEL	1		
22	380-2810	SHIELD AS	1		
23	295-8261	GEAR (55-TEETH)	1		
24	338-0891	PLATE-INFORMATION (TRANSMISSION)	1		
25	363-2112	SEAL-LIP TYPE	1		
26	366-0683	MANIFOLD	1		
27	371-0886	HOUSING AS-TORQUE CONVERTER	1		
	5M-7937	DOWEL	2		
	265-6991	INSERT-THREADED (M16X2-THD)	10	M	
	266-4188	INSERT-THREADED (M8X1.25-THD)	12	M	
28	172-9966	BOLT (M12X1.75X65-MM)	13	M	
29	5P-8347	BOLT (M8X1.25X70-MM)	2	M	
30	6V-5684	BOLT (M12X1.75X45-MM)	7	M	
31	6V-5843	BOLT (M10X1.5X45-MM)	1	M	
32	8T-4184	BOLT (M12X1.75X45-MM)	10	M	
33	8T-4194	BOLT (M12X1.75X50-MM)	3	M	
34	8T-4223	WASHER-HARD (13.5X25.5X3-MM THK)	10		

CAT codes: M.

288-2663 TORQUE CONVERTER GP

288-2663 TORQUE CONVERTER GP S/N T9G1-UP PART OF 361-3860, 361-3861, 361-3862, 361-3863 TRANSMISSION
AR-COMplete


Drawing 1 of 2



288-2663 TORQUE CONVERTER GP (continued)

Drawing 2 of 2

REFER TO ALL ILLUSTRATIONS OF
THIS GROUP FOR AUXILIARY VIEWS



Ref.	Part number	Description	Qty	Code	Group page
1	1T-0655	BEARING-THRUST	2		
2	1T-1078	BEARING-THRUST	2		
3	1T-0657	PLATE	2		
4	1T-0679	ROLLER-FREEWHEEL	11		
5	1T-0680	SPRING-FREEWHEEL	11		
6	1T-0686	RACE-THRUST BEARING	3		

288-2663 TORQUE CONVERTER GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
7	1T-0762	RACE-THRUST BEARING	1		
8	7S-7018	RING-SEAL METAL	1		
9	8B-7789	RING-SNAP	3		
10	260-3738	BOLT-SOCKET HEAD (M20X2.5X45-MM)	1	M	
11	260-9530	HUB-IMPELLER	1		
12	293-5988	CARRIER-STATOR	1		
13	260-9533	PISTON	1		
15	284-3602	TURBINE	1		
16	390-9741	HUB	1		
17	260-9554	PLATE-SPLINED	1		
18	260-9555	PLATE-BACKING	1		
19	260-9557	PLATE	2		
20	262-7071	COUPLING GP-TORSIONAL (TORQUE CONVERTER)	1	Y	
21	297-6404	IMPELLER-CONVERTER	1		
22	269-9158	SEAL-O-RING	3		
23	271-2456	STATOR-CONVERTER	1		
24	272-7959	ADAPTER-DRIVE	1		
25	275-5308	DISC-FRICTION	2		
26	384-1847	HOUSING AS-CLUTCH	1		
26A	1T-0577	BUSHING	1		
27	095-0670	BOLT (M12X1.75X45-MM)	8	M	
30	154-1581	RING-RETAINING	1		
31	1S-6477	RING-SEAL	1		
32	390-9762	RETAINER	1		
33	284-3599	CAM-FREEWHEEL	1		
34	3S-1284	RING-SEAL	1		
35	5P-7213	WASHER-HARD (13.5X20.5X2-MM THK)	8		
36	6V-1902	SEAL-O-RING	1		
37	6V-4249	BOLT (M10X1.5X50-MM)	20	M	
39	6V-5839	WASHER (11X21X2.5-MM THK)	24		
40	6V-7981	BOLT (M10X1.5X70-MM)	24	M	
41	7B-0472	DOWEL	2		
42	7L-3386	SEAL-O-RING	1		
44	9S-8010	PLUG	1		

CAT codes: M, Y.

366-9004 TORQUE CONVERTER GP

366-9004 TORQUE CONVERTER GP S/N S4H1-UP; T1P1-UP PART OF 443-5672, 443-5673, 443-5674, 443-5675, 493-4269, 493-4270, 493-4271, 493-4272 TRANSMISSION AR-COMplete

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	1T-0655	BEARING-THRUST	2		
2	1T-1078	BEARING-THRUST	2		
3	1T-0657	PLATE	2		
4	1T-0679	ROLLER-FREEWHEEL	11		

366-9004 TORQUE CONVERTER GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
5	1T-0680	SPRING-FREEWHEEL	11		
6	1T-0686	RACE-THRUST BEARING	3		
7	1T-0762	RACE-THRUST BEARING	1		
8	7S-7018	RING-SEAL METAL	1	C	
9	8B-7789	RING-SNAP	3		
10	260-3738	BOLT-SOCKET HEAD (M20X2.5X45-MM)	1	M	
11	260-9530	HUB-IMPELLER	1		
13	390-9741	HUB	1	C	
14	260-9554	PLATE-SPLINED	1		
15	260-9555	PLATE-BACKING	1		
16	260-9557	PLATE	1		
17	262-7071	COUPLING GP-TORSIONAL (TORQUE CONVERTER)	1	Y	
18	268-0169	TURBINE-CONVERTER	1		
19	268-8128	STATOR-CONVERTER	1		
20	269-9158	SEAL-O-RING	3		
21	272-7959	ADAPTER-DRIVE	1		
22	275-5308	DISC-FRICTION	1		
23	284-3599	CAM-FREEWHEEL	1		
24	364-5467	HOUSING AS-CLUTCH	1	C	
24A	1T-0577	BUSHING	1		
25	293-5988	CARRIER-STATOR	1		
26	297-6403	IMPELLER	1		
27	095-0670	BOLT (M12X1.75X45-MM)	8	M	
30	154-1581	RING-RETAINING	1		
31	1S-6515	RING-SEAL	1		
32	390-9762	RETAINER	1	C	
33	283-0015	PISTON	1		
34	2S-1362	RING-SEAL	1		
35	5P-7213	WASHER-HARD (13.5X20.5X2-MM THK)	8		
36	6V-1902	SEAL-O-RING	1		
37	6V-4249	BOLT (M10X1.5X50-MM)	20	M	
39	6V-5839	WASHER (11X21X2.5-MM THK)	24		
40	6V-7981	BOLT (M10X1.5X70-MM)	24	M	

366-9004 TORQUE CONVERTER GP (continued)

Ref.	Part number	Description	Qty	Code	Group page
41	7B-0472	DOWEL	2		
42	7L-3386	SEAL-O-RING	1		
44	9S-8010	PLUG	1		

CAT codes: C, M, Y.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

S4H-SEBP5959

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99