

# CATERPILLAR TH580B

SLH / SEBP3572


## Contents

| Section                      | Page |
|------------------------------|------|
| Basic engine                 | 2    |
| Lubrication system           |      |
| Cooling system               |      |
| Air inlet and exhaust        |      |
| Fuel system                  |      |
| Basic engine                 |      |
| Basic engine                 |      |
| Electrical and electronics   |      |
| Power train                  |      |
| Basic engine                 |      |
| Power train                  |      |
| Hydraulic system             |      |
| Hydraulic system             |      |
| Labels, kits and diagnostics |      |
| Catalog items                |      |
| Air inlet and exhaust        |      |
| Catalog items                |      |

196-7056 BELT GP-SERPENTINE

196-7056 BELT GP-SERPENTINE S/N SLH1-619 PART OF 210-4831 ENGINE & TRANSMISSION AR AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description     | Qty | Code | Group page |
|------|-------------|-----------------|-----|------|------------|
| 1    | 8P-6363     | PLUG            | 1   |      |            |
| 2    | 190-8142    | BELT-SERPENTINE | 1   |      |            |
| 3    | 5P-9212     | PLUG            | 1   |      |            |

236-3841 BELT GP-SERPENTINE

236-3841 BELT GP-SERPENTINE S/N SLH1-UP PART OF 210-4831, 222-7751 ENGINE & TRANSMISSION AR AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description     | Qty | Code | Group page |
|------|-------------|-----------------|-----|------|------------|
| 1    | 8P-6363     | PLUG            | 1   |      |            |
| 2    | 236-3842    | BELT-SERPENTINE | 1   |      |            |
| 3    | 5P-9212     | PLUG            | 1   |      |            |

183-3780 BELT TENSIONER GP

183-3780 BELT TENSIONER GP S/N SLH1-UP PART OF 207-7247, 207-7249, 271-0933, 271-0945 INSTALLATION  
AR-ENGINE AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description                    | Qty | Code | Group page |
|------|-------------|--------------------------------|-----|------|------------|
| 1    | 171-6108    | PULLEY (8-GROOVE)              | 1   |      |            |
| 2    | 190-0642    | BELT TENSIONER                 | 1   |      |            |
| 3    | 8T-4121     | WASHER-HARD (11X21X2.5-MM THK) | 1   |      |            |
| 4    | 8T-4172     | BOLT (M10X1.5X80-MM)           | 1   | M    |            |
| 5    | 8T-4189     | BOLT (M8X1.25X20-MM)           | 4   | M    |            |
| 6    | 8T-4224     | WASHER-HARD (8.8X16X2-MM THK)  | 4   |      |            |

CAT codes: M.

234-2674 CAMSHAFT GP

234-2674 CAMSHAFT GP S/N CRX107-UP PART OF 176-3180, 194-9477 ENGINE AR-PRIMARY AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description  | Qty | Code | Group page |
|------|-------------|--------------|-----|------|------------|
| 1    | 350-1846    | CAMSHAFT AS  | 1   |      |            |
| 1A   | 1B-8736     | KEY-WOODRUFF | 1   |      |            |

446-9163 COVER GP-CYLINDER HEAD

446-9163 COVER GP-CYLINDER HEAD S/N CRX5120-UP PART OF 239-5602 COVER GP-VALVE MECHANISM AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description                | Qty | Code | Group page |
|------|-------------|----------------------------|-----|------|------------|
| 1    | 225-6451    | GASKET (VALVE COVER)       | 1   |      |            |
| 2    | 225-6478    | SCREW-MACHINE              | 4   |      |            |
| 3    | 431-1704    | PLATE                      | 1   |      |            |
| 4    | 136-3608    | CAP AS (ENGINE OIL FILLER) | 1   |      |            |
| 4A   | 124-0506    | SEAL                       | 1   |      |            |
| 5    | 349-2746    | BOLT                       | 10  |      |            |
| 6    | 292-9008    | SEAL                       | 1   |      |            |

230-9196 COVER GP-FRONT HOUSING

230-9196 COVER GP-FRONT HOUSING S/N CRX5120-UP PART OF 176-3180, 194-9477 ENGINE AR-PRIMARY AN ATTACHMENT

Drawing 1 of 1




| Ref. | Part number | Description               | Qty | Code | Group page |
|------|-------------|---------------------------|-----|------|------------|
| 1    | 100-4830    | BOLT (M10X1.5X20-MM)      | 1   | M    |            |
| 2    | 111-8222    | BOLT (M8X1.25X16-MM)      | 5   | M    |            |
| 3    | 209-5502    | COVER AS (POWER TAKE-OFF) | 1   |      |            |
| 3A   | 209-5503    | SEAL-COVER                | 1   |      |            |
| 4    | 6I-0646     | BOLT (M10X1.5X14-MM)      | 1   | M    |            |
| 5    | 214-3203    | WASHER (SEALING)          | 1   |      |            |

CAT codes: M.

230-9150 COVER GP-VALVE MECHANISM

230-9150 COVER GP-VALVE MECHANISM S/N CRX107-5119 PART OF 176-3180, 194-9477 ENGINE AR-PRIMARY AN ATTACHMENT

Drawing 1 of 1



| Ref. | Part number | Description                              | Qty | Code | Group page |
|------|-------------|------------------------------------------|-----|------|------------|
| 1    | 5D-1026     | CLAMP-BAND                               | 1   |      |            |
| 2    | 6I-0846     | BOLT (M6X1X14-MM)                        | 3   | M    |            |
| 3    | 7C-1281     | BRACKET                                  | 1   |      |            |
| 4    | 162-1565    | SPRING (CRANKCASE BREATHER HOSE)         | 1   |      |            |
| 5    | 198-9169    | HOSE ((BREATHER) (CRANKCASE))            | 1   |      |            |
| 6    | 225-6481    | COVER AS-VALVE                           | 1   |      |            |
| 7    | 136-3608    | CAP AS (ENGINE OIL FILLER)               | 1   |      |            |
| 8    | 124-0506    | SEAL                                     | 1   |      |            |
| 9    | 225-6451    | GASKET (VALVE COVER)                     | 1   |      |            |
| 10   | 225-6455    | BOLT                                     | 10  |      |            |
| 11   | 225-6456    | SPRING                                   | 1   |      |            |
| 12   | 225-6461    | CAP                                      | 1   |      |            |
| 13   | 225-6464    | DIAPHRAGM (CRANKCASE PRESSURE CONTACTOR) | 1   |      |            |
| 14   | 225-6477    | PLATE                                    | 1   |      |            |

230-9150 COVER GP-VALVE MECHANISM (continued)


| Ref. | Part number | Description   | Qty | Code | Group page |
|------|-------------|---------------|-----|------|------------|
| 15   | 225-6478    | SCREW-MACHINE | 4   |      |            |
| 16   | 225-6479    | CAP           | 1   |      |            |
| 17   | 225-6522    | PLUG-CUP      | 1   |      |            |
| 18   | 225-6524    | PLUG-CUP      | 1   |      |            |
| 19   | 230-9127    | COVER         | 1   |      |            |
| 20   | 230-9144    | CONNECTOR     | 1   |      |            |
| 21   | 150-7732    | SEAL-O-RING   | 1   |      |            |
| 22   | 225-6455    | BOLT          | 2   |      |            |
| 23   | 225-6517    | GASKET        | 1   |      |            |

CAT codes: M.

239-5602 COVER GP-VALVE MECHANISM

239-5602 COVER GP-VALVE MECHANISM S/N CRX5120-UP PART OF 176-3180, 194-9477 ENGINE AR-PRIMARY Type 1  
AN ATTACHMENT

Drawing 1 of 1



| Ref. | Part number | Description                              | Qty | Code | Group page |
|------|-------------|------------------------------------------|-----|------|------------|
| 1    | 5D-1026     | CLAMP-BAND                               | 1   |      |            |
| 2    | 6I-0846     | BOLT (M6X1X14-MM)                        | 3   | M    |            |
| 3    | 7C-1281     | BRACKET                                  | 1   |      |            |
| 4    | 162-1565    | SPRING (CRANKCASE BREATHER HOSE)         | 1   |      |            |
| 5    | 198-9169    | HOSE (CRANKCASE BREATHER)                | 1   |      |            |
| 6    | 247-7799    | COVER AS-VALVE                           | 1   |      |            |
| 6A   | 136-3608    | CAP AS (ENGINE OIL FILLER)               | 1   |      |            |
| 6B   | 124-0506    | SEAL                                     | 1   |      |            |
| 6C   | 225-6451    | GASKET (VALVE COVER)                     | 1   |      |            |
| 6D   | 225-6455    | BOLT (ISOLATOR)                          | 10  |      |            |
| 6E   | 225-6456    | SPRING                                   | 1   |      |            |
| 6F   | 225-6461    | CAP                                      | 1   |      |            |
| 6G   | 225-6464    | DIAPHRAGM (CRANKCASE PRESSURE CONTACTOR) | 1   |      |            |
| 6H   | 225-6477    | PLATE                                    | 1   |      |            |

**MANUALS-KOMATSU.COM**

## **Complete Caterpillar PDF Parts Catalogue**

SLH-SEBP3572

**\$99**

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

**Buy complete PDF - \$99**