

CATERPILLAR 140K 2

SZW / SEBP6016


Contents

Section	Page
Basic engine	2
Lubrication system	
Cooling system	
Air inlet and exhaust	
Fuel system	
Basic engine	
Hydraulic system	
Electrical and electronics	
Power train	
Cooling system	
Air inlet and exhaust	
Hydraulic system	
Hydraulic system	
Air inlet and exhaust	
Hydraulic system	
Air inlet and exhaust	

149-4915 AIR COMPRESSOR GP

149-4915 AIR COMPRESSOR GP S/N TX71-UP; KHX27197-UP PART OF 389-9576 AIR COMPRESSOR GP

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	2P-4358	FLANGE	1		
2	6D-1004	GASKET	1		
3	8T-6757	PLUG-PIPE	1		
4	141-1546	PLUG-PIPE	1		
5	4P-3977	GASKET-CYLINDER HEAD	1		
6	7E-8928	GASKET	1		
7	6V-1820	BOLT (M10X1.5X30-MM)	2	M	
8	6V-5839	WASHER (11X21X2.5-MM THK)	2		
9	4P-3966	PISTON & ROD AS	1		
10	128-7759	ADAPTER AS	1		
	128-7761	BOLT	3		

AVAILABLE REPAIR KIT(S):

7E-8923	KIT-CRANKSHAFT BEARING (AIR COMPRESSOR)	1
---------	---	---

(INCLUDES FRONT COVER SEAL, FRONT MAIN & REAR BEARINGS, FRONT & REAR WASHERS, BEARING INSERTS, SLOTTED INSERTS, O-RING SEAL, CYLINDER HEAD & BASE GASKETS)

149-4915 AIR COMPRESSOR GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
	164-7572	KIT-RING (AIR COMPRESSOR)	1		
(INCLUDES PISTON RINGS & SPACERS)					
	7E-8926	KIT-CYLINDER HEAD (AIR COMPRESSOR)	1		
(INCLUDES UNLOADER PISTONS, UNLOADER SPRINGS, UNLOADER O-RING, UNLOADER GASKET, INLET VALVES, INLET VALVE STOPS, INLET VALVE SEATS, INLET SPRINGS, INLET GASKETS, DISCHARGE VALVES, DISCHARGE VALVE SEATS, DISCHARGE VALVE SPRINGS, DISCHARGE GASKET, GOVERNOR GASKET, STRAINER GASKET, & CYLINDER HEAD GASKET)					

CAT codes: M.

360-2196 AIR COMPRESSOR GP

360-2196 AIR COMPRESSOR GP S/N TX71-3450; KHX27197-UP PART OF 312-0255, 395-0484 ENGINE AR-COMPLETE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4P-5106	BRACKET	1		
3	8Y-1816	SPACER (12.5X25X25-MM THK)	1		
4	124-5572	VALVE AS-RELIEF (AIR COMPRESSOR)	1		
5	135-9819	SEAL-INTEGRAL	1		
6	389-9576	AIR COMPRESSOR GP	1	Y	

360-2196 AIR COMPRESSOR GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
7	8T-6868	BOLT (M12X1.75X80-MM)	2	M	
8	202-2762	CLIP (LOOP)	2		
9	389-3737	ELBOW AS	1		
	2T-1922	ELBOW	1		
	228-7090	SEAL-O-RING	1		
10	341-8667	HOSE AS	1	I	
11	341-8841	TUBE AS	1		
12	360-2197	TUBE AS	1		
13	319-6225	ELBOW AS	1		
	228-7090	SEAL-O-RING	1		
	238-5080	SEAL-O-RING	1		
	6V-8625	ELBOW	1		
14	335-3982	ELBOW AS	1		
	214-7568	SEAL-O-RING	1		
	228-7088	SEAL-O-RING	1		
	6V-8627	ELBOW	1		
15	353-5097	ELBOW AS	1		
	228-7090	SEAL-O-RING	1		
	238-5082	SEAL-O-RING	1		
	127-1647	ELBOW	1		
16	330-9763	CONNECTOR AS	1		
	228-7090	SEAL-O-RING	1		
	8C-6872	CONNECTOR	1		
17	2N-1287	ELBOW-FLARED	1		
18	3J-5389	PLUG (EXTERNAL)	1		
19	5L-5502	FITTING	1		
22	8T-4121	WASHER-HARD (11X21X2.5-MM THK)	5		
23	6V-4248	BOLT (M10X1.5X25-MM)	2	M	
24	8T-6466	BOLT (M10X1.5X60-MM)	1	M	
25	8T-4195	BOLT (M10X1.5X30-MM)	2	M	
26	8T-4223	WASHER-HARD (13.5X25.5X3-MM THK)	2		

CAT codes: I, M, Y.

360-2196 AIR COMPRESSOR GP

360-2196 AIR COMPRESSOR GP S/N TX71-UP PART OF 395-0484, 511-5381, 539-8083 ENGINE AR-COMPLETE

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	4P-5106	BRACKET	1		
2	112-6032	SPACER (10.5X22X8-MM THK)	1	C	
3	6B-6205	SPACER (0.438X0.875X1.281-IN THK)	1	C	
4	124-5572	VALVE AS-RELIEF (AIR COMPRESSOR)	1		
5	135-9819	SEAL-INTEGRAL	1		

360-2196 AIR COMPRESSOR GP (continued)


Ref.	Part number	Description	Qty	Code	Group page
6	389-9576	AIR COMPRESSOR GP	1	Y	
7	8T-6868	BOLT (M12X1.75X80-MM)	2	M	
8	202-2762	CLIP (LOOP)	2		
9	389-3737	ELBOW AS	1		
	2T-1922	ELBOW	1		
	228-7090	SEAL-O-RING	1		
10	341-8667	HOSE AS	1	I	
11	485-7243	TUBE AS	1	C	
12	485-7242	TUBE AS	1	C	
13	319-6225	ELBOW AS	1		
	228-7090	SEAL-O-RING	1		
	238-5080	SEAL-O-RING	1		
	6V-8625	ELBOW	1		
14	335-3982	ELBOW AS	1		
	214-7568	SEAL-O-RING	1		
	228-7088	SEAL-O-RING	1		
	6V-8627	ELBOW	1		
15	353-5097	ELBOW AS	1		
	228-7090	SEAL-O-RING	1		
	238-5082	SEAL-O-RING	1		
	127-1647	ELBOW	1		
16	330-9763	CONNECTOR AS	1		
	228-7090	SEAL-O-RING	1		
	8C-6872	CONNECTOR	1		
17	2N-1287	ELBOW-FLARED	1		
18	3J-5389	PLUG (EXTERNAL)	1		
19	5L-5502	FITTING	1		
22	8T-4121	WASHER-HARD (11X21X2.5-MM THK)	5		
23	6V-4248	BOLT (M10X1.5X25-MM)	2	M	
24	8T-5005	BOLT (M10X1.5X70-MM)	1	CM	
25	8T-4195	BOLT (M10X1.5X30-MM)	2	M	
26	8T-4223	WASHER-HARD (13.5X25.5X3-MM THK)	2		

CAT codes: C, I, M, Y.

389-9576 AIR COMPRESSOR GP

389-9576 AIR COMPRESSOR GP S/N TX71-UP; KHX27197-UP PART OF 360-2196 AIR COMPRESSOR GP

Drawing 1 of 1




Ref.	Part number	Description	Qty	Code	Group page
1	7C-3179	GEAR (50-TEETH)	1		
2	149-4915	AIR COMPRESSOR GP	1	Y	
3	6B-6682	NUT-FULL (3/4-16-THD)	1		
4	7X-0521	WASHER-HARD (20X36.5X5-MM THK)	1		

CAT codes: R, Y.

425-5542 BELT TENSIONER GP

425-5542 BELT TENSIONER GP S/N SZW1-UP PART OF 458-5970, 458-5976, 458-5979, 458-5988, 464-8591, 464-8594 OPTION AR-CAB

Drawing 1 of 1



Ref.	Part number	Description	Qty	Code	Group page
1	198-3611	BELT-SERPENTINE	1		
2	336-0057	FILM-INSTRUCTION (ALTERNATOR BELT MOUNTING)	1		
3	347-1266	GUARD AS	1		
4	198-4776	WASHER-HARD (8.8X20X8-MM THK)	4		
5	198-4777	WASHER-HARD (11X25X10-MM THK)	2		
6	8T-4136	BOLT (M10X1.5X25-MM)	2	M	
7	8T-4908	BOLT (M8X1.25X25-MM)	4	M	

CAT codes: M.

529-7481 BRACKET GP-MOUNTING -INSTALLATION

529-7481 BRACKET GP-MOUNTING -INSTALLATION S/N SZW1-UP PART OF 532-5950 BRACKET GP-MOUNTING

Drawing unavailable in the current source. The parts list is preserved below.

Ref.	Part number	Description	Qty	Code	Group page
1	9X-2041	SCREW-TRUSS HEAD (M10X1.5X20-MM)	2	M	
2	225-3109	SCREW-TRUSS HEAD (M4X0.7X14-MM)	4	M	
3	8T-4121	WASHER-HARD (11X21X2.5-MM THK)	3		
4	8T-4136	BOLT (M10X1.5X25-MM)	1	M	

CAT codes: M.

MANUALS-KOMATSU.COM

Complete Caterpillar PDF Parts Catalogue

SZW-SEBP6016

\$99

Buy on this catalogue page in our store.

Download instructions are sent after payment confirmation.

Buy complete PDF - \$99