





JY010107

Reference: A0100-001001

A001001 Engine, Gauge Cylinder (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT1E051-0101-8	Cylinder Block Assembly	1	SN: 8A0357-UP
2	KT16851-9626-0	• Cap	3	SN: 8A0357-UP
3	KT16851-9627-0	• Cap	5	SN: 8A0357-UP
4	KT15451-9627-0	• Cap	2	SN: 8A0357-UP
5	KT15261-9601-0	• Plug	5	SN: 8A0357-UP
6	KT15521-9602-0	• Plug	3	SN: 8A0357-UP
7	KT15521-9603-0	• Plug	1	SN: 8A0357-UP
8	KT15261-9616-0	• Plug, Expansion	1	SN: 8A0357-UP
9	KT05012-00508	• Pin	2	SN: 8A0357-UP
10	KT05012-00814	• Pin	2	SN: 8A0357-UP
11	KT15221-3365-0	• Pin	1	SN: 8A0357-UP
12	KT15231-3396-0	• Pin	2	SN: 8A0357-UP
13	KT17331-5919-0	• Pin	2	SN: 8A0357-UP
14	KT16851-1621-2	• Cover	1	SN: 8A0357-UP
15	KT06311-55020	Plug	1	SN: 8A0357-UP
16	KT04717-01320	Gasket	1	SN: 8A0357-UP

Reference: A0100-001001




JY010108

Reference: A0100-001002

A001002 Engine, Oil Pan (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT1G386-0150-0	Oil Pan Assembly	1	SN: 8A0357-UP
2	KT01023-50614	Bolt	18	SN: 8A0357-UP
3	KT06331-45016	Plug	1	SN: 8A0357-UP
4	KT04724-00160	Gasket	1	SN: 8A0357-UP
5	KT13901-3375-0	Plug, Drain	1	SN: 8A0357-UP
6	KT6C090-5896-0	Gasket	1	SN: 8A0357-UP
7	KT1G386-3211-0	Filter, Oil	1	SN: 8A0357-UP
8	KT04814-00160	O-ring	1	SN: 8A0357-UP
9	KT01123-60814	Bolt	1	SN: 8A0357-UP

Reference: A0100-001002




JY010109

Reference: A0100-001003

A001003 Engine, Cylinder Head (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT1G386-0174-0	Hanger	2	SN: 8A0357-UP
2	KT01123-60816	Bolt	2	SN: 8A0357-UP
3	KT16667-5769-2	Stay	1	SN: 8A0357-UP
4	KT1G969-0304-0	Cylinder Head Assembly	1	SN: 8A0357-UP
5	KT15321-9626-0	• Plug	1	SN: 8A0357-UP
6	KT15261-0337-0	• Plug	2	SN: 8A0357-UP
7	KT15841-1354-0	• Guide	3	SN: 8A0357-UP
8	KT15841-1356-0	• Guide	3	SN: 8A0357-UP
9	KT15261-9601-0	• Plug	1	SN: 8A0357-UP
10	KT15841-9602-0	• Plug	1	SN: 8A0357-UP
11	KT14601-0345-0	Bolt	14	SN: 8A0357-UP
12	KT16871-0331-3	Gasket	1	SN: 8A0357-UP
13	KT19837-5792-0	Spring	1	SN: 8A0357-UP

Reference: A0100-001003




JY010110

Reference: A0100-001004

A001004 Engine, Gear Case (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT17529-0402-5	Case Assembly	1	SN: 8A0357-UP
2	KT15521-9603-0	• Plug	8	SN: 8A0357-UP
3	KT15841-5628-0	• Pin	1	SN: 8A0357-UP
4	KT1G639-3288-0	• Cover	1	SN: 8A0357-UP
5	KT16259-3290-0	• Bolt	1	SN: 8A0357-UP
6	KT04814-50600	• O-ring	1	SN: 8A0357-UP
7	KT04814-00150	• O-ring	1	SN: 8A0357-UP
8	KT15241-3229-0	Joint	1	SN: 8A0357-UP
9	KT16851-3695-0	Spring	1	SN: 8A0357-UP
10	KT15841-3693-0	Seat, Valve	1	SN: 8A0357-UP
11	KT07715-03211	Ball	1	SN: 8A0357-UP
12	KT16871-0413-0	Gasket	1	SN: 8A0357-UP
13	KT01023-50618	Bolt	1	SN: 8A0357-UP
14	KT01023-60650	Bolt	7	SN: 8A0357-UP
15	KT15841-9101-0	Bolt	3	SN: 8A0357-UP
16	KT01023-50660	Bolt	1	SN: 8A0357-UP
17	KT01023-60670	Bolt	1	SN: 8A0357-UP
18	KT01023-50680	Bolt	2	SN: 8A0357-UP
19	KT17563-9101-0	Bolt	1	SN: 8A0357-UP
20	KT15877-0414-0	Seal, Oil	1	SN: 8A0357-UP
21	KT19461-8334-0	Cover	1	SN: 8A0357-UP
22	KT19461-8813-2	Gasket	1	SN: 8A0357-UP
23	KT15221-8821-0	Stud	3	SN: 8A0357-UP
24	KT02751-50060	Nut	3	SN: 8A0357-UP
25	KT1G386-3314-0	Plug	1	SN: 8A0357-UP
26	KT04817-50300	O-ring	1	SN: 8A0357-UP
27	KT19090-1131-0	Flange	1	SN: 8A0357-UP
28	KT19483-3312-3	Packing	1	SN: 8A0357-UP
29	KT01023-60650	Bolt	2	SN: 8A0357-UP
30	KT01023-50618	Bolt	1	SN: 8A0357-UP

Reference: A0100-001004




JY010111

Reference: A0100-001005

A001005 Engine, Head Cover (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT1G958-0551-2	Tube	1	SN: 8A0357-UP
2	KT09318-88125	Clamp	2	SN: 8A0357-UP
2	KT1G958-1450-4	Head Cover Assembly	1	SN: 8A0357-UP
3	KT1G958-1451-2	• Cover	1	SN: 8A0357-UP
4	KT16241-7337-0	• Pipe	1	SN: 8A0357-UP
5	KT1G801-0512-0	• Cover	1	SN: 8A0357-UP
6	KT1G911-0520-3	• Valve Assembly	1	SN: 8A0357-UP
7	KT03024-50510	• Screw	4	SN: 8A0357-UP
8	KT1G958-1452-0	• Gasket	1	SN: 8A0357-UP
9	KT1G911-9102-2	Bolt	4	SN: 8A0357-UP
10	KTE9151-3314-0	Plug	1	SN: 8A0357-UP
11	KT04814-50300	O-ring	1	SN: 8A0357-UP

Reference: A0100-001005




JY010112

Reference: A0100-001006

A001006 Engine, Oil Filter (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT15241-3209-4	Oil Filler Assembly	1	SN: 8A0357-UP
2	KT1G386-3280-0	Tray	1	SN: 8A0357-UP

Reference: A0100-001006




JY010113

Reference: A0100-001007

A001007 Engine, Oil Gauge (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT17456-3642-0	Guide	1	SN: 8A0357-UP
2	KT1G386-3641-0	Gauge, Oil Level Sight	1	SN: 8A0357-UP

Reference: A0100-001007




JY010114

Reference: A0100-001008

A001008 Engine, Oil Pump (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT16851-3501-2	Oil Pump Assembly	1	SN: 8A0357-UP
2	KT16851-3515-2	Gasket	1	SN: 8A0357-UP
3	KT15841-9105-0	Bolt	3	SN: 8A0357-UP
4	KT15841-3566-0	Gear	1	SN: 8A0357-UP
5	KT05712-00408	Key	1	SN: 8A0357-UP
6	KT02783-50100	Nut	1	SN: 8A0357-UP

Reference: A0100-001008




JY010115

Reference: A0100-001009

A001009 Engine, Main Bearing Case (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT16851-0709-0	Main Metal Assembly	1	SN: 8A0357-UP
2	KT15841-0454-0	• Bolt	2	SN: 8A0357-UP
3	KT16861-2348-0	• Metal	1	SN: 8A0357-UP
4	KT15852-0436-0	Gasket	1	SN: 8A0357-UP
4	KT15841-0480-3	Cover Assembly	1	SN: 8A0357-UP
5	KT15841-0481-5	• Cover	1	SN: 8A0357-UP
6	KT19215-9916-0	• Seal, Oil	1	SN: 8A0357-UP
7	KT15841-0482-3	Gasket	1	SN: 8A0357-UP
8	KT01023-50622	Bolt	16	SN: 8A0357-UP
9	KT16851-0704-0	Main Metal Assembly	1	SN: 8A0357-UP
10	KT15841-0454-0	• Bolt	2	SN: 8A0357-UP
11	KT16861-2349-0	• Metal	1	SN: 8A0357-UP
12	KT16851-0705-0	Main Metal Assembly	1	SN: 8A0357-UP
13	KT15841-0454-0	• Bolt	2	SN: 8A0357-UP
14	KT16861-2349-0	• Metal	1	SN: 8A0357-UP
15	KT15841-0456-2	Bolt	2	SN: 8A0357-UP

Reference: A0100-001009



JY010116

Reference: A0100-001010

A001010 Engine, Camshaft and Idle Gearshaft (#8A0357-)

Item	Part No.	Part Name	Qty	Options
1	KT16851-1555-2	Tappet	6	SN: 8A0357-UP
2	KT16851-1511-0	Rod, Push	6	SN: 8A0357-UP
3	KT16864-1601-5	Camshaft Assembly	1	SN: 8A0357-UP
4	KT07715-00401	• Ball	1	SN: 8A0357-UP
5	KT16864-1651-0	• Gear	1	SN: 8A0357-UP
6	KT05712-00518	• Key	1	SN: 8A0357-UP
7	KT15841-1627-0	• Stopper	1	SN: 8A0357-UP
8	KT01023-50612	Bolt	2	SN: 8A0357-UP
8	KT15875-9934-0	Gear Assembly, Idle	1	SN: 8A0357-UP
9	KT15875-2401-3	• Gear	1	SN: 8A0357-UP
10	KT15875-2428-2	• • Bushing	1	SN: 8A0357-UP
11	KT15875-2437-0	• Collar	1	SN: 8A0357-UP
12	KT15875-2432-0	• Ring, Snap	1	SN: 8A0357-UP
13	KT15875-2425-0	• Shaft	1	SN: 8A0357-UP
14	KT01023-50614	Bolt	3	SN: 8A0357-UP

Reference: A0100-001010

Get the complete PDF catalogue

Komatsu 3D67E-2A S/N 8A0357-UP (For PC18MR-3)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.