





Reference: B0100-001001

B001001 Engine Mounting (#35001-)

Item	Part No.	Part Name	Qty	Options
1	2A5-01-11880	Bracket	1	SN: 35001-UP
2	2A6-01-11121	Bracket	1	SN: 35001-UP
3	2A5-01-11230	Bolt	3	SN: 35001-UP
4	2A6-01-11130	Bolt	2	SN: 35001-UP
5	2A6-01-11650	Bolt	1	SN: 35001-UP
6	01643-31232	Washer	6	SN: 35001-UP
7	2A6-01-11680	Spacer	1	SN: 35001-UP
8	2A5-01-11910	Bracket	2	SN: 35001-UP
9	2A5-01-11230	Bolt	8	SN: 35001-UP
10	01643-31232	Washer	8	SN: 35001-UP
11	04020-01228	Pin, Dowel	4	SN: 35001-UP
12	2A5-01-11320	Cushion	4	SN: 35001-UP
13	2A5-01-11261	Plate	2	SN: 35001-UP
14	2A5-01-11271	Plate	2	SN: 35001-UP
15	01580-11613	Nut	3	SN: 35001-UP
16	01643-31645	Washer	3	SN: 35001-UP
17	2A6-01-11710	Cushion	4	SN: 35001-UP
18	2A5-01-11261	Plate	2	SN: 35001-UP
19	2A5-01-11271	Plate	2	SN: 35001-UP
20	2A5-01-11590	Plate	2	SN: 35001-UP
21	01011-81655	Bolt	2	SN: 35001-UP
22	01643-31645	Washer	2	SN: 35001-UP
23	20Y-01-12270	Bolt	2	SN: 35001-UP
24	01643-31645	Washer	2	SN: 35001-UP

Reference: B0100-001001




JY033564

Reference: B0200-002001

B002001 Air Cleaner, Inner Parts (#35001-)

Item	Part No.	Part Name	Qty	Options
1	6755-81-7200	Air Cleaner Assembly	1	SN: 35001-UP
	600-185-4100	• Element Assembly	1	SN: 35001-UP
2	600-185-4110	•• Element, Outer	1	SN: 35001-UP
3		•• Element, Inner	1	SN: 35001-UP
4	600-184-1470	•• O-ring	1	SN: 35001-UP
5	600-184-1420	• Cover	1	SN: 35001-UP
6	600-184-1350	• Valve, Vacuator	1	SN: 35001-UP
7	600-181-1930	• Plate, Service Instruction, Air Cleaner	1	SN: 35001-UP

Reference: B0200-002001




Reference: B0200-002002

B002002 Air Cleaner, Air Cleaner Mounting (#35001-)

Item	Part No.	Part Name	Qty	Options
1	6222-81-7190	Band	2	SN: 35001-UP
2	6643-11-4641	Bolt	2	SN: 35001-UP
3	2A6-01-21110	Bracket	1	SN: 35001-UP
4	2A6-01-11111	Hose	1	SN: 35001-UP
5	2A6-01-11730	Sheet	2	SN: 35001-UP
6	2A6-54-12771	Sheet	1	SN: 35001-UP
7	07299-00105	Clamp	1	SN: 35001-UP
8	07299-00130	Clamp	1	SN: 35001-UP
	22U-01-27200	Hood Assembly	1	SN: 35001-UP
9		• Hood	1	SN: 35001-UP
10	600-714-1260	• Clamp	1	SN: 35001-UP
11	7861-93-1430	Sensor, Dust Indicator	1	SN: 35001-UP
12	6252-81-7900	Sensor, Airflow	1	SN: 35001-UP
	6252-81-7910	• O-ring	1	SN: 35001-UP
13	01023-10412	Screw	2	SN: 35001-UP
14	01010-81225	Bolt	4	SN: 35001-UP
15	175-54-34170	Washer	4	SN: 35001-UP

Reference: B0200-002002




JH019075

Reference: B0200-002003

B002003 Air Cleaner, Komatsu Closed Crankcase Ventilation (KCCV) (#35001-)

Item	Part No.	Part Name	Qty	Options
1	600-332-2211	Ventilator	1	SN: 35001-UP
	600-331-2900	• Element Kit	1	SN: 35001-UP
2	01010-81070	Bolt	4	SN: 35001-UP
3	01643-31032	Washer	4	SN: 35001-UP
4	22U-01-41250	Hose	1	SN: 35001-UP
5	07281-00359	Clamp, Hose	1	SN: 35001-UP
6	2A5-01-11210	Clip	1	SN: 35001-UP
7	01010-81230	Bolt	1	SN: 35001-UP
8	01643-31232	Washer	1	SN: 35001-UP
9	6746-21-7460	Joint	1	SN: 35001-UP
10	07206-30812	Bolt, Joint	1	SN: 35001-UP
11	07005-01212	Seal, Washer	2	SN: 35001-UP
12	6755-21-7240	Joint	1	SN: 35001-UP
13	07206-30812	Bolt, Joint	1	SN: 35001-UP
14	07005-01212	Seal, Washer	2	SN: 35001-UP
15	6755-21-7290	Hose	1	SN: 35001-UP
16	07281-00359	Clamp, Hose	2	SN: 35001-UP
17	6252-11-2901	Sensor, Pressure	1	SN: 35034-UP
	6252-11-2900	Sensor, Pressure	1	SN: 35001-35033
	6252-11-2800	• O-ring	1	SN: 35001-UP
18	600-331-1930	Bolt	1	SN: 35001-UP
19	01640-20508	Washer	1	SN: 35001-UP
20	6755-21-7310	Hose	1	SN: 35001-UP
21	07281-00359	Clamp, Hose	2	SN: 35001-UP
22	2A6-01-11391	Bracket	1	SN: 35001-UP
23	01010-81230	Bolt	2	SN: 35001-UP
24	01643-31232	Washer	2	SN: 35001-UP

Reference: B0200-002003




Reference: B0200-002004

B002004 Air Cleaner, Komatsu Closed Crankcase Ventilation (KCCV) Piping (#35001-)

Item	Part No.	Part Name	Qty	Options
1	2A6-01-11511	Hose	1	SN: 35001-UP
2	07281-00197	Clamp	2	SN: 35001-UP
3	6261-51-2810	Valve, Check	1	SN: 35001-UP
4	07260-20906	Hose	1	SN: 35001-UP
5	07281-00197	Clamp	2	SN: 35001-UP
6	04434-51608	Clip	1	SN: 35001-UP
7	01010-80825	Bolt	1	SN: 35001-UP
8	01643-30823	Washer	1	SN: 35001-UP
9	6755-21-7150	Bracket	1	SN: 35001-UP
10	01584-00806	Nut	1	SN: 35001-UP
11	04434-52310	Clip	1	SN: 35001-UP
12	2A5-01-11580	Cushion	1	SN: 35001-UP
13	01010-80825	Bolt	1	SN: 35001-UP
14	01643-30823	Washer	1	SN: 35001-UP
15	22N-957-1420	Collar	1	SN: 35001-UP
16	2A6-01-11551	Bracket	1	SN: 35001-UP
17	01010-81230	Bolt	1	SN: 35001-UP
18	01643-31232	Washer	1	SN: 35001-UP
19	04434-52312	Clip	1	SN: 35001-UP
20	2A5-01-11580	Cushion	1	SN: 35001-UP
21	6755-21-7121	Joint	1	SN: 35001-UP
22	6755-21-7110	O-ring	1	SN: 35001-UP
23	07281-00289	Clamp	1	SN: 35001-UP
24	04434-53412	Clip	1	SN: 35001-UP
25	07095-40627	Cushion	1	SN: 35001-UP
26	01010-81230	Bolt	1	SN: 35001-UP
27	01643-31232	Washer	1	SN: 35001-UP
28	2A6-01-11521	Hose	1	SN: 35001-UP
29	07281-00197	Clamp	2	SN: 35001-UP
30	07281-00197	Clamp	1	SN: 35001-UP
31	04434-52312	Clip	2	SN: 35001-UP
32	2A5-01-11580	Cushion	2	SN: 35001-UP
33	01010-81230	Bolt	2	SN: 35001-UP

Item	Part No.	Part Name	Qty	Options
34	01643-31232	Washer	2	SN: 35001-UP
35	6755-21-7430	Hose	1	SN: 35001-UP
36	07281-00197	Clamp	2	SN: 35001-UP
37	2A6-01-11561	Bracket	1	SN: 35001-UP
38	01010-81230	Bolt	2	SN: 35001-UP
39	01643-31232	Washer	2	SN: 35001-UP
40	04434-52310	Clip	1	SN: 35001-UP
41	2A5-01-11580	Cushion	1	SN: 35001-UP
42	07281-00197	Clamp	1	SN: 35001-UP
43	6252-21-7720	Hose	1	SN: 35001-UP

Reference: B0200-002004




JY031893

Reference: B0200-003001

B003001 Air Cleaner, Inner Parts, Air Cleaner (#35001-)

Item	Part No.	Part Name	Qty	Options
	6755-81-7400	Air Cleaner Assembly	1	SN: 35001-UP
	600-185-4100	• Element Assembly	1	SN: 35001-UP
1	600-185-4110	• • Element, Outer	1	SN: 35001-UP
2		• • Element, Inner	1	SN: 35001-UP
3	600-184-1470	• • O-ring	1	SN: 35001-UP
4	600-184-1420	• Cover	1	SN: 35001-UP
5	600-184-1350	• Valve, Vacuator	1	SN: 35001-UP

Reference: B0200-003001




JH102813

Reference: B0200-003002

B003002 Air Cleaner, Air Cleaner Mounting (Pre-cleaner) (#35001-)

Item	Part No.	Part Name	Qty	Options
1	6222-81-7190	Band	2	SN: 35001-UP
2	6643-11-4641	Bolt	2	SN: 35001-UP
3	2A6-01-21110	Bracket	1	SN: 35001-UP
4	2A6-01-11111	Hose	1	SN: 35001-UP
5	2A6-01-11730	Sheet	2	SN: 35001-UP
6	2A6-54-12771	Sheet	1	SN: 35001-UP
7	07299-00105	Clamp	1	SN: 35001-UP
8	07299-00130	Clamp	1	SN: 35001-UP
9	2A6-01-11840	Seal	1	SN: 35001-UP
10	7861-93-1430	Sensor, Dust Indicator	1	SN: 35001-UP
11	6252-81-7900	Sensor, Airflow	1	SN: 35001-UP
	6252-81-7910	• O-ring	1	SN: 35001-UP
12	01023-10412	Screw	2	SN: 35001-UP
13	01010-81225	Bolt	4	SN: 35001-UP
14	175-54-34170	Washer	4	SN: 35001-UP

Reference: B0200-003002




JH019075

Reference: B0200-003003

B003003 Air Cleaner, Komatsu Closed Crankcase Ventilation (KCCV) (#35001-)

Item	Part No.	Part Name	Qty	Options
1	600-332-2211	Ventilator	1	SN: 35001-UP
	600-331-2900	• Element Kit	1	SN: 35001-UP
2	01010-81070	Bolt	4	SN: 35001-UP
3	01643-31032	Washer	4	SN: 35001-UP
4	22U-01-41250	Hose	1	SN: 35001-UP
5	07281-00359	Clamp, Hose	1	SN: 35001-UP
6	2A5-01-11210	Clip	1	SN: 35001-UP
7	01010-81230	Bolt	1	SN: 35001-UP
8	01643-31232	Washer	1	SN: 35001-UP
9	6746-21-7460	Joint	1	SN: 35001-UP
10	07206-30812	Bolt, Joint	1	SN: 35001-UP
11	07005-01212	Seal, Washer	2	SN: 35001-UP
12	6755-21-7240	Joint	1	SN: 35001-UP
13	07206-30812	Bolt, Joint	1	SN: 35001-UP
14	07005-01212	Seal, Washer	2	SN: 35001-UP
15	6755-21-7290	Hose	1	SN: 35001-UP
16	07281-00359	Clamp, Hose	2	SN: 35001-UP
17	6252-11-2901	Sensor, Pressure	1	SN: 35001-UP
	6252-11-2800	• O-ring	1	SN: 35001-UP
18	600-331-1930	Bolt	1	SN: 35001-UP
19	01640-20508	Washer	1	SN: 35001-UP
20	6755-21-7310	Hose	1	SN: 35001-UP
21	07281-00359	Clamp, Hose	2	SN: 35001-UP
22	2A6-01-11391	Bracket	1	SN: 35001-UP
23	01010-81230	Bolt	2	SN: 35001-UP
24	01643-31232	Washer	2	SN: 35001-UP

Reference: B0200-003003



Reference: B0200-003004

B003004 Air Cleaner, Komatsu Closed Crankcase Ventilation (KCCV) Piping (#35001-)

Item	Part No.	Part Name	Qty	Options
1	2A6-01-11511	Hose	1	SN: 35001-UP
2	07281-00197	Clamp	2	SN: 35001-UP
3	6261-51-2810	Valve, Check	1	SN: 35001-UP
4	07260-20906	Hose	1	SN: 35001-UP
5	07281-00197	Clamp	2	SN: 35001-UP
6	04434-51608	Clip	1	SN: 35001-UP
7	01010-80825	Bolt	1	SN: 35001-UP
8	01643-30823	Washer	1	SN: 35001-UP
9	6755-21-7150	Bracket	1	SN: 35001-UP
10	01584-00806	Nut	1	SN: 35001-UP
11	04434-52310	Clip	1	SN: 35001-UP
12	2A5-01-11580	Cushion	1	SN: 35001-UP
13	01010-80825	Bolt	1	SN: 35001-UP
14	01643-30823	Washer	1	SN: 35001-UP
15	22N-957-1420	Collar	1	SN: 35001-UP
16	2A6-01-11551	Bracket	1	SN: 35001-UP
17	01010-81230	Bolt	1	SN: 35001-UP
18	01643-31232	Washer	1	SN: 35001-UP
19	04434-52312	Clip	1	SN: 35001-UP
20	2A5-01-11580	Cushion	1	SN: 35001-UP
21	6755-21-7121	Joint	1	SN: 35001-UP
22	6755-21-7110	O-ring	1	SN: 35001-UP
23	07281-00289	Clamp	1	SN: 35001-UP
24	04434-53412	Clip	1	SN: 35001-UP
25	07095-40627	Cushion	1	SN: 35001-UP
26	01010-81230	Bolt	1	SN: 35001-UP
27	01643-31232	Washer	1	SN: 35001-UP
28	2A6-01-11521	Hose	1	SN: 35001-UP
29	07281-00197	Clamp	2	SN: 35001-UP
30	07281-00197	Clamp	1	SN: 35001-UP
31	04434-52312	Clip	2	SN: 35001-UP
32	2A5-01-11580	Cushion	2	SN: 35001-UP
33	01010-81230	Bolt	2	SN: 35001-UP

Get the complete PDF catalogue

Komatsu PC290LC-11 S/N 35001-UP (For KAL)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.