





Reference: E0100-001001

E001001 Battery, Lower Battery (For 120volt 240Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76213	Battery Assembly	1	SN: 321560-UP
	3BB-07-79930	Battery Assembly	1	SN: 320001-321559
1	3BB-07-76111	• Case	1	SN: 320001-UP
2	3BB-55-79171	• Fan Assembly	1	SN: 320001-UP
3	01640-20408	• Washer	24	SN: 320001-UP
4	01252-70450	• Bolt	24	SN: 320001-UP
5	37B-1QL-5010	• Plate, Warning, Do Not Put Hands	1	SN: 320001-UP
6	3BB-07-72580	• Sheet	8	SN: 320001-UP
7	3BB-07-72590	• Sheet	1	SN: 320001-UP
8	3BB-07-72670	• Sheet	2	SN: 320001-UP
9	3BB-07-51710	• Battery, Wet, (EC-FV600H5K1)	20	SN: 320001-UP
10	3BB-07-72420	• Sheet	4	SN: 320001-UP
11	3BB-07-72450	• Sheet	1	SN: 320001-UP
12	3BB-07-72460	• Sheet	2	SN: 320001-UP
13	3BB-07-72470	• Sheet	2	SN: 320001-UP
14	3BB-07-62470	• Sheet	2	SN: 320001-UP
15	3BB-55-68860	• Cable	8	SN: 320001-UP
16	3BB-55-79190	• Cable	2	SN: 320001-UP
17	01580-10806	• Nut	20	SN: 320001-UP
18	01643-30823	• Washer	20	SN: 320001-UP
19	3BB-55-79210	• Cable	2	SN: 320001-UP
20	01580-10806	• Nut	4	SN: 320001-UP
21	01643-30823	• Washer	4	SN: 320001-UP
22	3BB-55-78960	• Cable	2	SN: 320001-UP
23	01580-10806	• Nut	4	SN: 320001-UP
24	01643-30823	• Washer	4	SN: 320001-UP
25	3BB-55-78970	• Cable	2	SN: 320001-UP
26	01580-10806	• Nut	4	SN: 320001-UP
27	01643-30823	• Washer	4	SN: 320001-UP
28	3BB-55-78980	• Cable	2	SN: 320001-UP
29	01580-10806	• Nut	4	SN: 320001-UP
30	01643-30823	• Washer	4	SN: 320001-UP
31	3BB-55-79271	• Wiring Harness	1	SN: 320001-UP
32	01370-10308	• Screw	3	SN: 320001-UP

Item	Part No.	Part Name	Qty	Options
33	3BA-07-71211	• Plug	3	SN: 320001-UP
34	07095-20211	• Cushion	4	SN: 320001-UP
35	08034-20519	• Band	12	SN: 320001-UP
36	3BB-07-72720	• Seal	3	SN: 320001-UP
37	3BB-07-72730	• Seal	1	SN: 320001-UP
38	3BB-07-72760	• Seal	1	SN: 320001-UP
39	3BB-07-72480	• Sheet	1	SN: 320001-UP
[A2]-The part specified in the line above can be used instead of this part.				SN: UP

Reference: E0100-001001




Reference: E0100-001002

E001002 Battery, Upper Battery (For 120volt 240Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76213	Battery Assembly	1	SN: 321560-UP
	3BB-07-79930	Battery Assembly	1	SN: 320001-321559
1	3BB-07-76120	• Bracket	1	SN: 320001-UP
2	01010-81235	• Bolt	2	SN: 320001-UP
3	01643-31232	• Washer	2	SN: 320001-UP
4	22B-46-24380	• Washer	2	SN: 320001-UP
5	3BB-07-72680	• Sheet	4	SN: 320001-UP
6	3BB-07-51710	• Battery, Wet, (EC-FV600H5K1)	20	SN: 320001-UP
7	3BB-07-72450	• Sheet	3	SN: 320001-UP
8	3BB-07-72440	• Sheet	2	SN: 320001-UP
9	3BB-07-62470	• Sheet	2	SN: 320001-UP
10	3BB-55-68860	• Cable	6	SN: 320001-UP
11	3BB-55-79190	• Cable	2	SN: 320001-UP
12	01580-10806	• Nut	16	SN: 320001-UP
13	01643-30823	• Washer	16	SN: 320001-UP
14	3BB-55-79180	• Cable	2	SN: 320001-UP
15	01580-10806	• Nut	4	SN: 320001-UP
16	01643-30823	• Washer	4	SN: 320001-UP
17	3BB-55-78960	• Cable	2	SN: 320001-UP
18	01580-10806	• Nut	4	SN: 320001-UP
19	01643-30823	• Washer	4	SN: 320001-UP
20	3BB-55-78970	• Cable	2	SN: 320001-UP
21	01580-10806	• Nut	4	SN: 320001-UP
22	01643-30823	• Washer	4	SN: 320001-UP
23	3BB-55-78980	• Cable	2	SN: 320001-UP
24	01580-10806	• Nut	4	SN: 320001-UP
25	01643-30823	• Washer	4	SN: 320001-UP
26	3BB-55-78830	• Cable	2	SN: 320001-UP
27	01580-10806	• Nut	4	SN: 320001-UP
28	01643-30823	• Washer	4	SN: 320001-UP
29	3BB-55-79281	• Wiring Harness	1	SN: 321560-UP
	3BB-55-79280	• Wiring Harness	1	SN: 320001-321559
30	01580-10806	• Nut	4	SN: 320001-UP
31	01643-30823	• Washer	4	SN: 320001-UP

Item	Part No.	Part Name	Qty	Options
32	3BB-55-79291	• Wiring Harness	1	SN: 321560-UP
	3BB-55-79290	• Wiring Harness	1	SN: 320001-321559
33	01580-10806	• Nut	4	SN: 320001-UP
34	01643-30823	• Washer	4	SN: 320001-UP
35	08034-20519	• Band	5	SN: 320001-UP
36	01370-10308	• Screw	2	SN: 320001-UP
37	3BA-07-71211	• Plug	2	SN: 320001-UP
38	3BB-07-72740	• Sheet	2	SN: 320001-UP
		[A2]-The part specified in the line above can be used instead of this part.		SN: UP

Reference: E0100-001002




Reference: E0100-001003

E001003 Battery, Fuse Box (For 120volt 240Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76213	Battery Assembly	1	SN: 321560-UP
	3BB-07-79930	Battery Assembly	1	SN: 320001-321559
1	3BB-07-76130	• Cover	1	SN: 320001-UP
2	3BB-07-72380	• Trim	2	SN: 320001-UP
3	3BB-07-72660	• Sheet	2	SN: 320001-UP
4	3EB-04-56530	• Clip	4	SN: 320001-UP
5	3BB-07-71150	• Cover	1	SN: 320001-UP
6	01010-81020	• Bolt	4	SN: 320001-UP
7	01643-31032	• Washer	4	SN: 320001-UP
8	3BB-96-63150	• Plate, Electric Caution	1	SN: 320001-UP
9	3BB-07-73150	• Sheet	1	SN: 320001-UP
10	3EB-04-56530	• Clip	2	SN: 320001-UP
11	3BB-55-78910	• Plate	1	SN: 320001-UP
12	3BB-07-72330	• Terminal	1	SN: 320001-UP
13	01023-70625	• Screw	2	SN: 320001-UP
14	3BB-55-78710	• Terminal	1	SN: 320001-UP
15	01023-70625	• Screw	2	SN: 320001-UP
16	3BB-55-68670	• Terminal	2	SN: 320001-UP
17	3BB-55-78920	• Wiring Harness	1	SN: 320001-UP
18	3BB-55-78930	• Wiring Harness	1	SN: 320001-UP
19	3BB-07-72340	• Bus Bar, (+)	1	SN: 320001-UP
20	01643-30823	• Washer	5	SN: 320001-UP
21	3BB-07-72350	• Bus Bar, (+)	1	SN: 320001-UP
22	01010-80820	• Bolt	3	SN: 320001-UP
23	01643-30823	• Washer	3	SN: 320001-UP
24	01580-10806	• Nut	5	SN: 320001-UP
25	01640-20816	• Washer	7	SN: 320001-UP
26	01602-20825	• Washer, Spring	2	SN: 320001-UP
27	37B-2EJ-7010	• Fuse, 100Amp.	4	SN: 320001-UP
28	01643-30823	• Washer	8	SN: 320001-UP

[A2]-The part specified in the line above can be used instead of this part.

SN: UP



JY100280

Reference: E0100-001004

E001004 Battery, Battery Cable (For 120volt 240Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76213	Battery Assembly	1	SN: 321560-UP
	3BB-07-79930	Battery Assembly	1	SN: 320001-321559
1	3BB-55-78940	• Cable Assembly	1	SN: 320001-UP
2	01023-10630	• Screw	2	SN: 320001-UP
3	01010-81020	• Bolt	2	SN: 320001-UP
4	01643-31032	• Washer	2	SN: 320001-UP
5	01010-81035	• Bolt	2	SN: 320001-UP
6	01643-31032	• Washer	2	SN: 320001-UP
7	203-54-56960	• Collar	2	SN: 320001-UP
8	3BB-07-62290	• Cushion	2	SN: 320001-UP
9	2A5-979-1650	• Washer	2	SN: 320001-UP
10	3BB-07-72570	• Cushion	1	SN: 320001-UP
11	3BB-07-72491	• Bracket	1	SN: 323092-UP
	3BB-07-72490	• Bracket	1	SN: 320001-323091
12	01010-80612	• Bolt	2	SN: 320001-UP
13	01643-30623	• Washer	2	SN: 320001-UP
14	3BB-07-72740	• Sheet	1	SN: 320001-UP
15	3BB-07-72750	• Seal	1	SN: 320001-UP
16		• Plate, Name	1	SN: 321560-UP
		• Plate, Name	1	SN: 320001-321559
17	3EB-96-51120	• Rivet	4	SN: 320001-UP
18	3BB-07-73160	Bracket	1	SN: 320001-UP
19	01010-81025	Bolt	4	SN: 320001-UP
20	01643-31032	Washer	4	SN: 320001-UP
21	3BB-41-62780	Cushion	2	SN: 320001-UP
22	3BB-50-72760	Cushion	2	SN: 320001-UP

[A1]-This part and the part specified in the line immediately above are interchangeable.

SN: UP


[A2]-The part specified in the line above can be used instead of this part.

SN: UP

[C1]-This part cannot be supplied as an individual part. It is supplied as an assembly.

SN: UP

Reference: E0100-001004




Reference: E0100-002001

E002001 Battery, Lower Battery (For 120volt 180Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76223	Battery Assembly	1	SN: 321560-UP
	3BB-07-79940	Battery Assembly	1	SN: 320001-321559
1	3BB-07-76111	• Case	1	SN: 320001-UP
2	3BB-55-79171	• Fan Assembly	1	SN: 320001-UP
3	01640-20408	• Washer	24	SN: 320001-UP
4	01252-70450	• Bolt	24	SN: 320001-UP
5	37B-1QL-5010	• Plate, Warning, Do Not Put Hands	1	SN: 320001-UP
6	3BB-07-72580	• Sheet	8	SN: 320001-UP
7	3BB-07-72590	• Sheet	1	SN: 320001-UP
8	3BB-07-72670	• Sheet	2	SN: 320001-UP
9	3BB-07-51710	• Battery, Wet, (EC-FV600H5K1)	20	SN: 320001-UP
10	3BB-07-72420	• Sheet	4	SN: 320001-UP
11	3BB-07-72450	• Sheet	1	SN: 320001-UP
12	3BB-07-72460	• Sheet	2	SN: 320001-UP
13	3BB-07-72470	• Sheet	2	SN: 320001-UP
14	3BB-07-62470	• Sheet	2	SN: 320001-UP
15	3BB-55-68860	• Cable	8	SN: 320001-UP
16	3BB-55-79190	• Cable	2	SN: 320001-UP
17	01580-10806	• Nut	20	SN: 320001-UP
18	01643-30823	• Washer	20	SN: 320001-UP
19	3BB-55-79210	• Cable	2	SN: 320001-UP
20	01580-10806	• Nut	4	SN: 320001-UP
21	01643-30823	• Washer	4	SN: 320001-UP
22	3BB-55-78960	• Cable	2	SN: 320001-UP
23	01580-10806	• Nut	4	SN: 320001-UP
24	01643-30823	• Washer	4	SN: 320001-UP
25	3BB-55-78970	• Cable	2	SN: 320001-UP
26	01580-10806	• Nut	4	SN: 320001-UP
27	01643-30823	• Washer	4	SN: 320001-UP
28	3BB-55-78980	• Cable	2	SN: 320001-UP
29	01580-10806	• Nut	4	SN: 320001-UP
30	01643-30823	• Washer	4	SN: 320001-UP
31	3BB-55-78540	• Wiring Harness	1	SN: 320001-UP
32	01370-10308	• Screw	3	SN: 320001-UP

Item	Part No.	Part Name	Qty	Options
33	3BA-07-71211	• Plug	3	SN: 320001-UP
34	07095-20211	• Cushion	4	SN: 320001-UP
35	08034-20519	• Band	12	SN: 320001-UP
36	3BB-07-72720	• Seal	3	SN: 320001-UP
37	3BB-07-72730	• Seal	1	SN: 320001-UP
38	3BB-07-72760	• Seal	1	SN: 320001-UP
39	3BB-07-72480	• Sheet	1	SN: 320001-UP
[A2]-The part specified in the line above can be used instead of this part.				SN: UP

Reference: E0100-002001



21180231

Reference: E0100-002002

E002002 Battery, Upper Battery (For 120volt 180Amp. Battery)(#320001-)

Item	Part No.	Part Name	Qty	Options
	3BB-07-76223	Battery Assembly	1	SN: 321560-UP
	3BB-07-79940	Battery Assembly	1	SN: 320001-321559
1	3BB-07-78120	• Bracket	1	SN: 320001-UP
2	01010-81235	• Bolt	2	SN: 320001-UP
3	01643-31232	• Washer	2	SN: 320001-UP
4	22B-46-24380	• Washer	2	SN: 320001-UP
5	3BB-07-72680	• Sheet	4	SN: 320001-UP
6	3BB-07-51710	• Battery, Wet, (EC-FV600H5K1)	10	SN: 320001-UP
7	3BB-07-73280	• Weight	2	SN: 320001-UP
8	3BB-07-73290	• Weight	2	SN: 320001-UP
9	3BB-55-68860	• Cable	3	SN: 320001-UP
10	3BB-55-79190	• Cable	1	SN: 320001-UP
11	01580-10806	• Nut	8	SN: 320001-UP
12	01643-30823	• Washer	8	SN: 320001-UP
13	3BB-55-79180	• Cable	1	SN: 320001-UP
14	01580-10806	• Nut	2	SN: 320001-UP
15	01643-30823	• Washer	2	SN: 320001-UP
16	3BB-55-78960	• Cable	1	SN: 320001-UP
17	01580-10806	• Nut	2	SN: 320001-UP
18	01643-30823	• Washer	2	SN: 320001-UP
19	3BB-55-78970	• Cable	1	SN: 320001-UP
20	01580-10806	• Nut	2	SN: 320001-UP
21	01643-30823	• Washer	2	SN: 320001-UP
22	3BB-55-78980	• Cable	1	SN: 320001-UP
23	01580-10806	• Nut	2	SN: 320001-UP
24	01643-30823	• Washer	2	SN: 320001-UP
25	3BB-55-78830	• Cable	1	SN: 320001-UP
26	01580-10806	• Nut	2	SN: 320001-UP
27	01643-30823	• Washer	2	SN: 320001-UP
28	3BB-55-78521	• Wiring Harness	1	SN: 321560-UP
	3BB-55-78520	• Wiring Harness	1	SN: 320001-321559
29	01580-10806	• Nut	2	SN: 320001-UP
30	01643-30823	• Washer	2	SN: 320001-UP
31	3BB-55-79291	• Wiring Harness	1	SN: 321560-UP
	3BB-55-79290	• Wiring Harness	1	SN: 320001-321559
32	01580-10806	• Nut	4	SN: 320001-UP
33	01643-30823	• Washer	4	SN: 320001-UP
34	08034-20519	• Band	3	SN: 320001-UP
35	01370-10308	• Screw	1	SN: 320001-UP
36	3BA-07-71211	• Plug	1	SN: 320001-UP
37	3BB-07-72740	• Sheet	2	SN: 320001-UP
38	3BB-07-72810	• Sheet	2	SN: 320001-UP
39	3BB-07-72820	• Sheet	2	SN: 320001-UP
40	22J-46-12120	• Cap	4	SN: 320001-UP
41	3BB-07-72830	• Sheet	2	SN: 320001-UP
42	3BB-07-72440	• Sheet	2	SN: 320001-UP
43	3BB-07-72460	• Sheet	1	SN: 320001-UP

Get the complete PDF catalogue

Komatsu FE30-2 S/N 320001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.