


シリンダヘッド
FIG. 101 CYLINDER HEAD



Reference: 101

030010 CYLINDER HEAD


Item	Part No.	Part Name	Qty	Options
	6130-11-1000	CYLINDER HEAD ASSEMBLY, WITH VALVE	1	SN: 11007-UP
	6130-11-1200	• CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 11007-UP
1		• ☆ HEAD, CYLINDER	1	SN: 11007-UP
2	6130-11-1131	• SLEEVE	4	SN: 11007-UP
3	6130-19-1310	• GUIDE, VALVE	8	SN: 11007-UP
4	6130-11-1323	• SEAT, EXHAUST VALVE (STD)	4	SN: 11007-UP
4	6130-19-1323	• SEAT, 0.25MM, EXHAUST VALVE (OS)	4	SN: 11007-UP
4	6130-18-1323	• SEAT, 0.50MM, EXHAUST VALVE (OS)	4	SN: 11007-UP
4	6130-17-1323	• SEAT, 0.75MM, EXHAUST VALVE (OS)	4	SN: 11007-UP
4	6130-16-1323	• SEAT, 1.00MM, EXHAUST VALVE (OS)	4	SN: 11007-UP
5	6130-11-1931	• PLATE	1	SN: 21822-UP
5	6130-11-1930	• PLATE	1	SN: 11007-21821
6	6130-11-1940	• GASKET (K1)	1	SN: 11007-UP
7	01010-30816	• BOLT	6	SN: 11007-UP
8	01602-00825	• WASHER, SPRING	6	SN: 11007-UP
9	6130-11-1410	• PLUG	9	SN: 11007-UP
10	6130-11-1420	• PLUG	4	SN: 11007-UP
11	6100-21-1130	• PLUG	2	SN: 11007-UP
12	6130-11-1451	• NOZZLE, WATER	8	SN: 11007-UP
12A	01140-61045	• STUD	8	SN: 11007-UP
13	6130-41-4131	• VALVE, INTAKE	4	SN: 11007-UP
14	6130-41-4210	• VALVE, EXHAUST	4	SN: 11007-UP
15	6130-41-4410	• SPRING, VALVE	8	SN: 11007-UP
16	6130-41-4511	• GUIDE, SPRING	8	SN: 22569-UP
16	6130-41-4510	• □ GUIDE, SPRING	8	SN: 11007-22568
17	6130-41-4520	• COTTER, VALVE	16	SN: 11007-UP
18	6130-41-4541	• SEAL, VALVE STEM (K1)	8	SN: 11007-UP
19	6130-41-4610	• COIL	8	SN: 11007-UP
20	6131-11-1811	GASKET (K1)	1	SN: ..-UP
20	6131-11-1810	□ GASKET	1	SN: 20060-..
20	6130-11-1814	□ GASKET	1	SN: .-20059
20	6130-11-1813	□ GASKET	1	SN: 11007-..
21	6130-11-1611	BOLT	10	SN: 15926-UP
21	6130-11-1610	□ BOLT	10	SN: 11007-15925

Item	Part No.	Part Name	Qty	Options
22	6130-11-1913	HANGA	1	SN: 11007-UP
23	01010-31025	BOLT	2	SN: 11007-UP
24	01602-01030	WASHER, SPRING	2	SN: 11007-UP

Catalog signs: ☆ not supplied separately: assembly only ☐ part above may be used instead

Reference: 101

ロ ッ カ アーム 組立 ハウジング
FIG. 103 ROCKER ARM AND HOUSING




Reference: 103

030020 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
	6130-11-7101	HOUSING ASSEMBLY, ROCKER ARM	1	SN: .-UP
	6130-11-7100	□ HOUSING ASSEMBLY, ROCKER ARM	1	SN: 11007-.
1		• ☆ HOUSING	1	SN: 11007-UP
2	6130-11-7120	• PLUG	1	SN: 11007-UP
3	6130-11-7150	• PLUG	1	SN: 11007-.
4	07005-02216	• GASKET	1	SN: 11007-.
5	6130-11-8410	• PLATE	1	SN: 11007-UP
6	6130-11-8420	• GASKET (K1)	1	SN: 11007-UP
7	01010-30820	• BOLT	4	SN: 11007-UP
8	01602-00825	• WASHER, SPRING	4	SN: 11007-UP
	6130-41-5200	ROCKER ARM SHAFT ASSEMBLY	1	SN: 11007-UP
	6130-41-5020	• SHAFT ASSEMBLY, ROCKER ARM	1	SN: 11007-UP
9	6130-41-5211	• • SHAFT	1	SN: 11007-UP
10	6130-41-5550	• • PLUG	2	SN: 11007-UP
11	6130-41-5540	• PLATE	2	SN: 11007-UP
12	04066-00020	• RING, SNAP	2	SN: 11007-UP
13	6130-41-5110	• BRACKET	1	SN: 11007-UP
14	6130-41-5120	• BRACKET	3	SN: 11007-UP
15	01010-30612	• BOLT	1	SN: 11007-UP
16	01602-00619	• WASHER, SPRING	1	SN: 11007-UP
17	6130-41-5320	• SPRING	2	SN: 11007-UP
18	6130-41-5330	• SPRING	1	SN: 11007-UP
19	6130-41-5510	• ARM, ROCKER, INTAKE	4	SN: 11007-UP
20	6130-41-5410	• ARM, ROCKER, EXHAUST	4	SN: 11007-UP
21	6130-41-5442	• SCREW, ADJUST	8	SN: 11007-UP
22	6130-41-5430	• NAT	8	SN: 11007-UP
23	01010-31230	BOLT	4	SN: 11007-UP
24	01602-01236	WASHER, SPRING	4	SN: 12151-UP
24	01650-11212	WASHER, LOCK	4	SN: 11007-12150
25	6130-11-7810	GASKET (K1)	1	SN: 11007-UP
26	01010-30885	BOLT	15	SN: 11007-UP
27	01602-00825	WASHER, SPRING	15	SN: 11007-UP
28	01643-00823	WASHER	15	SN: 11007-UP

Catalog signs: □ part above may be used instead ☆ not supplied separately: assembly only

ロ ッ カ アームハウジング カバ ー
FIG. 105 ROCKER ARM HOUSING COVER



Reference: 105


030030 ROCKER ARM HOUSING COVER

Item	Part No.	Part Name	Qty	Options
1	6130-11-8121	COVER	1	SN: 13782-UP
1	6130-11-8120	COVER	1	SN: 11007-13781
2	6130-11-8811	GASKET (K1)	1	SN: 11007-UP
3	01010-30822	BOLT	10	SN: 11007-UP
4	01602-00825	WASHER, SPRING	10	SN: 11007-UP
5	01640-20816	WASHER	10	SN: 11007-UP
6	6130-11-8913	BREATHER ASSEMBLY	1	SN: 20060-UP
6	6130-11-8912	☐ BREATHER ASSEMBLY	1	SN: 13782-20059
6	6130-11-8911	BREATHER ASSEMBLY	1	SN: 11007-13781
7	6130-11-8920	O RING	1	SN: 13782-UP
7	6110-21-7810	GASKET (K1)	1	SN: 11007-13781
8	01010-31025	BOLT	2	SN: 11007-UP
9	01602-01030	WASHER, SPRING	2	SN: 11007-UP
10	01640-21016	WASHER	2	SN: 11007-UP
17	6130-11-8961	PIPE, BREATHER	1	SN: 11007-UP
18	6130-11-8970	HOSE	1	SN: 11007-UP
19	07280-03223	CLAMP	2	SN: 11007-UP
20	6130-11-8980	CLAMP	1	SN: 11007-UP

Catalog signs: ☐ part above may be used instead

Reference: 105

コンプレッションリリース
FIG. 107 COMPRESSION RELEASE



Reference: 107


030040 COMPRESSION RELEASE

Item	Part No.	Part Name	Qty	Options
1	6130-41-8111	SHAFT	1	SN: 11007-UP
2	07000-02012	O RING (K1)	1	SN: 11007-UP
3	6130-41-8210	LEVER	1	SN: 11007-UP
4	01010-30825	BOLT	1	SN: 11007-UP
5	01602-00825	WASHER, SPRING	1	SN: 11007-UP
6	6130-41-8230	SCREW, ADJUST	1	SN: 11007-UP
7	01580-00605	NUT, LOCK	1	SN: 11007-UP
8	6130-41-8320	BOLT	1	SN: 11007-UP
9	01602-00825	WASHER, SPRING	1	SN: 11007-UP
10	6130-41-8220	SPRING, RETURN	1	SN: 11007-UP
11	01010-30820	BOLT	1	SN: 11007-UP
12	01602-00825	WASHER, SPRING	1	SN: 11007-UP
13	01640-20816	WASHER	2	SN: 11007-UP
14	6130-41-5141	BOLT	1	SN: 11007-UP
15	07005-00612	GASKET (K1)	1	SN: .-UP
15	01641-01068	☐ WASHER	1	SN: 11007-.

Catalog signs: ☐ part above may be used instead

Reference: 107

エア-インテーク コネクション および エアークリーナ
FIG. 111 AIR INTAKE CONNECTION AND AIR CLEANER



Reference: 111

030050 AIR INTAKE CONNECTION AND AIR CLEANER


Item	Part No.	Part Name	Qty	Options
1	6130-11-4221	CONNECTOR, AIR INTAKE	1	SN: 12677-UP
1	6130-11-4220	■ CONNECTOR, AIR INTAKE (6130-11-4221,6130-81-4513)	1	SN: 11007-12676
2	6130-11-4811	GASKET (K1)	1	SN: 11007-UP
3	01010-30825	BOLT	4	SN: 11007-UP
4	01602-00825	WASHER, SPRING	4	SN: 11007-UP
5	01640-20816	WASHER	4	SN: 11007-UP
6	6130-11-4321	BRACKET	1	SN: 11007-UP
7	01010-30822	BOLT	5	SN: 11007-UP
8	01602-00825	WASHER, SPRING	5	SN: 11007-UP
9	6130-81-7201	AIR CLEANER ASSEMBLY	1	SN: 11007-UP
	6130-81-7211	• BODY	1	SN: 11007-UP
	6141-81-7030	• ELEMENT ASSEMBLY	1	SN: 11007-UP
10	600-181-7310	•• ELEMENT, INNER	1	SN: 11007-UP
11	600-181-7210	•• ELEMENT, OUTER	1	SN: 11007-UP
11A	600-181-7440	•• GASKET	1	SN: 11007-UP
12	600-181-7511	•• WASHER	1	SN: 11007-UP
13	600-181-7620	• NUT,WING	1	SN: 11007-UP
	600-181-7120	• COVER ASSEMBLY	1	SN: 11007-UP
14	600-181-7130	•• COVER	1	SN: 11007-UP
15	600-181-7410	•• GASKET	1	SN: 11007-UP
16	04064-01510	•• RING, SNAP	1	SN: 11007-UP
17	600-181-7610	• NUT,WING	1	SN: 11007-UP
17A	600-181-7511	• WASHER	1	SN: 11007-UP
	6110-83-9100	PULLEY CLEANER ASSEMBLY	1	SN: 11007-UP
18	6110-83-9110	• BODY	1	SN: 11007-UP
18A	6110-83-9120	• SLEEVE	1	SN: 11007-UP
18B	6110-83-9130	• COVER	1	SN: 11007-UP
19	6141-11-4510	BAND	1	SN: 11007-UP
20	6110-23-6520	BOLT	1	SN: .-UP
20	6110-21-6520	□ BOLT	1	SN: 11007-.
21	6110-21-6530	PIN	1	SN: 11007-UP
22	6110-21-6540	PIN, WITH THREAD	1	SN: 11007-UP
23	6110-11-4430	GASKET (K1)	1	SN: 11007-UP

Item	Part No.	Part Name	Qty	Options
24	01580-00806	NAT	6	SN: 11007-UP
25	01602-00825	WASHER, SPRING	6	SN: 11007-UP
26	01640-20816	WASHER	6	SN: 11007-UP
27	600-181-7710	PLATE, CAUTION, (JAPANESE)	1	SN: 11007-UP
28	600-181-7720	PLATE, CUSHION, (ENGLISH)	1	SN: 11007-UP

Catalog signs: ☒ may be used instead of described part ☐ part above may be used instead

Reference: 111

エキゾーストマニホールドおよびマフラー
FIG. 121 EXHAUST MANIFOLD AND MUFFLER



Reference: 121


030060 EXHAUST MANIFOLD AND MUFFLER

Item	Part No.	Part Name	Qty	Options
	6130-11-5010	EXHAUST MANIFOLD ASSEMBLY	1	SN: 11007-UP
1	6130-11-5110	• MANIFOLD, EXHAUST	1	SN: 11007-UP
2	01140-61030	• STUD	4	SN: 11007-UP
3	01140-61045	STUD	8	SN: 11007-UP
4	6110-11-1190	NAT	8	SN: 11007-UP
5	6130-11-5210	GASKET (K1)	1	SN: 11007-UP
6	6130-11-5540	MUFFLER	1	SN: 20013-UP
6	6130-11-5520	MUFFLER	1	SN: 11007-20012
7	6110-11-1190	NAT	4	SN: 11007-UP
7	01583-21006	☒ NAT	4	SN: (11007-11483)
8	6110-11-1190	NAT	4	SN: 11007-UP
8	01582-21008	☒ NAT	4	SN: (11007-11483)
9	6130-11-5810	GASKET (K1)	4	SN: 11007-UP
10	01010-31020	BOLT	2	SN: 11007-UP
11	01602-01030	WASHER, SPRING	2	SN: 11007-UP
12	6130-11-5361	PIPE, EXHAUST	1	SN: .-UP
12	6130-11-5360	☐ PIPE, EXHAUST	1	SN: 20013-.
12	6130-11-5320	PIPE, EXHAUST	1	SN: 11007-20012
13	6130-11-5910	CLAMP	1	SN: 11007-UP
14	01050-31285	BOLT	1	SN: 11007-UP
15	01582-21210	NUT, LOCK	1	SN: 11007-UP
16	01583-21207	NAT	1	SN: 11007-UP
17	01640-21223	WASHER	2	SN: 11007-UP

Catalog signs: ☒ discontinued: use part above ☐ part above may be used instead

Reference: 121

ウォーターパイプおよびサーモスタート
FIG. 131 WATER PIPE AND THERMOSTAT



Reference: 131

030070 WATER PIPE AND THERMOSTAT

Item	Part No.	Part Name	Qty	Options
	6130-11-6013	THERMOSTAT CASE ASSEMBLY	1	SN: 13062-UP
	6130-11-6011	THERMOSTAT CASE ASSEMBLY	1	SN: 11007-13061
1	6130-11-6413	• CASE	1	SN: 13062-UP
1	6130-11-6411	• CASE	1	SN: 11007-13061
2	6003500-2-10	• VALVE, AIR	1	SN: 11007-UP
3	07042-00415	• PLUG	1	SN: 11007-UP
4	6130-11-6810	GASKET (K1)	1	SN: 11007-UP
5	6110-13-6310	THERMOSTAT	1	SN: 11007-UP
6	01010-30835	BOLT	3	SN: 11106-UP
6	01010-30840	BOLT	3	SN: 11007-11105
7	01602-00825	WASHER, SPRING	3	SN: 11007-UP
8	6130-11-6511	PIPE, WATER OUTLET	1	SN: 13062-UP
8	6130-11-6520	PIPE, WATER OUTLET	1	SN: 11007-13061
9	07042-00108	PLUG	1	SN: 11007-UP
10	6110-13-6451	GASKET (K1)	1	SN: 11007-UP
10	6110-13-6450	☒ GASKET	1	SN: (11007-12678)
11	01010-30822	BOLT	3	SN: 11007-UP
12	01602-00825	WASHER, SPRING	3	SN: 11007-UP
13	6130-11-6212	PLATE	1	SN: 14382-UP
13	6130-11-6211	☐ PLATE	1	SN: 11007-14381
14	6130-11-6310	GASKET (K1)	1	SN: 11007-UP
15	01010-30822	BOLT	6	SN: 11007-UP
16	01602-00825	WASHER, SPRING	6	SN: 11007-UP
17	01640-20816	WASHER	6	SN: 11007-.

Catalog signs: ☒ discontinued: use part above ☐ part above may be used instead

Reference: 131

Get the complete PDF catalogue

Komatsu 4D105-1A (JPN) S/N 11007-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.