


FIG. 101 CYLINDER HEAD



Reference: 101

030010 CYLINDER HEAD


Item	Part No.	Part Name	Qty	Options
	6141-11-1010	CYLINDER HEAD ASSEMBLY	1	SN: 41958-UP
	6141-11-1103	• CYLINDER HEAD ASSEMBLY	1	SN: 41958-UP
1		• ☆ HEAD	1	SN: 41958-UP
2	6140-11-1123	• TUBE	1	SN: 41958-UP
3	6140-11-1132	• SLEEVE	4	SN: 41958-UP
4	6140-11-1140	• PIPE	4	SN: 41958-UP
5	6140-11-1150	• PLUG	4	SN: 41958-UP
6	6140-11-1160	• PLUG	15	SN: 41958-UP
7	6140-11-1170	• PLUG	1	SN: 41958-UP
8	6140-19-1310	• GUIDE	8	SN: 41958-UP
9	01140-61045	• STUD	8	SN: 41958-UP
10	6110-11-1190	• NAT	8	SN: 41958-UP
11	01100-30845	• STUD	8	SN: 41958-UP
12	01580-00806	• NAT	8	SN: 41958-UP
13	01602-00825	• WASHER	8	SN: 41958-UP
14	6140-41-4111	• VALVE, INTAKE	4	SN: 41958-UP
15	6140-41-4211	• VALVE, EXHAUST	4	SN: 41958-UP
16	6140-41-4410	• SPRING	8	SN: 41958-UP
17	6140-41-4511	• SEAT	8	SN: 41958-UP
18	6140-41-4520	• COTTER	16	SN: 41958-UP
19	6140-41-4530	• ROTATOR	8	SN: 41958-UP
20	6140-41-4540	• SEAL (K1)	8	SN: 41958-UP
21	6141-11-1813	GASKET (K1)	1	SN: .-UP
21	6141-11-1812	□ GASKET	1	SN: 41958-.
22	6142-11-1610	BOLT	17	SN: 55593-UP
22	6140-11-1611	□ BOLT	17	SN: 41958-55592
23	6140-11-1620	WASHER	17	SN: 41958-55592
24	04530-01222	BOLT	2	SN: 41958-UP
25	6140-11-1510	SHIM	4	SN: 41958-UP
	6141-11-8107	COVER ASSEMBLY	1	SN: .-UP
	6141-11-8106	□ COVER ASSEMBLY	1	SN: 41958-.
26		• ☆ COVER	1	SN: 41958-UP
27	04020-00820	• PIN	1	SN: 41958-UP
28	6141-11-8213	• TUBE	1	SN: .-UP
28	6141-11-8212	• □ TUBE	1	SN: 41958-.
29	6141-11-8221	• PLATE	1	SN: 41958-UP
30	01010-30614	• BOLT	2	SN: 41958-UP
31	01602-00619	• WASHER	2	SN: 41958-UP
32	6141-11-8811	GASKET (K1)	1	SN: 41958-UP
33	01252-30835	BOLT	10	SN: 41958-UP
34	01641-20812	WASHER	10	SN: 41958-UP
35	01602-00825	WASHER	10	SN: 41958-UP
	6140-11-3103	NOZZLE HOLDER ASSEMBLY, (SEE FIG.421)	4	SN: 41958-UP
36	6140-11-3112	• HOLDA	1	SN: 41958-UP
36A	6140-11-3150	• BOLT	1	SN: 41958-UP
36B	DK150639-4200	• NAT	1	SN: 41958-UP
37	6140-11-3132	• NOZZLE	1	SN: 41958-UP

Item	Part No.	Part Name	Qty	Options
38	6127-11-3160	• GASKET (K1)	2	SN: 41958-UP
39	6140-11-3240	PACKING (K1)	4	SN: 41958-UP
40	6141-14-8120	PLUG	1	SN: 41958-UP
41	04064-01510	LINK	1	SN: 41958-UP
42	07000-02011	O RING	1	SN: 41958-UP

Catalog signs: ☆ not supplied separately; assembly only ☐ part above may be used instead

Reference: 101

ロッカ アーム および デコンプ シャフト
FIG. 104 ROCKER ARM AND DECOMP SHAFT



Reference: 104


030020 ROCKER ARM AND DECOMP SHAFT

Item	Part No.	Part Name	Qty	Options
	6141-41-5020	ROCKER ARM SHAFT ASSEMBLY	1	SN: 41958-UP
1	6141-41-5210	• SHAFT	1	SN: 41958-UP
2	6130-41-5550	• PLUG	2	SN: 41958-UP
	6140-41-5500	ROCKER ARM ASSEMBLY	8	SN: 47820-UP
	6140-41-5403	ROCKER ARM ASSEMBLY	8	SN: 41958-47819
3		• ☆ ARM	1	SN: 47820-UP
3		• ☆ ARM	1	SN: 41958-47819
4		• ☆ BUSH	1	SN: 41958-UP
5	6140-41-5241	BOLT	1	SN: 41958-UP
6	01602-00825	WASHER	1	SN: 41958-UP
7	6140-41-5111	BRACKET	1	SN: 41958-UP
8	6141-41-5220	BRACKET	2	SN: 47820-UP
8	6141-41-5120	BRACKET	2	SN: 41958-47819
9	6141-41-5230	BRACKET	1	SN: 47820-UP
9	6141-41-5130	BRACKET	1	SN: 41958-47819
10	6140-41-5111	BRACKET	1	SN: 47820-UP
10	6141-41-5151	BRACKET	1	SN: 41958-47819
11	01010-31075	BOLT	5	SN: 41958-UP
12	01602-01030	WASHER	5	SN: 41958-UP
13	6140-41-5444	BOLT	8	SN: 41958-UP
14	01580-00806	NAT	8	SN: 41958-UP
15	6140-41-5540	SPACER	4	SN: 41958-UP
16	6140-41-5550	SPACER	1	SN: 41958-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 104

エアークリーナ マニホールド および エアークリーナ
FIG. 115 AIR INTAKE MANIFOLD AND AIR CLEANER



Reference: 115

030030 AIR INTAKE MANIFOLD AND AIR CLEANER


Item	Part No.	Part Name	Qty	Options
1	6141-11-4112	MANIFOLD	1	SN: 41958-UP
2	6141-11-4810	GASKET (K1)	1	SN: 41958-UP
3	01010-30845	BOLT	2	SN: 41958-UP
4	01010-30850	BOLT	4	SN: 41958-UP
5	01010-30865	BOLT	2	SN: 41958-UP
6	01010-30890	BOLT	2	SN: 41958-UP
7	01602-00825	WASHER	10	SN: 41958-UP
8	01641-20812	WASHER	6	SN: 41958-UP
	6141-11-4020	CONNECTOR ASSEMBLY	1	SN: 41958-UP
9	6141-11-4121	• CONNECTOR	1	SN: 41958-UP
10	6141-11-8231	• TUBE	1	SN: 41958-UP
11	6110-11-4430	GASKET (K1)	1	SN: 41958-UP
12	6141-11-4821	GASKET (K1)	1	SN: 41958-UP
13	01010-31030	BOLT	3	SN: 41958-UP
14	01602-01030	WASHER	3	SN: 41958-UP
15	01641-21016	WASHER	3	SN: 41958-UP
16	6141-11-4280	HOSE	1	SN: 41958-UP
17	07280-02523	CLAMP	1	SN: 41958-UP
18	6141-11-4612	BRACKET	1	SN: 41958-UP
19	01010-31020	BOLT	2	SN: 41958-UP
20	01602-01030	WASHER	2	SN: 41958-UP
21	6141-11-4510	BAND	1	SN: 41958-UP
22	6110-21-6530	PIN	1	SN: 41958-UP
23	6110-21-6540	PIN, WITH THREAD	1	SN: 41958-UP
24	6110-23-6520	BOLT	1	SN: 41958-UP
	6141-85-7301	AIR CLEANER ASSEMBLY	1	SN: 41958-UP
25	6141-85-7331	• BODY	1	SN: 41958-UP
	6141-81-7043	• ELEMENT ASSEMBLY	1	SN: .-UP
	6141-81-7042	• □ ELEMENT ASSEMBLY	1	SN: 41958-.
26	600-181-8221	•• ELEMENT	1	SN: 41958-UP
	600-181-2390	•• WASHER ASSEMBLY	2	SN: .-UP
27		••• ☆ WASHER	1	SN: .-UP
27		••• ☆ WASHER	1	SN: 41958-.
27A		••• ☆ NAT	1	SN: .-UP

Item	Part No.	Part Name	Qty	Options
28		••• ☆ NAT	1	SN: 41958-.
29	600-181-8630	• GUIDE	1	SN: 41958-UP
30	600-181-8032	• COVER	1	SN: 41958-UP
31	600-181-8420	• GASKET	1	SN: 41958-UP
32	6131-81-7121	• COVER	1	SN: 41958-UP
33	6141-85-7311	CAP	1	SN: 41958-UP
34	01580-00806	NAT	6	SN: 41958-UP
35	01602-00825	WASHER	6	SN: 41958-UP
36	01641-20812	WASHER	6	SN: 41958-UP

Catalog signs: ☐ part above may be used instead ☆ not supplied separately: assembly only

Reference: 115

エキゾースト マニホールド および マフラー
FIG. 124 EXHAUST MANIFOLD AND MUFFLER




Reference: 124

030040 EXHAUST MANIFOLD AND MUFFLER

Item	Part No.	Part Name	Qty	Options
	6141-11-5010	MANIFOLD ASSEMBLY	1	SN: 41958-UP
1	6141-11-5111	• MANIFOLD	1	SN: 41958-UP
2	01140-61030	• STUD	4	SN: 41958-UP
3	6110-11-1190	NAT	4	SN: 41958-UP
4	6140-11-5810	GASKET (K1)	4	SN: 41958-UP
5	6141-11-5340	BRACKET	1	SN: 41958-UP
6	01050-31020	BOLT	2	SN: 41958-UP
7	01602-01030	WASHER	2	SN: 41958-UP
8	01010-31020	BOLT	2	SN: 41958-UP
9	01602-01030	WASHER	2	SN: 41958-UP
10	6141-11-5712	MUFFLER	1	SN: 41958-UP
11	6141-11-5740	CLAMP	1	SN: 41958-UP
12	6141-15-5710	PIPE	1	SN: 41958-UP
13	01050-31070	BOLT	1	SN: 41958-UP
14	01640-21016	WASHER	2	SN: 41958-UP
15	01580-21008	NAT	2	SN: 41958-UP
16	6130-11-5210	GASKET (K1)	1	SN: 41958-UP
17	6110-11-1190	NUT, (SEE FIG.101)	8	SN: 41958-UP
18	M720170804331	BELLOWS, (FOR STATIONARY USE)	1	SN: 41958-UP
19	M710040343411	COVER, (FOR LOW TEMPERATURE)	1	SN: 41958-UP
20	M720040304340	BAND, (FOR LOW TEMPERATURE)	2	SN: 41958-UP
21	M018010800306	BOLT, (FOR STATIONARY USE)	4	SN: 41958-UP
22	M018200800006	NUT, (FOR LOW NOISE)	4	SN: 41958-UP
23	M011600800006	WASHER, (FOR LOW TEMPERATURE)	4	SN: 41958-UP
24	6141-15-5510	MUFFLER, (FOR LOW NOISE)	1	SN: 41958-UP
25	M800919008202	BOLT, (FOR STATIONARY USE)	4	SN: 41958-UP
26	M710040343420	WIRE, (FOR LOW TEMPERATURE)	1	SN: 41958-UP

Reference: 124

FIG. 202 CYLINDER BLOCK



Reference: 202

060010 CYLINDER BLOCK


Item	Part No.	Part Name	Qty	Options
	6141-25-1030	CYLINDER BLOCK ASSEMBLY	1	SN: 41958-UP
	6141-25-1300	• CYLINDER BLOCK ASSEMBLY	1	SN: 41958-UP
1		• ☆ BLOCK	1	SN: 41958-UP
2	6100-21-1130	• PLUG	7	SN: 41958-UP
3	6140-21-1140	• PLUG	2	SN: 41958-UP
4	6140-21-3121	• PIN	1	SN: 41958-UP
5	04020-01024	• PIN	1	SN: 41958-UP
6	04020-01228	• PIN	2	SN: 41958-UP
7	04025-00512	• PIN	1	SN: .-UP
7	04020-00514	• □ PIN	1	SN: 41958-
8	6141-21-5150	• PIN	2	SN: 41958-UP
9	04020-00820	• PIN	4	SN: 41958-UP
10	6140-21-1130	• BUSH	2	SN: 41958-UP
11	04025-00412	• PIN	1	SN: 41958-UP
13	07213-50610	• CONNECTOR	1	SN: 41958-UP
14	6140-61-6512	• VALVE	1	SN: 41958-UP
15	6140-21-1811	• INSERT	1	SN: 41958-UP
16	6140-51-6330	• O RING (K2)	1	SN: 41958-UP
17	6140-21-1410	• BUSH	3	SN: 41958-UP
19	6141-25-1440	• BUSH	2	SN: 41958-UP
20	6140-21-1210	• △ CAP	4	SN: 41958-UP
21	6141-21-1230	• △ CAP	1	SN: 41958-UP
22	6141-21-1530	• LINK	2	SN: 41958-UP
23	6142-21-1610	• BOLT	10	SN: 55593-UP
23	6140-21-1711	• □ BOLT	10	SN: 41958-55592
24	6140-11-1620	• WASHER	10	SN: 41958-55592
25	6140-21-2211	• LINER	4	SN: 41958-UP
26	6140-21-2220	• O RING (K2)	4	SN: 41958-UP
27	6140-21-2230	• O RING (K2)	4	SN: 41958-UP
28	6141-21-2412	SHAFT	1	SN: 41958-UP
29	6141-21-2421	PLATE	1	SN: 41958-UP
30	01010-31265	BOLT	1	SN: 41958-UP
31	01602-01236	WASHER	1	SN: 41958-UP
32	6141-25-3611	FILLA	1	SN: 41958-UP
33	07025-00050	CAP	1	SN: 41958-UP
34	6110-61-6831	GASKET (K2)	1	SN: 41958-UP
35	01010-31025	BOLT	2	SN: 41958-UP
36	01602-01030	WASHER	2	SN: 41958-UP
37	7700-82-1570	ADAPTER	1	SN: 41958-UP
38	6141-81-5122	GEAR	1	SN: 41958-UP
39	6140-81-5142	SUPPORT	1	SN: 41958-UP
40	6140-81-5150	O RING (K2)	1	SN: 41958-UP
41	07000-01009	O RING (K2)	1	SN: 41958-UP
42	01014-30818	BOLT	2	SN: 41958-UP
43	01602-00825	WASHER	2	SN: 41958-UP
44	09605-01000	PLATE, NAME, (ENGLISH) (LIMITED SUPPLY PART)	1	SN: 41958-UP
45	04418-02550	SCREW	4	SN: 41958-UP

Item	Part No.	Part Name	Qty	Options
46	6141-25-3811	FLANGE	1	SN: 41958-UP
47	6141-61-6830	GASKET (K2)	1	SN: 41958-UP
48	01010-30820	BOLT	2	SN: 41958-UP
49	01602-00825	WASHER	2	SN: 41958-UP
50	600-815-1281	SWITCH, THERMO	1	SN: 41958-UP
51	600-815-1940	SWITCH, PRESSURE	1	SN: .-UP
51	600-815-1261	 SWITCH, PRESSURE	1	SN: 41958-.
54	6141-25-3511	PLATE	2	SN: 41958-UP
55	01010-31230	BOLT	2	SN: 41958-UP
56	01602-01236	WASHER	2	SN: 41958-UP
57	08073-00510	SWITCH, PRESSURE	1	SN: 41958-UP
	6141-31-6101	IDLER GEAR ASSEMBLY	1	SN: 41958-UP
58		•  GEAR	1	SN: 41958-UP
59	6141-31-6220	• BUSH	1	SN: 41958-UP
60	6141-31-6260	BEARING	1	SN: 41958-UP

Catalog signs:  not supplied separately: assembly only  part above may be used instead  semi-finished: additional work required

Reference: 202

フロント カバー および プレート
FIG. 212 FRONT COVER AND PLATE




Reference: 212

060020 FRONT COVER AND PLATE

Item	Part No.	Part Name	Qty	Options
1	6141-21-3213	PLATE	1	SN: 41958-UP
2	6141-21-3231	GASKET (K2)	1	SN: 41958-UP
3	01010-30820	BOLT	2	SN: 41958-UP
4	01602-00825	WASHER	2	SN: 41958-UP
	6141-25-3010	COVER ASSEMBLY	1	SN: 41958-UP
5	6141-21-3113	• COVER	1	SN: 41958-UP
6	6141-21-3150	• POINTER	1	SN: 41958-UP
7	6141-21-3261	GASKET (K2)	1	SN: 41958-UP
8	01010-30895	BOLT	2	SN: 41958-UP
9	01010-30875	BOLT	7	SN: 41958-UP
10	01010-30855	BOLT	1	SN: 41958-UP
11	01580-00806	NAT	2	SN: 41958-UP
12	01602-00825	WASHER	10	SN: 41958-UP
13	6141-21-3611	COVER	1	SN: 41958-UP
14	07000-02135	O RING (K2)	1	SN: 41958-UP
15	01010-30820	BOLT	2	SN: 41958-UP
16	01010-30865	BOLT	1	SN: 41958-UP
17	01602-00825	WASHER	3	SN: 41958-UP
18	01641-20812	WASHER	3	SN: 41958-UP
19	01010-30830	BOLT, (SEE FIG.402)	4	SN: 41958-UP
20	01010-30818	BOLT, (SEE FIG.402)	2	SN: 41958-UP
21	01602-00825	WASHER, (SEE FIG.402)	6	SN: 41958-UP
22	6140-21-3520	SEAL, FRONT (K2)	1	SN: 41958-UP
23	6141-25-3730	SUPPORT	2	SN: 41958-UP
24	01010-31045	BOLT	6	SN: 41958-UP
25	01010-31050	BOLT	2	SN: 41958-UP
26	01602-01030	WASHER	8	SN: 41958-UP

Reference: 212

FIG. 216 OIL PAN
オイルパン



Reference: 216

060030 OIL PAN

Item	Part No.	Part Name	Qty	Options
1	6141-22-5111	PAN	1	SN: 41958-UP
2	6141-21-5811	GASKET (K2)	1	SN: 41958-UP
3	01010-30818	BOLT	14	SN: .-UP
3	01010-30820	BOLT	14	SN: 41958-.
4	01010-30845	BOLT	3	SN: 41958-UP
5	01010-30816	BOLT	3	SN: .-UP
5	01010-30814	BOLT	3	SN: 41958-.
6	01602-00825	WASHER	20	SN: 41958-UP
7	01640-20816	WASHER	17	SN: 41958-UP
8	6141-25-5310	GUIDE	1	SN: 41958-UP
9	6141-21-5312	GAUGE	1	SN: 41958-UP
10	6141-21-5830	GASKET (K2)	1	SN: 41958-UP
11	01010-31030	BOLT	2	SN: 41958-UP
12	01602-01030	WASHER	2	SN: 41958-UP
13	01580-01008	NAT	2	SN: 41958-UP
14	6141-25-5320	CLAMP	1	SN: 41958-UP
15	6141-21-5350	CLAMP	1	SN: 41958-UP
16	01010-30820	BOLT	1	SN: 41958-UP
17	01642-20810	WASHER	2	SN: 41958-UP
18	01602-00825	WASHER	1	SN: 41958-UP
19	01580-00806	NAT	1	SN: 41958-UP
20	6144-21-5190	PLUG, (TRANSPORT PARTS)	1	SN: .-UP
20	07044-12412	□ PLUG, (TRANSPORT PARTS)	1	SN: 41958-.
21	07000-03022	O RING (K2)	1	SN: 41958-UP

Catalog signs: □ part above may be used instead

Reference: 216

Get the complete PDF catalogue

Komatsu 4D92-1H (JPN) S/N 41958-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.