





Reference: 0101

030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6204-12-1200	CYLINDER HEAD ASS'Y, VALVE LESS	1	SN: 11437-UP
1		☆ HEAD, CYLINDER	1	SN: 11437-UP
2	6204-19-1310	• GUIDE, VALVE	8	SN: 11437-UP
3	6204-11-1440	• SEAT, EXHAUST VALVE (STD)	4	SN: 11437-UP
	6204-19-1440	• SEAT ? 0.25MM, EXHAUST VALVE (OS)	4	SN: 11437-UP
	6204-18-1440	• SEAT ? 0.50MM, EXHAUST VALVE (OS)	4	SN: 11437-UP
4	07046-41008	• PLUG	4	SN: 11437-UP
5	07046-41810	• PLUG	5	SN: 11437-UP
6	07046-42216	• PLUG	3	SN: 11437-UP
7	07046-42516	• PLUG	12	SN: 11437-UP
8	02720-40104	• PLUG	1	SN: 11437-UP
9	6204-11-8910	• PIPE, BREATHER	2	SN: 11437-UP
10	6207-41-4110	VALVE, INTAKE	4	SN: 41242-UP
	6204-41-4110	◆ VALVE, INTAKE	4	SN: 11437-41241
11	6204-41-4210	VALVE, EXHAUST	4	SN: 11437-UP
12	6204-41-4510	SEAT, SPRING	8	SN: 11437-UP
13	6204-41-4520	COTTER	16	SN: 11437-UP
14	6204-41-4431	SPRING, VALVE	8	SN: 11437-UP
15	6204-41-4540	SEAL, VALVE (K1)	8	SN: 60008-UP
	6204-41-4540	SEAL, VALVE (K1)	4	SN: 11437-60007
16	6206-11-1930	HANGER, FRONT (W/O CORROSION RESISTOR)	1	SN: 11437-UP
	6204-61-8111	BRACKET, FRONT (WITH CORROSION RESISTOR)	1	SN: .-UP
	6204-61-8110	□ BRACKET, FRONT (WITH CORROSION RESISTOR)	1	SN: 11437-.
17	6206-11-1920	HANGER, REAR	1	SN: 11437-UP
18	01435-01020	BOLT	4	SN: 11437-UP
19	6202-12-1812	GASKET, HEAD (K1)	1	SN: 60011-UP
	6202-12-1811	□ GASKET, HEAD (K1)	1	SN: 38735-60010
	6202-12-1810	□ GASKET, HEAD (K1)	1	SN: 11437-38734
20	6204-13-1610	BOLT	17	SN: 41242-UP
	6142-11-1611	□ BOLT	17	SN: 11437-41241
21	6204-12-2110	PLUG, HOT	4	SN: 11437-UP

Catalog signs: ☆ not supplied separately: assembly only ◆ interchangeable with part above □ part above may be used instead



PE30139


Reference: 0111

030020 ROCKER ARM

Item	Part No.	Part Name	Qty	Options
1	6204-41-5110	BRACKET	1	SN: 11437-UP
2	6204-41-5120	BRACKET	3	SN: 11437-UP
	6202-43-5200	SHAFT ASS'Y	1	SN: 60008-UP
	6204-41-5200	■ SHAFT ASS'Y (6202-43-5200{6221-41-5310})	1	SN: 11437-60007
3		• ☆ SHAFT	1	SN: 60008-UP
		• ☆ SHAFT	1	SN: 11437-60007
4	6221-41-5540	• PLUG	2	SN: 60008-UP
	6142-42-5550	• PLUG	2	SN: 11437-60007
5	6221-41-5310	BOLT	1	SN: 60008-UP
	01010-30612	BOLT	1	SN: 11437-60007
6	6202-43-5410	ARM,ROCKER	8	SN: 60008-UP
	6204-41-5410	ARM,ROCKER	8	SN: 11437-60007
7	6221-41-5410	SCREW,ADJUST	8	SN: 60008-UP
	6204-41-5420	SCREW,ADJUST	8	SN: 11437-60007
8	6221-41-5420	NUT	8	SN: 60008-UP
	6130-41-5430	NUT	8	SN: 11437-60007
9	6202-43-5320	SPRING	3	SN: 60008-UP
	6142-42-5320	SPRING	3	SN: 11437-60007
10	6221-41-5520	SPRING	2	SN: 60008-UP
	6136-41-5320	SPRING	2	SN: 11437-60007
11	6136-41-5330	CLIP	2	SN: 11437-UP
12	01435-00865	BOLT	5	SN: 11437-UP
13	6204-41-5710	BOLT	3	SN: 11437-UP

Catalog signs: ■ may be used instead of described part ☆ not supplied separately: assembly only

Reference: 0111




PE36915

Reference: 0116

030030 CYLINDER HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6204-11-8210	HEAD COVER ASS'Y	1	SN: 36216-UP
1	6204-11-8220	• COVER,HEAD	1	SN: 36216-UP
2	6204-11-8230	• TUBE	1	SN: 36216-UP
3	6130-12-8620	HOSE	1	SN: 36216-UP
4	6130-12-8630	PIPE	1	SN: 36216-UP
5	07281-00609	CLAMP	2	SN: 36216-UP
6	6130-12-8610	CAP	1	SN: 36216-UP
7	6204-11-8810	O-RING (K1)	1	SN: 36216-UP
8	6136-11-8120	NUT	3	SN: 36216-UP
9	6136-11-8130	WASHER	3	SN: 36216-UP
10	6136-11-8142	PACKING (K1)	3	SN: 36216-UP
11	6204-81-2810	PLATE ? CAUTION,(JAPANESE)	1	SN: 68146-UP
	6204-81-2820	PLATE ? CAUTION,(ENGLISH)	1	SN: 36216-UP
	6204-81-2830	PLATE ? CAUTION,(SPANISH)	1	SN: 36216-UP
	6204-81-2840	PLATE ? CAUTION,(GERMAN)	1	SN: 36216-UP
	6204-81-2850	PLATE ? CAUTION,(FRENCH)	1	SN: 36216-UP
	6204-81-2860	PLATE ? CAUTION,(ARABIC)	1	SN: 36216-UP
	6204-81-2870	PLATE ? CAUTION,(RUSSIAN)	1	SN: 36216-UP
	6204-81-2880	PLATE ? CAUTION,(CHINESE)	1	SN: 36216-UP
	6204-81-2890	PLATE ? CAUTION,(PORTUGUESE)	1	SN: 36216-UP
	6204-81-2910	PLATE ? CAUTION,(ITALIAN)	1	SN: 36216-UP
	6204-81-2920	PLATE ? CAUTION,(INDONESIAN)	1	SN: 36216-UP
	6204-81-2930	PLATE ? CAUTION,(POLISH)	1	SN: 36216-UP
	6204-81-2940	PLATE ? CAUTION,(CZECH)	1	SN: 36216-UP
	6204-81-2950	PLATE ? CAUTION,(GREEK)	1	SN: 36216-UP
	6204-81-2960	PLATE ? CAUTION,(SWEDISH)	1	SN: 36216-UP
	6204-81-2970	PLATE ? CAUTION,(TURKISH)	1	SN: 36216-UP
	6204-81-2980	PLATE ? CAUTION,(PERSIAN)	1	SN: 36216-UP

Reference: 0116




PJ36916

Reference: 0132

030040 AIR INTAKE MANIFOLD AND CONNECTION (SINGLE ELEMENT TYPE)

Item	Part No.	Part Name	Qty	Options
	6204-11-4120	INTAKE MANIFOLD A.	1	SN: 36216-UP
1	6204-11-4130	• MANIFOLD,AIR INTAKE	1	SN: 36216-UP
2	6204-11-4140	• PLATE	1	SN: 36216-UP
3	01435-00812	• BOLT	4	SN: 36216-UP
4	01435-21075	BOLT	8	SN: 36216-UP
5	6204-12-4240	CONNECTOR,AIR	1	SN: 36216-UP
6	02720-20204	PLUG	1	SN: 36216-UP
7	6136-11-4820	GASKET (K1)	1	SN: 36216-UP
8	01435-21025	BOLT	4	SN: 36216-UP
9	09920-00150	LIQUID GASKET,LG-7 ? 150G	-2	SN: 36216-UP

Reference: 0132




Reference: 0142

030050 AIR CLEANER (SINGLE ELEMENT TYPE)

Item	Part No.	Part Name	Qty	Options
1	6204-81-7810	BODY	1	SN: 36216-UP
	600-181-6340	ELEMENT ASS'Y	1	SN: 36216-UP
2		• ☆ ELEMENT	1	SN: 36216-UP
3	600-181-7920	• NUT,WING	1	SN: 36216-UP
4	600-181-7511	• WASHER,SEAL	1	SN: 36216-UP
5	04064-01510	• RING,SNAP	1	SN: 36216-UP
6	600-181-9890	VALVE	1	SN: 36216-UP
7	07281-01589	CLAMP	2	SN: 36216-UP
8	6204-81-7530	BRACKET	1	SN: 36216-UP
9	01435-21020	BOLT	2	SN: 36216-UP
10	6204-12-4310	HOSE	1	SN: 36216-UP
11	07281-00809	CLAMP	2	SN: 36216-UP
12	09637-01661	PLATE ? INSTRUCTION,(JAPANESE)	1	SN: 36216-UP
	09637-30661	PLATE ? INSTRUCTION,(ENGLISH)	1	SN: 36216-UP
	09637-40662	PLATE ? INSTRUCTION,(RUSSIAN)	1	SN: 36216-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0142




Reference: 0152

030060 EXHAUST MANIFOLD AND MUFFLER

Item	Part No.	Part Name	Qty	Options
1	6204-11-5130	MANIFOLD,EXHAUST	1	SN: 36216-UP
2	6205-11-5810	GASKET (K1)	1	SN: 76132-UP
	6204-11-5810	◆ GASKET (K1)	1	SN: 36216-76131
3	01435-01045	BOLT	7	SN: 36216-UP
4	01435-01095	BOLT	1	SN: 36216-UP
5	6134-11-5120	SPACER	1	SN: 36216-UP
6	6130-12-5580	GASKET (K1)	1	SN: 36216-UP
7	01140-61025	STUD	4	SN: 36216-UP
8	6142-12-5850	NUT	4	SN: 36216-UP
9	6204-11-5221	MUFFLER	1	SN: 36216-UP

Catalog signs: ◆ interchangeable with part above

Reference: 0152



Reference: 0202


060010 CYLINDER BLOCK

Item	Part No.	Part Name	Qty	Options
	6204-21-1102	CYLINDER BLOCK ASS'Y	1	SN: 52380-UP
	6204-21-1101	■ CYLINDER BLOCK ASS'Y (6204-21-1102{6204-51-1211})	1	SN: 36216-52379
1		• ☆ BLOCK,CYLINDER	1	SN: 52380-UP
		• ☆ BLOCK,CYLINDER	1	SN: 36216-52379
2	6204-21-1410	• BUSHING,CAMSHAFT	1	SN: 36216-UP
3	6206-21-1420	• BUSHING,CAMSHAFT	2	SN: 36216-UP
4	6204-29-1210	• △ CAP,MAIN METAL ? NO.1 ?2 ?3 ?4	4	SN: 36216-UP
5	6204-29-1220	• △ CAP,MAIN METAL ? NO.5	1	SN: 36216-UP
6	6141-21-1530	• RING,DOWEL	2	SN: 36216-UP
7	04025-00408	• PIN,SPRING	6	SN: 36216-UP
8	6204-21-1610	• BOLT,MAIN CAP	10	SN: 36216-UP
9	6204-51-1711	• BUSHING,OIL PUMP	1	SN: 52380-UP
	6204-51-1710	• □ BUSHING,OIL PUMP	1	SN: 36216-52379
10	6204-51-1620	• SHAFT,OIL PUMP	1	SN: 36216-UP
11	07046-21810	• PLUG	4	SN: 36216-UP
12	04020-00820	• PIN,DOWEL	2	SN: 36216-UP
13	6136-52-1620	• PIN	1	SN: 47846-UP
14	07046-42216	• PLUG	1	SN: 36216-UP
15	04020-01228	• PIN,DOWEL	2	SN: 36216-UP
16	07046-43016	• PLUG	7	SN: 52380-UP
	07046-43016	• PLUG	6	SN: 36216-52379
17	07046-42516	• PLUG	5	SN: 52380-UP
	07046-42516	• PLUG	4	SN: 36216-52379
18	07042-10312	• PLUG	1	SN: 36216-UP
19	07043-50108	• PLUG	6	SN: 36216-UP
20	6140-21-1130	• BUSHING,DOWEL	2	SN: 36216-UP
21	07046-44016	PLUG	1	SN: 36216-UP
22	07046-23016	PLUG	1	SN: 36216-UP
23	6204-21-6710	PLATE	1	SN: 36216-UP
24	6132-11-4820	GASKET (K2)	1	SN: 36216-UP
25	01435-20814	BOLT	2	SN: 36216-UP
26	08073-00505	SWITCH	1	SN: 36216-UP
27	6204-21-5510	GUIDE,BASE	1	SN: 36216-UP
28	6150-21-5930	NUT	1	SN: 36216-UP
29	6150-21-5920	COLLAR	1	SN: 36216-UP
30	6204-21-5430	GUIDE,OIL GAUGE	1	SN: 36216-UP
31	6204-21-5330	GAUGE,OIL	1	SN: 36216-UP
32	6144-21-5650	CLIP	1	SN: 36216-UP
33	6689-12-5950	STAY	1	SN: 36216-UP
34	01435-20820	BOLT	1	SN: 36216-UP
35	01584-00806	NUT	1	SN: 36216-UP
36	07046-42216	PLUG	1	SN: 36216-UP
37	07046-41410	PLUG	1	SN: 36216-UP
38	6204-81-2210	PLATE ? NAME,(LIMITED SUPPLY)	1	SN: 36216-UP
	6204-81-2370	PLATE ? NAME,(ARABIC)	1	SN: 36216-UP
39	6207-21-2110	LINER (MARK A),CYLINDER	-2	SN: 36216-UP

Item	Part No.	Part Name	Qty	Options
	6207-21-2120	LINER (MARK B),CYLINDER	-2	SN: 36216-UP

Catalog signs: ■ may be used instead of described part ☆ not supplied separately: assembly only Δ semi-finished: additional work required □ part above may be used instead

Reference: 0202



Reference: 0205

060020 FRONT COVER AND GEAR (FOR 25A NON HARDENING PULLEY ALTERNATOR)

Item	Part No.	Part Name	Qty	Options
1	6204-21-3211	PLATE,FRONT	1	SN: 11437-UP
2	6206-21-3830	GASKET (K2)	1	SN: 34802-UP
	6204-21-3811	◆ GASKET (K2)	1	SN: 11437-34801
3	01435-20816	BOLT	2	SN: 11437-UP
4	6204-21-3112	COVER,FRONT	1	SN: 60008-UP
	6204-21-3111	□ COVER,FRONT	1	SN: 11437-60007
5	6204-21-3850	POINTER	1	SN: 11437-UP
6	01435-20855	BOLT	11	SN: 11437-UP
7	01435-20860	BOLT	2	SN: 11437-UP
8	01435-20870	BOLT	2	SN: 11437-UP
9	6204-21-3311	COVER	1	SN: 11437-UP
10	6204-21-3451	GROMMET (K2)	1	SN: 11437-UP
11	6204-21-3460	GROMMET (K2)	6	SN: 11437-UP
12	6204-21-3410	PACKING (K2)	1	SN: 11437-UP
13	01435-20620	BOLT	6	SN: 11437-UP
14	6204-21-3480	SPACER	6	SN: 11437-UP
15	6204-21-3510	SEAL ? FRONT (K2)	1	SN: 11437-UP
	6206-31-6301	IDLER GEAR ASS'Y	1	SN: 27509-UP
	6204-31-6300	■ IDLER GEAR ASS'Y (6206-31-6301{6204-31-6331})	1	SN: 11437-27508
16		• ☆ GEAR,IDLER	1	SN: 27509-UP
		• ☆ GEAR,IDLER	1	SN: 11437-27508
17	6204-31-6341	• BUSHING	1	SN: 27509-UP
	6204-31-6340	• BUSHING	1	SN: 11437-27508
18	6204-31-6331	SHAFT	1	SN: 27509-UP
	6204-31-6330	SHAFT	1	SN: 11437-27508

Get the complete PDF catalogue

Komatsu 4D95L-W-1E S/N 11437-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.