




PE38113

Reference: 0101


030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6206-11-1100	CYLINDER HEAD ASS'Y, VALVE LESS	1	SN: 10001-UP
1		• ☆ HEAD, CYLINDER	1	SN: 10001-UP
2	6204-19-1310	• GUIDE, VALVE	12	SN: 10001-UP
3	6204-11-1440	• SEAT, EXHAUST VALVE (STD)	6	SN: 10001-UP
	6204-19-1440	• SEAT ? 0.25MM, EXHAUST VALVE (OS)	6	SN: 10001-UP
	6204-18-1440	• SEAT ? 0.50MM, EXHAUST VALVE (OS)	6	SN: 10001-UP
4	07046-41008	• PLUG	6	SN: 10001-UP
5	07046-41810	• PLUG	13	SN: 10001-UP
6	07046-42216	• PLUG	5	SN: 10001-UP
7	07046-42516	• PLUG	15	SN: 10001-UP
8	02720-40104	• PLUG	1	SN: 10001-UP
9	6204-11-8910	• PIPE, BREATHER	3	SN: 10001-UP
10	6207-41-4110	VALVE, INTAKE	6	SN: 46742-UP
	6204-41-4110	◆ VALVE, INTAKE	6	SN: 10001-46741
11	6204-41-4210	VALVE, EXHAUST	6	SN: 10001-UP
12	6204-41-4510	SEAT, SPRING	12	SN: 10001-UP
13	6204-41-4520	COTTER	24	SN: 10001-UP
14	6204-41-4550	CAP, VALVE STEM	12	SN: 77218-UP
15	6204-41-4431	SPRING, VALVE	12	SN: 10001-UP
16	6204-41-4540	SEAL, VALVE (K1)	12	SN: 55961-UP
	6204-41-4540	SEAL, VALVE (K1)	6	SN: 10001-55960
17	6207-11-1430	SEAT, INTAKE VALVE (SERVICE PARTS) (STD)	6	SN: 10001-UP
	6207-19-1430	SEAT ? 0.25MM, INTAKE VALVE (SERVICE PARTS) (OS)	6	SN: 10001-UP
	6207-18-1430	SEAT ? 0.50MM, INTAKE VALVE (SERVICE PARTS) (OS)	6	SN: 10001-UP
18	6206-11-1930	HANGER, FRONT	1	SN: 10001-UP
19	6206-11-1960	HANGER, REAR	1	SN: 43220-UP
	6206-11-1910	HANGER, REAR	1	SN: 10001-43219
20	01435-01020	BOLT	4	SN: 10001-UP
21	6206-11-1812	GASKET, HEAD (K1)	1	SN: 59763-UP
	6206-11-1811	□ GASKET, HEAD	1	SN: 45128-59762
	6206-11-1810	□ GASKET, HEAD (K1)	1	SN: 10001-45127
22	6204-13-1610	BOLT	25	SN: 46742-UP

Item	Part No.	Part Name	Qty	Options
23	6142-11-1611	☐ BOLT	25	SN: 10001-46741
	01643-51232	WASHER	25	SN: 77218-UP
	01643-31232	☐ WASHER	25	SN: 46742-77217

Catalog signs: ☆ not supplied separately: assembly only ◆ interchangeable with part above ☐ part above may be used instead

Reference: 0101



PE80001


Reference: 0111

030020 ROCKER ARM

Item	Part No.	Part Name	Qty	Options
1	6204-41-5110	BRACKET	1	SN: 10001-UP
2	6204-41-5120	BRACKET	5	SN: 10001-UP
	6206-41-5201	SHAFT ASS'Y	1	SN: 55963-UP
	6206-41-5200	■ SHAFT ASS'Y (6206-41-5201{6221-41-5310})	1	SN: 10001-55962
3		• ☆ SHAFT	1	SN: 55963-UP
		• ☆ SHAFT	1	SN: 10001-55962
4	6221-41-5540	• PLUG	2	SN: 55963-UP
	6142-42-5550	• PLUG	2	SN: 10001-55962
5	6221-41-5310	BOLT	1	SN: 55963-UP
	01010-30612	BOLT	1	SN: 10001-55962
6	6202-43-5410	ARM,ROCKER	12	SN: 55963-UP
	6204-41-5410	◆ ARM,ROCKER	12	SN: 10001-55962
7	6221-41-5410	SCREW,ADJUST	12	SN: 55963-UP
	6204-41-5420	◆ SCREW,ADJUST	12	SN: 10001-55962
8	6221-41-5420	NUT	12	SN: 55963-UP
	6130-41-5430	◆ NUT	12	SN: 10001-55962
9	6202-43-5320	SPRING	5	SN: 55963-UP
	6142-42-5320	◆ SPRING	5	SN: 10001-55962
10	6221-41-5520	SPRING	2	SN: 55963-UP
	6136-41-5320	◆ SPRING	2	SN: 10001-55962
11	6136-41-5330	CLIP	2	SN: 10001-UP
12	01435-00865	BOLT	8	SN: 10001-UP
13	6204-41-5710	BOLT	4	SN: 10001-UP

Catalog signs: ■ may be used instead of described part ☆ not supplied separately: assembly only ◆ interchangeable with part above

Reference: 0111




Reference: 0115

030030 CYLINDER HEAD COVER

Item	Part No.	Part Name	Qty	Options
1	6206-11-8510	COVER,HEAD	1	SN: 66443-UP
	6206-11-8110	◆ COVER,HEAD	1	SN: 10001-66442
2	6206-11-8810	O-RING (K1)	1	SN: 10001-UP
3	6136-11-8120	NUT	4	SN: 10001-UP
4	6136-11-8130	WASHER	4	SN: 10001-UP
5	6136-11-8142	PACKING (K1)	4	SN: 10001-UP
6	6130-12-8610	CAP	1	SN: 10001-UP
7	6204-81-2210	PLATE ? NAME,(ENGLISH)	1	SN: 63885-UP
	6206-81-2110	PLATE ? NAME,(ENGLISH)	1	SN: 30279-63884
	6204-81-2260	PLATE ? NAME,(GERMAN)	1	SN: 63885-UP
	6206-81-2160	PLATE ? NAME,(GERMAN)	1	SN: 30279-63884
	6204-81-2340	PLATE ? NAME,(CHINESE)	1	SN: 63885-UP
	6206-81-2240	PLATE ? NAME,(CHINESE)	1	SN: 30279-63884
	6204-81-2350	PLATE ? NAME,(SWEDISH)	1	SN: 63885-UP
	6206-81-2260	PLATE ? NAME,(SWEDISH)	1	SN: 30279-63884
	6204-81-2810	PLATE ? CAUTION,(JAPANESE)	1	SN: 10001-UP
	6204-81-2820	PLATE ? CAUTION,(ENGLISH)	1	SN: 10001-UP
8	6204-81-2840	PLATE ? CAUTION,(GERMAN)	1	SN: 10001-UP
	6204-81-2880	PLATE ? CAUTION,(CHINESE)	1	SN: 10001-UP
	6204-81-2960	PLATE ? CAUTION,(SWEDISH)	1	SN: 10001-UP

Catalog signs: ◆ interchangeable with part above

Reference: 0115




PG30004

Reference: 0131

030040 AIR INTAKE MANIFOLD AND CONNECTION(#10001-43219)

Item	Part No.	Part Name	Qty	Options
1	6206-11-4110	MANIFOLD,AIR INTAKE	1	SN: 10001-43219
2	01435-21030	BOLT	11	SN: 10001-43219
3	01435-21085	BOLT	1	SN: 10001-43219
4	600-815-2341	HEATER,RIBBON	1	SN: 10001-@
5	6206-11-4250	CONNECTOR,AIR	1	SN: 10001-@
6	6136-11-4820	GASKET (K1)	2	SN: 10001-@
7	01435-21070	BOLT	4	SN: 10001-@
8	08670-01635	INDICATOR,DUST (JAPANESE-ENGLISH)	1	SN: 10001-@
	08670-20635	INDICATOR,DUST (ENGLISH-GERMAN)	1	SN: 10001-@
	08670-30640	INDICATOR,DUST (CHINESE)	1	SN: 10001-@
9	6137-81-9140	PLATE ? CAUTION,(SWEDISH)	1	SN: 10001-@
10	6137-81-9150	PLATE ? CAUTION,(SWEDISH)	1	SN: 10001-@
11	6206-81-5510	BRACKET	1	SN: 10001-@
12	01435-21020	BOLT	2	SN: 10001-@
	01435-21025	BOLT,(WITH CORROSION RESISTOR)	2	SN: 10001-@
13	600-815-2170	SWITCH,HEATER	1	SN: 10001-@
14	01435-20612	BOLT	2	SN: 10001-@
15	6206-81-4720	WIRE ? 480MM	1	SN: 10001-@
16	6206-81-4730	WIRE ? 380MM	1	SN: 10001-@
17	08036-10814	CLIP	1	SN: 10001-@
18	6131-12-5920	SPACER	1	SN: 10001-@
19	01435-21025	BOLT	1	SN: 10001-@
20	08038-00519	CAP	3	SN: 10001-@
21	09920-00150	LIQUID GASKET,LG-7 ? 150G	-2	SN: 10001-@

Reference: 0131



PG36674


Reference: 0131A

030050 AIR INTAKE MANIFOLD AND CONNECTION(#43220-)

Item	Part No.	Part Name	Qty	Options
	6206-11-4170	INTAKE MANIFOLD A.	1	SN: 43220-UP
1	6206-11-4140	• MANIFOLD,AIR INTAKE	1	SN: 43220-UP
2	6206-11-4150	• PLATE	2	SN: 43220-UP
3	6206-11-4160	• BOLT	12	SN: 43220-UP
4	01435-21030	BOLT	10	SN: 43220-UP
5	01435-21085	BOLT	2	SN: 43220-UP
6	600-815-2341	HEATER,RIBBON	1	SN: 10001-UP
7	6206-11-4250	CONNECTOR,AIR	1	SN: 10001-UP
8	6136-11-4820	GASKET (K1)	2	SN: 10001-UP
9	01435-21070	BOLT	4	SN: 10001-UP
10	08670-02001	INDICATOR,DUST (JAPANESE-ENGLISH)	1	SN: 70384-UP
	08670-01635	□ INDICATOR,DUST (JAPANESE-ENGLISH)	1	SN: 10001-70383
	08670-20635	INDICATOR,DUST (ENGLISH-GERMAN)	1	SN: 10001-70383
	08670-30640	INDICATOR,DUST (CHINESE)	1	SN: 10001-70383
11	6137-81-9140	PLATE ? CAUTION,(SWEDISH)	1	SN: 10001-70383
12	6137-81-9150	PLATE ? CAUTION,(SWEDISH)	1	SN: 10001-70383
13	6206-81-5510	BRACKET	1	SN: 10001-UP
14	01435-21020	BOLT	2	SN: 10001-UP
	01435-21025	BOLT,(WITH CORROSION RESISTOR)	2	SN: 10001-UP
15	600-815-2170	SWITCH,HEATER	1	SN: 10001-UP
16	01435-20612	BOLT	2	SN: 10001-UP
17	6206-81-4720	WIRE ? 480MM	1	SN: 10001-UP
18	6206-81-4730	WIRE ? 380MM	1	SN: 10001-UP
19	08036-10814	CLIP	1	SN: 10001-UP
20	6131-12-5920	SPACER	1	SN: 10001-UP
21	01435-21025	BOLT	1	SN: 10001-UP
22	08038-00519	CAP	3	SN: 10001-UP
23	09920-00150	LIQUID GASKET,LG-7 ? 150G	-2	SN: 10001-UP

Catalog signs: ☐ part above may be used instead

Reference: 0131A



PJ30758


Reference: 0141

030060 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
1	6130-82-7401	AIR CLEANER ASS'Y	1	SN: 10001-UP
	6130-82-7411	• BODY	1	SN: 10001-UP
	600-181-9500	• ELEMENT ASS'Y	1	SN: 10001-UP
2		• ☆ ELEMENT, INNER	1	SN: 10001-UP
3	600-181-9631	• NUT	1	SN: 10001-UP
4	600-181-7511	• WASHER, SEAL	1	SN: 10001-UP
	600-181-9200	• ELEMENT ASS'Y, OUTER	1	SN: 10001-UP
5		• ☆ ELEMENT, OUTER	1	SN: 10001-UP
6	600-181-8640	• NUT, WING	1	SN: 10001-UP
7	600-181-7511	• WASHER, SEAL	1	SN: 10001-UP
8	04064-01510	• RING, SNAP	1	SN: 10001-UP
9	600-181-9551	• DIVIDER	1	SN: 10001-UP
10	600-181-9430	• GASKET	1	SN: 10001-UP
11	600-181-9541	• PAN, DUST	1	SN: 10001-UP
12	600-181-7680	• VALVE	1	SN: 10001-UP
13	6131-11-4510	BAND	2	SN: 10001-UP
	6110-21-6530	PIN	2	SN: 10001-UP
	6110-21-6540	PIN ? WITH THREAD	2	SN: 10001-UP
14	6110-23-6520	BOLT	2	SN: 10001-UP
15	09637-30161	PLATE ? INSTRUCTION, (ENGLISH)	1	SN: 10001-UP
	09637-81161	PLATE ? INSTRUCTION, (GERMAN)	1	SN: 10001-UP
	09637-90261	PLATE ? INSTRUCTION, (CHINESE)	1	SN: 10001-UP
	205-00-75260	PLATE ? CAUTION, (SWEDISH)	1	SN: 10001-UP
16	6206-81-8850	PLATE ? NAME, (TBG SPEC.)	1	SN: 10001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 0141




Reference: 0151

030070 EXHAUST MANIFOLD AND MUFFLER

Item	Part No.	Part Name	Qty	Options
1	6206-11-5110	MANIFOLD,EXHAUST	1	SN: 10001-UP
2	6207-11-5810	GASKET (K1)	2	SN: 66441-UP
	6206-11-5811	GASKET	2	SN: 45128-66440
	6206-11-5811	GASKET (K1)	2	SN: 14141-45127
	6207-11-5810	◆ GASKET (K1)	2	SN: 10001-14140
3	01435-01045	BOLT	11	SN: 33691-UP
	01435-01090	BOLT	11	SN: 10001-33690
4	01435-01095	BOLT	1	SN: 10001-UP
5	6134-11-5120	SPACER	1	SN: 33691-UP
	6134-11-5120	SPACER	12	SN: 10001-33690
6	6206-11-5610	PIPE	1	SN: 10001-UP
7	6130-12-5580	GASKET (K1)	1	SN: 10001-UP
8	01140-61025	STUD	4	SN: 10001-UP
9	6142-12-5850	NUT	4	SN: 10001-UP
10	6206-11-5510	BRACKET	1	SN: 10001-UP
11	01435-01025	BOLT	4	SN: 10001-UP
12	6206-11-5210	MUFFLER	1	SN: 10001-UP
13	6206-11-5960	U-BOLT	2	SN: 10001-UP
14	01584-00806	NUT	4	SN: 10001-UP
15	6206-11-5910	CLAMP	1	SN: 10001-UP
16	01435-01235	BOLT	2	SN: 10139-UP
	01435-01030	BOLT	2	SN: 10001-10138
17	6206-11-5850	PLATE	1	SN: 66445-UP
	01584-01210	□ NUT	2	SN: 10139-66444
	01584-01008	NUT	2	SN: 10001-10138
18	6206-11-5730	PIPE,EXHAUST	1	SN: 10001-UP
	6206-11-5781	PIPE,EXHAUST (REGULATION OF SWEDEN)	1	SN: 22790-UP
	6206-11-5780	PIPE,EXHAUST (REGULATION OF SWEDEN)	1	SN: 10001-22789
19	6206-11-5920	CLAMP	1	SN: 10001-UP
20	01010-31080	BOLT	1	SN: 10001-UP
21	01580-21008	NUT	2	SN: 10001-UP
22	01640-21016	WASHER	2	SN: 10001-UP

Catalog signs: ◆ interchangeable with part above □ part above may be used instead



Reference: 0201

060010 CYLINDER BLOCK

Item	Part No.	Part Name	Qty	Options
	6206-21-1102	CYLINDER BLOCK ASS'Y	1	SN: 48444-UP
	6206-21-1101	■ CYLINDER BLOCK ASS'Y (6206-21-1102{6206-51-1201})	1	SN: 10034-48443
1	6206-21-1100	CYLINDER BLOCK ASS'Y	1	SN: 10001-10033
		• ☆ BLOCK,CYLINDER	1	SN: 10034-UP
		• ☆ BLOCK,CYLINDER	1	SN: 10001-10033
2	6204-21-1410	• BUSHING,CAMSHAFT	1	SN: 10001-UP
3	6206-21-1420	• BUSHING,CAMSHAFT	3	SN: 10001-UP
4	6204-29-1210	• △ CAP,MAIN METAL ? NO.1 ?2 ?3 ?4 ?5 ?6	6	SN: 10001-UP
5	6204-29-1220	• △ CAP,MAIN METAL ? NO.7	1	SN: 10001-UP
6	6141-21-1530	• RING,DOWEL	2	SN: 10001-UP
7	04025-00408	• PIN,SPRING	6	SN: 10001-UP
8	6204-21-1610	• BOLT,MAIN CAP	14	SN: 10001-UP
9	6204-51-1711	• BUSHING,OIL PUMP	1	SN: 48444-UP
	6204-51-1710	• □ BUSHING,OIL PUMP	1	SN: 10001-48443
10	6204-51-1620	• SHAFT,OIL PUMP	1	SN: 10001-UP
11	07046-41810	• PLUG	4	SN: 33690-UP
	07046-21810	• □ PLUG	4	SN: 10001-33689
12	04020-00820	• PIN,DOWEL	2	SN: 10001-UP
13	6136-52-1620	• PIN,OIL PUMP	1	SN: 48444-UP
14	07046-42216	• PLUG	1	SN: 10034-UP
	07046-42010	• PLUG	1	SN: 10001-10033
15	04020-01228	• PIN,DOWEL	2	SN: 10001-UP
16	07046-43016	• PLUG	9	SN: 48444-UP
	07046-43016	• PLUG	8	SN: 10034-48443
	07046-43016	• PLUG	7	SN: 10001-10033
17	07046-42516	• PLUG	7	SN: 48444-UP
	07046-42516	• PLUG	6	SN: 10001-48443
18	07042-10312	• PLUG	1	SN: 48444-UP
	07042-00312	• □ PLUG	1	SN: 10001-48443
19	07043-50108	• PLUG	5	SN: 10001-UP
20	07043-50211	• PLUG	1	SN: 10001-UP
21	6140-21-1130	• BUSHING,DOWEL	2	SN: 10001-UP
22	07046-44016	PLUG,(WITHOUT CORROSION RESISTOR)	1	SN: 10001-UP
23	08073-00505	SWITCH	1	SN: 10001-UP
24	6206-21-6710	PLATE	1	SN: 10001-UP
25	6206-21-6810	GASKET (K2)	1	SN: 10001-UP
26	01435-20816	BOLT	4	SN: 10001-UP
27	6204-21-5510	GUIDE,BASE	1	SN: 10001-UP
28	6150-21-5930	NUT	1	SN: 10001-UP
29	6150-21-5920	COLLAR	1	SN: 10001-UP
30	6206-21-5420	GUIDE,OIL GAUGE	1	SN: 10001-UP
31	6206-21-5321	GAUGE,OIL	1	SN: 10139-UP
	6206-21-5320	GAUGE,OIL	1	SN: 10001-10138
32	6136-71-5730	BRACKET	1	SN: 10001-UP
33	6206-21-5510	CLIP	1	SN: 10001-UP
34	01435-20816	BOLT	1	SN: 10001-UP

Get the complete PDF catalogue

Komatsu 6D95L-1C S/N 10001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.