





Reference: A1010-A0A2

030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6206-11-1400	CYLINDER HEAD ASS'Y, VALVE LESS	1	SN: 96999-UP
1		• ☆ HEAD, CYLINDER	1	SN: 96999-UP
2	6204-19-1310	• GUIDE, VALVE	12	SN: 96999-UP
3	6204-11-1440	• SEAT, EXHAUST VALVE (STD)	6	SN: 96999-UP
	6204-19-1440	• SEAT □ 0.25MM, EXHAUST VALVE (OS)	6	SN: 96999-UP
	6204-18-1440	• SEAT □ 0.50MM, EXHAUST VALVE (OS)	6	SN: 96999-UP
4	07046-41008	• PLUG	6	SN: 96999-UP
5	07046-41810	• PLUG	13	SN: 96999-UP
6	07046-42216	• PLUG	5	SN: 96999-UP
7	07046-42516	• PLUG	15	SN: 96999-UP
8	02720-40104	• PLUG	1	SN: 96999-UP
9	6207-41-4110	VALVE, INTAKE	6	SN: 96999-UP
10	6204-41-4210	VALVE, EXHAUST	6	SN: 96999-UP
11	6204-41-4510	SEAT, SPRING	12	SN: 96999-UP
12	6204-41-4520	COTTER	24	SN: 96999-UP
13	6204-41-4410	SPRING, VALVE	12	SN: 96999-UP
14	6204-41-4550	CAP, VALVE STEM	12	SN: 96999-UP
15	6204-41-4540	SEAL, VALVE (K1)	12	SN: 96999-UP
16	6206-11-1830	GASKET, HEAD (K1)	1	SN: 96999-UP
17	6204-13-1610	BOLT	25	SN: 96999-UP
18	01643-51232	WASHER	25	SN: 96999-UP
19	6207-11-1430	SEAT, INTAKE VALVE (SERVICE PARTS) (STD)	6	SN: 96999-UP
	6207-19-1430	SEAT □ 0.25MM, INTAKE VALVE (SERVICE PARTS) (OS)	6	SN: 96999-UP
	6207-18-1430	SEAT □ 0.50MM, INTAKE VALVE (SERVICE PARTS) (OS)	6	SN: 96999-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: A1010-A0A2




P D 3 8 1 9 8

Reference: A1030-A0A2

030020 FRONT HANGER (FOR 15A ALTERNATOR)

Item	Part No.	Part Name	Qty	Options
1	6206-11-1930	HANGER,FRONT	1	SN: 96999-UP
2	01435-01020	BOLT	2	SN: 96999-UP

Reference: A1030-A0A2




PJ38597

Reference: A1030-A0A3

030030 FRONT HANGER (FOR 13A 25A ALTERNATOR)

Item	Part No.	Part Name	Qty	Options
1	6206-11-1950	HANGER,FRONT	1	SN: 96999-UP
2	01435-01020	BOLT	2	SN: 96999-UP

Reference: A1030-A0A3




PE38199

Reference: A1050-A0A2

030040 REAR HANGER

Item	Part No.	Part Name	Qty	Options
1	6206-11-1960	HANGER,REAR	1	SN: 96999-UP
2	01435-01020	BOLT	2	SN: 96999-UP

Reference: A1050-A0A2




PG38200

Reference: A1110-A0A2

030050 HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6207-11-8500	HEAD COVER ASS'Y	1	SN: 96999-UP
1	6207-11-8510	• COVER,HEAD	1	SN: 96999-UP
2	6207-11-8170	• TUBE	1	SN: 96999-UP
3	6207-11-8140	• PLATE	1	SN: 96999-UP
4	04418-02550	• SCREW	4	SN: 96999-UP
5	6204-11-8230	• TUBE	1	SN: 96999-UP
6	6206-11-8810	O-RING (K1)	1	SN: 96999-UP
7	6136-11-8120	NUT	4	SN: 96999-UP
8	6136-11-8130	WASHER	4	SN: 96999-UP
9	6136-11-8142	PACKING (K1)	4	SN: 96999-UP
10	6130-12-8610	CAP	1	SN: 96999-UP
11	6206-11-8610	HOSE	1	SN: 96999-UP
12	6130-12-8630	PIPE,OIL FILLER	1	SN: 96999-UP
13	07281-00709	CLAMP	2	SN: 96999-UP
14	6207-11-8910	TUBE,BREATHER	1	SN: 96999-UP
15	01435-21020	BOLT	1	SN: 96999-UP
16	07286-01606	HOSE	1	SN: 96999-UP
17	07285-00180	CLIP	3	SN: 96999-UP
18	07286-01670	HOSE	1	SN: 96999-UP

Reference: A1110-A0A2




PJ38201

Reference: A1310-A0A2

030060 AIR INTAKE (FOR 15A ALTERNATOR)

Item	Part No.	Part Name	Qty	Options
	6206-11-4170	INTAKE MANIFOLD A.	1	SN: 96999-UP
1	6206-11-4140	• MANIFOLD,AIR INTAKE	1	SN: 96999-UP
2	6206-11-4150	• PLATE	2	SN: 96999-UP
3	6206-11-4160	• BOLT	12	SN: 96999-UP
4	01435-21085	BOLT	2	SN: 96999-UP
5	01435-21030	BOLT	10	SN: 96999-UP
6	6206-11-4310	CONNECTOR,AIR	1	SN: 96999-UP
7	6136-11-4820	GASKET (K1)	2	SN: 96999-UP
8	600-815-2341	HEATER,RIBBON	1	SN: 96999-UP
9	01435-21070	BOLT	4	SN: 96999-UP
10	01641-21016	WASHER	1	SN: 96999-UP
11	01435-21070	BOLT	2	SN: 96999-UP
12	6136-51-6190	SPACER	2	SN: 96999-UP
13	6144-11-5630	SPACER	2	SN: 96999-UP
14	08089-00000	SWITCH	1	SN: 96999-UP
15	07323-20100	ELBOW	1	SN: 96999-UP
16	09920-00150	LIQUID GASKET,LG-7φ 150G	-2	SN: 96999-UP

Reference: A1310-A0A2




PJ38601

Reference: A1310-A0B2

030070 AIR INTAKE (FOR 13A and 25A ALTERNATOR)

Item	Part No.	Part Name	Qty	Options
	6206-11-4170	INTAKE MANIFOLD A.	1	SN: 96999-UP
1	6206-11-4140	• MANIFOLD,AIR INTAKE	1	SN: 96999-UP
2	6206-11-4150	• PLATE	2	SN: 96999-UP
3	6206-11-4160	• BOLT	12	SN: 96999-UP
4	01435-21085	BOLT	2	SN: 96999-UP
5	01435-21030	BOLT	10	SN: 96999-UP
6	6206-11-4310	CONNECTOR,AIR	1	SN: 96999-UP
7	6136-11-4820	GASKET (K1)	2	SN: 96999-UP
8	600-815-2341	HEATER,RIBBON	1	SN: 96999-UP
9	01435-21070	BOLT	2	SN: 96999-UP
10	01641-21016	WASHER	1	SN: 96999-UP
11	01435-21070	BOLT	2	SN: 96999-UP
12	6136-51-6190	SPACER	1	SN: 96999-UP
13	6144-11-5630	SPACER	1	SN: 96999-UP
14	6132-21-4630	SPACER	1	SN: 96999-UP
15	08089-00000	SWITCH	1	SN: 96999-UP
16	07323-20100	ELBOW	1	SN: 96999-UP
17	09920-00150	LIQUID GASKET,LG-7 and 150G	-2	SN: 96999-UP

Reference: A1310-A0B2




PG38202

Reference: A1370-A0A1

030080 HEATER SWITCH

Item	Part No.	Part Name	Qty	Options
1	6206-81-4720	WIRE□ 480MM	1	SN: 96999-UP
2	6206-81-4730	WIRE□ 380MM	1	SN: 96999-UP
3	08036-10814	CLIP	1	SN: 96999-UP
4	6131-12-5920	SPACER	1	SN: 96999-UP
5	01435-21025	BOLT	1	SN: 96999-UP
6	08038-00519	CAP	3	SN: 96999-UP
7	600-815-2170	SWITCH	1	SN: 96999-UP
8	6206-81-5510	BRACKET	1	SN: 96999-UP
9	01435-20612	BOLT	2	SN: 96999-UP
10	01435-21020	BOLT	2	SN: 96999-UP

Reference: A1370-A0A1



PJ38203


Reference: A1410-A0A1

030090 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
1	6206-83-7700	AIR CLEANER ASS'Y	1	SN: 96999-UP
	6206-81-7610	• BODY	1	SN: 96999-UP
	600-181-9500	• ELEMENT ASS'Y	1	SN: 96999-UP
	600-181-9200	•• ELEMENT ASS'Y, OUTER	1	SN: 96999-UP
2		••• ☆ ELEMENT, OUTER	1	SN: 96999-UP
3	600-181-8640	••• NUT, WING	1	SN: 96999-UP
4	600-181-7511	••• WASHER, SEAL	1	SN: 96999-UP
5	04064-01510	••• RING, SNAP	1	SN: 96999-UP
6		•• ☆ ELEMENT, INNER	1	SN: 96999-UP
7	600-181-9631	•• NUT	1	SN: 96999-UP
8	600-181-7511	•• WASHER, SEAL	1	SN: 96999-UP
9	600-181-9551	• DIVIDER	1	SN: 96999-UP
10	600-181-9430	• GASKET	1	SN: 96999-UP
11	600-181-7680	• VALVE	1	SN: 96999-UP
12	600-181-9541	• PAN, DUST	1	SN: 96999-UP
13	6134-11-4610	BAND	1	SN: 96999-UP
14	6110-23-6520	BOLT	1	SN: 96999-UP
15	6110-21-6530	PIN	1	SN: 96999-UP
16	6110-21-6540	PIN [□] WITH THREAD	1	SN: 96999-UP
17	6110-11-4430	GASKET (K1)	1	SN: 96999-UP
18	01584-00806	NUT	6	SN: 96999-UP
19	6206-81-7790	CAP	1	SN: 96999-UP
20	6206-11-4541	BRACKET	1	SN: 96999-UP
21	01435-21030	BOLT	2	SN: 96999-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: A1410-A0A1



PJ38604

Reference: A1410-A0A9

030100 AIR CLEANER (WITH EXTENSION)

Item	Part No.	Part Name	Qty	Options
1	6134-82-7400	AIR CLEANER ASS'Y	1	SN: 96999-UP
	6134-81-7410	• BODY	1	SN: 96999-UP
	600-181-9500	• ELEMENT ASS'Y	1	SN: 96999-UP
	600-181-9200	•• ELEMENT ASS'Y, OUTER	1	SN: 96999-UP
2		••• ☆ ELEMENT, OUTER	1	SN: 96999-UP
3	600-181-8640	••• NUT, WING	1	SN: 96999-UP
4	600-181-7511	••• WASHER, SEAL	1	SN: 96999-UP
5	04064-01510	••• RING, SNAP	1	SN: 96999-UP
6		•• ☆ ELEMENT, INNER	1	SN: 96999-UP
7	600-181-9631	•• NUT	1	SN: 96999-UP
8	600-181-7511	•• WASHER, SEAL	1	SN: 96999-UP
9	600-181-9551	• DIVIDER	1	SN: 96999-UP
10	600-181-9430	• GASKET	1	SN: 96999-UP
11	600-181-7680	• VALVE	1	SN: 96999-UP
12	6134-81-7440	• PAN, DUST	1	SN: 96999-UP
13	6131-11-4510	BAND	2	SN: 96999-UP
14	6110-23-6520	BOLT	2	SN: 96999-UP
15	6110-21-6530	PIN	2	SN: 96999-UP
16	6110-21-6540	PIN ^α WITH THREAD	2	SN: 96999-UP
17	600-181-9390	CAP	1	SN: 96999-UP
18	6206-81-7390	EXTENSION, EXHAUST	1	SN: 96999-UP
19	07281-00909	CLAMP	2	SN: 96999-UP
20	6134-11-4460	HOSE	1	SN: 96999-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: A1410-A0A9

Get the complete PDF catalogue

Komatsu 6D95L-1AC-P S/N 96999-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.