





P4F9550

Reference: |AA0003

|AA0003 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6271-11-1010	HEAD ASSY	1	
	6271-11-1100	CYLINDER HEAD A., VALVE LESS	1	
1	Ÿo	• HEAD, CYLINDER	1	
2	6204-19-1310	• GUIDE, VALVE	8	
3	6207-11-1431	• SEAT, INTAKE VALVE (STD)	4	
	6207-19-1431	• SEAT, 0.25MM, INTAKE VALVE (OS)	4	
	6207-18-1431	• SEAT, 0.50MM, INTAKE VALVE (OS)	4	
4	6208-11-1440	• SEAT, EXHAUST VALVE (STD)	4	
	6208-19-1440	• SEAT, 0.25MM, EXHAUST VALVE (OS)	4	
	6208-18-1440	• SEAT, 0.50MM, EXHAUST VALVE (OS)	4	
5	07046-41008	• PLUG	4	
6	07046-41810	• PLUG	9	
7	07046-42216	• PLUG	3	
8	07046-42516	• PLUG	11	
9	02720-40104	• PLUG	1	
10	6207-41-4130	VALVE, INTAKE	4	
11	6209-41-4210	VALVE, EXHAUST	4	
12	6204-41-4510	SEAT	8	
13	6204-41-4520	COTTER	16	
14	6204-41-4410	SPRING, VALVE	8	
15	6204-41-4541	SEAL	8	
16	6204-41-4550	CAP	8	
17	6204-11-1840	GASKET	1	
18	6204-13-1610	BOLT	17	

Reference: |AA0003




00091042

Reference: |AA0004

|AA0004 LIFTING BRACKET

Item	Part No.	Part Name	Qty	Options
1	6208-11-1910	HANGER, FRONT	1	
2	01435-01020	BOLT	2	
3	6271-11-1960	HANGER, REAR	1	

Reference: |AA0004




JY013801

Reference: |AA0005

|AA0005 HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6271-11-8200	HEAD COVER ASS'Y	1	
1	6271-11-8210	• COVER, HEAD	1	
2	6207-11-8140	• PLATE	1	
3	04418-02550	• SCREW	4	
4	6204-11-8810	• O-RING	1	
5	6136-11-8120	NUT	3	
6	6136-11-8130	WASHER	3	
7	6136-11-8142	PACKING	3	
8	6271-11-9140	PLATE	1	
9	04418-02550	SCREW	8	

Reference: |AA0005




00091832

Reference: |AA0006

|AA0006 BREATHER

Item	Part No.	Part Name	Qty	Options
1	6150-21-6750	BREATHER	1	
2	6209-11-8210	O-RING	1	
3	6271-11-8970	HOSE	1	
4	07285-00220	CLIP	1	
5	07285-00200	CLIP	1	
6	6271-11-8930	TUBE, BREATHER	1	
7	01435-00814	BOLT	1	
8	07286-01656	HOSE	1	
9	07285-00180	CLIP	1	

Reference: |AA0006




0 0 0 9 1 8 3 9

Reference: |AA0007

|AA0007 AIR INTAKE CONNECTOR

Item	Part No.	Part Name	Qty	Options
1	6271-11-4441	CONNECTOR, AIR	1	
2	6204-11-4850	GASKET	1	

Reference: |AA0007




J Y 0 2 6 4 8 5

Reference: |AA0008

|AA0008 AIR INTAKE HEATER

Item	Part No.	Part Name	Qty	Options
1	6204-11-4850	HEATER, RIBBON	1	
2	6204-11-4850	GASKET	1	

Reference: |AA0008




0 0 0 9 1 8 4 0

Reference: |AA0009

|AA0009 AIR INTAKE CONNECTOR MOUNTING

Item	Part No.	Part Name	Qty	Options
1	01435-01070	BOLT	4	

Reference: |AA0009




JY026340

Reference: |AA0010

|AA0010 EXHAUST MUFFLER MOUNTING

Item	Part No.	Part Name	Qty	Options
1	6205-11-5811	GASKET	1	
2	01435-01045	BOLT	8	

Reference: |AA0010




J Y 0 2 6 3 3 3

Reference: |AA0011

|AA0011 TURBOCHARGER

Item	Part No.	Part Name	Qty	Options
1	6271-81-8500	TURBOCHARGER ASS'Y	1	
2	6205-11-5580	GASKET	1	
3	01124-60825	STUD	4	
4	6201-11-5850	NUT	4	

Reference: |AA0011



JY026386

Reference: |AA0012

|AA0012 EXHAUST MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6271-11-5140	MANIFOLD, EXHAUST	1	
2	07042-20108	PLUG	2	

Reference: |AA0012

Get the complete PDF catalogue

Komatsu SAA4D95LE-5N-W S/N 517769-up

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.