




JY013301

Reference: |A00003

|A00003 CYLINDER HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6271-11-8200	HEAD COVER ASSEMBLY	1	
1	6271-11-8210	• COVER, HEAD	1	
2	6207-11-8140	• PLATE	1	
3	04418-02550	• SCREW	4	
4	6204-11-8810	• O-RING	1	
5	6136-11-8120	NUT	3	
6	6136-11-8130	WASHER	3	
7	6136-11-8142	PACKING	3	
8	6271-11-9120	PLATE	1	
9	04418-02550	SCREW	8	

Reference: |A00003




00058515

Reference: |A00004

|A00004 HEAD COVER ACCESSORY

Item	Part No.	Part Name	Qty	Options
1	6204-11-8610	CAP, OIL FILLER	1	
2	6208-11-8610	HOSE	1	
3	07281-00709	CLAMP	2	
4	6202-13-8631	PIPE	1	

Reference: |A00004




JY013302

Reference: |A00005

|A00005 BREATHER

Item	Part No.	Part Name	Qty	Options
1	6150-21-6750	BREATHER	1	
2	6209-11-8210	O-RING	1	
3	6271-11-8970	HOSE	1	
4	07285-00220	CLIP	1	
5	07285-00200	CLIP, HOSE	1	
6	6271-11-8910	TUBE, BREATHER	1	
7	01435-00814	BOLT	1	
8	07286-01664	HOSE	1	
9	07285-00180	CLIP	1	

Reference: |A00005




Reference: |A00006

|A00006 AIR INTAKE MANIFOLD

Item	Part No.	Part Name	Qty	Options
1	6271-11-4130	MANIFOLD, AIR INTAKE	1	
2	01435-01075	BOLT	6	
3	01435-01065	BOLT	2	
4	09920-00150	LIQUID GASKET, LG-7, 150G	-2	

Reference: |A00006




00058507

Reference: |A00007

|A00007 AIR INTAKE CONNECTOR

Item	Part No.	Part Name	Qty	Options
1	6271-11-4322	CONNECTOR, AIR	1	
2	6204-11-4850	GASKET	1	

Reference: |A00007




00058508

Reference: |A00008

|A00008 AIR INTAKE CONNECTOR MOUNTING

Item	Part No.	Part Name	Qty	Options
1	01435-01070	BOLT	3	
2	01435-01080	BOLT	1	
3	6240-71-6640	BRACKET	1	
4	6132-21-4630	SPACER	1	

Reference: |A00008




00058490

Reference: |A00009

|A00009 AIR INTAKE HEATER

Item	Part No.	Part Name	Qty	Options
1	600-815-9140	HEATER	1	
2	6204-11-4850	GASKET	1	

Reference: |A00009




00019776

Reference: |A00010

|A00010 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
	6271-81-7500	AIR CLEANER	1	
		• BODY	1	
	600-184-1240	• COVER ASSEMBLY	1	
1	600-184-2810	• PLATE	1	
2		•• COVER	1	
3	600-184-1250	•• VALVE, VACUATOR	1	
	600-185-2500	• ELEMENT ASSEMBLY	1	
4	600-185-2510	•• ELEMENT, OUTER	1	
5	600-185-2520	•• ELEMENT, INNER	1	
6	600-184-1280	•• O-RING	1	

Reference: |A00010




00058510

Reference: |A00011

|A00011 AIR TRANSFER CONNECTION

Item	Part No.	Part Name	Qty	Options
1	6208-11-4811	CONNECTOR, AIR	1	
2	6208-11-4850	GASKET	1	
3	01435-00825	BOLT	3	

Reference: |A00011



00058529

Reference: |A00012

|A00012 EXHAUST MANIFOLD MOUNTING

Item	Part No.	Part Name	Qty	Options
1	6205-11-5811	GASKET	1	
2	01435-01045	BOLT	8	

Reference: |A00012

Get the complete PDF catalogue

Komatsu SAA4D95LE-5Q S/N 555215-up

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.