





Reference: A1103-A2A0

## A-001 A1103-A2A0 CYLINDER HEAD

| Item | Part No.     | Part Name                             | Qty | Options |
|------|--------------|---------------------------------------|-----|---------|
|      | 6754-11-1012 | HEAD, CYLINDER                        | 1   |         |
|      | 6754-41-4200 | • KIT, EXHAUST VALVE                  | 12  |         |
| 1    | 6744-11-1020 | • • COLLET, VALVE                     | 2   |         |
| 2    | NSS          | • • VALVE, EXHAUST                    | 1   |         |
|      | 6754-41-4100 | • KIT, INTAKE VALVE                   | 12  |         |
| 3    | 6744-11-1020 | • • COLLET, VALVE                     | 2   |         |
| 4    | NSS          | • • VALVE, INTAKE                     | 1   |         |
| 5    | 6754-41-4540 | • • SEAL, VALVE STEM                  | 1   |         |
| 6    | 6754-41-4540 | • SEAL, VALVE STEM                    | 12  |         |
| 7    | 6754-41-4430 | • SPRING, VALVE                       | 24  |         |
| 8    | 6754-41-4510 | • RETAINER, VALVE SPRING              | 24  |         |
|      | NSS          | • HEAD, CYLINDER                      | 1   |         |
| 9    | 6736-21-1820 | • • PLUG, EXPANSION                   | 13  |         |
| 10   | 6735-21-5530 | • • PLUG, EXPANSION                   | 11  |         |
| 11   | NSS          | • • HEAD, CYLINDER                    | 1   |         |
| 12   | 6754-11-1150 | • • PLUG, EXPANSION                   | 7   |         |
| 13   | 6744-11-1070 | • • PLUG, EXPANSION                   | 2   |         |
| 14   | 6754-11-1160 | • • PLUG, EXPANSION                   | 2   |         |
| 15   | NSS          | • • INSERT, VALVE (STD)               | 12  |         |
| N/I  | 1317 540 H1  | • • INSERT, VALVE (0.127 MM OVERSIZE) | -2  |         |
| N/I  | 1317 541 H1  | • • INSERT, VALVE (0.254 MM OVERSIZE) | -2  |         |
| N/I  | 1317 542 H1  | • • INSERT, VALVE (0.508 MM OVERSIZE) | -2  |         |
| 16   | NSS          | • • INSERT, VALVE (STD)               | 12  |         |
| N/I  | 1317 543 H1  | • • INSERT, VALVE (0.127 MM OVERSIZE) | -2  |         |
| N/I  | 1317 544 H1  | • • INSERT, VALVE (0.254 MM OVERSIZE) | -2  |         |
| N/I  | 1317 545 H1  | • • INSERT, VALVE (0.508 MM OVERSIZE) | -2  |         |
| 17   | 6754-11-1811 | GASKET, CYLINDER HEAD                 | 1   |         |
| 18   | 6754-11-1610 | BOLT                                  | 26  |         |

Reference: A1103-A2A0




Reference: A1109-A2A0

## A-003 A1109-A2A0 ROCKER LEVER

| Item | Part No.     | Part Name                        | Qty | Options |
|------|--------------|----------------------------------|-----|---------|
| 1    | 6754-41-3110 | ROD, PUSH                        | 12  |         |
| 2    | 6754-41-5310 | CROSSHEAD, VALVE                 | 12  |         |
| 3    | 6754-41-5180 | BOLT                             | 12  |         |
|      | 6754-41-5210 | LEVER ASSEMBLY, INTAKE           | 6   |         |
| 4    | NSS          | • LEVER                          | 1   |         |
| 5    | 6754-41-5140 | •• SCREW, ROCKER LEVER ADJUSTING | 1   |         |
| 6    | 6735-41-5550 | •• NUT                           | 1   |         |
|      | 6754-41-5110 | LEVER ASSEMBLY, EXHAUST          | 6   |         |
| 7    | NSS          | • LEVER                          | 1   |         |
| 8    | 6754-41-5140 | •• SCREW, ROCKER LEVER ADJUSTING | 1   |         |
| 9    | 6735-41-5550 | •• NUT                           | 1   |         |
| 10   | 6754-41-5260 | SUPPORT                          | 6   |         |
| 11   | 6754-41-5190 | SHAFT, ROCKER LEVER              | 12  |         |
| 12   | 6754-12-7110 | HOUSING ASSEMBLY, ROCKER LEVER   | 1   |         |
| 13   | NSS          | • SLEEVE                         | 5   |         |
| 14   | 6754-11-7120 | GASKET, ROCKER LEVER HOUSING     | 1   |         |
| 15   | 6736-21-3210 | BOLT (M8-1.25x50)                | 2   |         |
| 16   | 6732-61-6150 | BOLT (M8-1.25x70)                | 5   |         |

Reference: A1109-A2A0




Reference: A1112-A2A0

## A-005 A1112-A2A0 VALVE COVER

| Item | Part No.     | Part Name            | Qty | Options |
|------|--------------|----------------------|-----|---------|
| 1    | 6754-11-8202 | COVER, VALVE         | 1   |         |
|      | 6754-11-8230 | CAP, FILLER          | 1   |         |
| 2    | NSS          | • CAP, FILLER        | 1   |         |
| 3    | 6754-11-8240 | • GASKET, FILLER CAP | 1   |         |
| 4    | 6754-11-8180 | GASKET, VALVE COVER  | 1   |         |
| 5    | 6754-11-8150 | STUD                 | 6   |         |
| 6    | 6754-11-8210 | ISOLATOR, NOISE      | 6   |         |
| 7    | 6754-11-8160 | NUT                  | 6   |         |

Reference: A1112-A2A0




Reference: A1115-A2A0

## A-007 A1115-A2A0 CRANKCASE BREATHER

| Item | Part No.     | Part Name           | Qty | Options |
|------|--------------|---------------------|-----|---------|
| 1    | 6742-01-0700 | SEAL, O-RING        | 1   |         |
| 2    | 6754-21-6180 | CLAMP, SPRING HOSE  | 1   |         |
| 3    | 6754-21-6170 | HOSE, PLAIN         | 1   |         |
| 4    | 6754-21-6140 | BREATHER, CRANKCASE | 1   |         |
| 5    | 6754-21-6280 | BOLT                | 2   |         |
|      | 6754-21-6100 | TUBE, BREATHER      | 1   |         |
| 6    | 6754-21-6240 | • SEAL, O-RING      | 2   |         |
| 7    | NSS          | • TUBE, BREATHER    | 1   |         |
| 8    | 6754-21-6250 | • SEAL, O-RING      | 1   |         |
| 9    | 6754-21-6150 | PLATE, CLAMPING     | 1   |         |
| 10   | 6754-21-6190 | BOLT                | 1   |         |

Reference: A1115-A2A0




Reference: A1120-A2A0

## A-009 A1120-A2A0 TURBOCHARGER OIL PIPING

| Item | Part No.     | Part Name                               | Qty | Options |
|------|--------------|-----------------------------------------|-----|---------|
|      | 6754-51-8200 | TUBE, TURBOCHARGER OIL DRAIN CONNECTION | 1   |         |
| 1    | NSS          | • TUBE, OIL DRAIN CONNECTION            | 1   |         |
| 2    | 6732-51-8330 | • SEAL, O-RING                          | 2   |         |
| 3    | 6731-61-1370 | BOLT                                    | 2   |         |
| 4    | 6754-51-8121 | GASKET, OIL DRAIN                       | 1   |         |
| 5    | 6754-51-8220 | HOSE, FLEXIBLE                          | 1   |         |
|      | 6732-51-8180 | CONNECTOR, MALE                         | 2   |         |
| 6    | 6737-51-8770 | • SEAL, O-RING                          | 1   |         |
| 7    | 6732-81-8850 | • CONNECTOR, MALE                       | 1   |         |
| 8    | 6732-81-8860 | • SEAL, O-RING                          | 1   |         |
| 9    | 6735-21-5530 | PLUG                                    | 1   |         |
| 10   | 6732-11-1920 | PLUG                                    | 1   |         |

Reference: A1120-A2A0




Reference: A1120-A2A1

## A-011 A1120-A2A1 TURBOCHARGER MOUNTING

| Item | Part No.     | Part Name                                | Qty | Options |
|------|--------------|------------------------------------------|-----|---------|
| 1    | 6732-81-8810 | STUD                                     | 4   |         |
| 2    | 6732-81-8820 | NUT                                      | 4   |         |
|      |              | KIT, TURBOCHARGER (SEE FIG. A1203-A2A0 ) |     |         |
| 3    | 6737-51-8770 | • SEAL, O-RING                           | 1   |         |
| 4    | 6754-81-8710 | • GASKET, TURBOCHARGER                   | 1   |         |
| 5    | 6732-81-8860 | • SEAL, O-RING                           | 1   |         |
| 6    | 6754-22-5710 | • GASKET, OIL DRAIN                      | 1   |         |
| 7    | NSS          | • TURBOCHARGER                           | 1   |         |

Reference: A1120-A2A1




Reference: A1203-A2A0

## A-013 A1203-A2A0 TURBOCHARGER

| Item | Part No.     | Part Name                            | Qty | Options |
|------|--------------|--------------------------------------|-----|---------|
|      | 6754-82-8110 | TURBOCHARGER KIT                     | -1  |         |
|      | NSS          | • TURBOCHARGER                       | 1   |         |
| 1    | NSS          | •• BAFFLE TURBOCHARGER NOISE         | 1   |         |
| 2    | 6736-81-8370 | •• BEARING, TURBOCHARGER             | 2   |         |
| 3    | 6731-82-8210 | •• NUT, LOCK                         | 1   |         |
| 4    | 6733-81-8650 | •• WASHER, PLAIN                     | 3   |         |
| 5    | 6736-81-8480 | •• BOLT                              | 2   |         |
| 6    | 6736-81-8430 | •• SHIELD, TURBOCHARGER HEAT         | 1   |         |
| 7    | 6736-81-8280 | •• SHAFT & WHEEL                     | 1   |         |
| 8    | 6733-81-8360 | •• RING, RETAINING                   | 1   |         |
| 9    | 6736-81-8470 | •• DATAPLATE                         | 1   |         |
| 10   | 6733-81-8330 | •• BAFFLE, OIL                       | 1   |         |
| 11   | 6732-81-8140 | •• COUPLING, ELBOW HOSE              | 1   |         |
| 12   | NSS          | •• END, ADJUSTING LINK               | 1   |         |
| 13   | 6743-82-8610 | •• NUT, HEXAGON FLANGE               | 2   |         |
| 14   | 6733-81-8370 | •• RING, RETAINING                   | 1   |         |
| 15   | 6733-81-8460 | •• SEAL, O RING                      | 1   |         |
| 16   | 6733-81-8380 | •• BOLT (M8-1.25x20)                 | 5   |         |
| 17   | 6733-81-8270 | •• PLATE, OIL SEAL                   | 1   |         |
| 18   | 6733-81-8260 | •• SLINGER, OIL                      | 1   |         |
| 19   | NSS          | •• ACTUATOR, TURBOCHARGER            | 1   |         |
| 20   | 6733-81-6850 | •• SPACER, MOUNTING                  | 3   |         |
| 21   | 6735-81-6810 | •• SPACER, MOUNTING                  | 1   |         |
| 22   | 6735-82-8220 | •• BEARING, TURBOCHARGER THRUST      | 1   |         |
| 23   | 6735-81-8620 | •• COLLAR, THRUST                    | 1   |         |
| 24   | 6742-01-5569 | •• BOLT                              | 1   |         |
| 25   | NSS          | •• IMPELLER, TURBOCHARGER COMPRESSOR | 1   |         |
| 26   | 6733-81-8480 | •• PIN, ROLL                         | 1   |         |
| 27   | NSS          | •• HOUSING, TURBOCHARGER BEARING     | 1   |         |
| 28   | 1304 920 H1  | •• PLATE, CLAMPING                   | 2   |         |
| 29   | 6735-81-8370 | •• BOLT                              | 2   |         |
| 30   | 1317 714 H1  | •• HOUSING, TURBINE                  | 1   |         |
| 31   | 6735-81-8310 | •• RING, RETAINING                   | 1   |         |
| 32   | NSS          | •• BRACKET, ACTUATOR                 | 1   |         |

| Item | Part No.     | Part Name              | Qty | Options |
|------|--------------|------------------------|-----|---------|
| 33   | 6733-51-8110 | •• GASKET, ADAPTER     | 1   |         |
| 34   | 6742-01-5564 | •• CLAMP, HOSE         | 2   |         |
| 35   | 6733-81-8320 | •• CONNECTION, ADAPTER | 1   |         |
| 36   | NSS          | •• HOSE, PLAIN         | 1   |         |
| 37   | NSS          | •• HOUSING, COMPRESSOR | 1   |         |
| 38   | 6736-81-8440 | •• SEAL, SPLIT RING    | 1   |         |
| 39   | 6736-81-8320 | •• SEAL, SPLIT RING    | 1   |         |
| 40   | 6736-81-8380 | •• BOLT (M8-1.25x12)   | 4   |         |
| 41   | 6736-81-8360 | •• RING, RETAINING     | 4   |         |
| 42   | 6743-82-8140 | •• RING, RETAINING     | 1   |         |

Reference: A1203-A2A0




Reference: A1204-A2A8

## A-017 A1204-A2A8 AIR INTAKE CONNECTION

| Item | Part No.     | Part Name              | Qty | Options |
|------|--------------|------------------------|-----|---------|
| 1    | 07043-70108  | PLUG, PIPE             | 1   |         |
| 2    | 6738-11-4370 | SEAL, O-RING           | 1   |         |
| 3    | 6738-11-4390 | NUT, LOCK              | 1   |         |
| 4    | 1307 683 H1  | CLAMP, V-BAND          | 1   |         |
| 5    | 6754-11-4120 | GASKET, CONNECTION     | 1   |         |
| 6    | 6738-11-4320 | PIPE, AIR TRANSFER     | 1   |         |
| 7    | 6754-11-4310 | CONNECTION, AIR INTAKE | 1   |         |
| 8    | 6734-11-5210 | BOLT (M8-1.25x80)      | 4   |         |

Reference: A1204-A2A8



Reference: A1206-A2A0

## A-019 A1206-A2A0 AIR INTAKE MANIFOLD

| Item | Part No.     | Part Name                     | Qty | Options |
|------|--------------|-------------------------------|-----|---------|
| 1    | 6745-21-4110 | PLUG, PIPE                    | 1   |         |
| 2    | 6754-11-4230 | COVER, INTAKE MANIFOLD        | 1   |         |
| 3    | 6732-11-4160 | BOLT (M8-1.25x25)             | 4   |         |
| 4    | 6743-12-4110 | BOLT (M8-1.25x30)             | 6   |         |
| 5    | 6754-11-4280 | GASKET, INTAKE MANIFOLD COVER | 1   |         |
| 6    | 6754-11-4430 | GASKET, CONNECTION            | 1   |         |
| 7    | 6754-11-4240 | CONNECTION, ADAPTER           | 1   |         |
|      | 6735-21-1910 | PLUG, THREADED                | 1   |         |
| 8    | NSS          | • PLUG, THREADED              | 1   |         |
| 9    | 6735-21-1930 | • SEAL, O-RING                | 1   |         |

Reference: A1206-A2A0

# Get the complete PDF catalogue

Komatsu WA320-6N S/N A35001-UP

**\$89**

with PayPal | Store cart: \$99

**Buy this PDF on Manuals Komatsu**

Check the model, serial range and language before payment.  
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.