





JD027568

Reference: |AA00001

|AA00001 LIFTING BRACKET MOUNTING

Item	Part No.	Part Name	Qty	Options
1	01435-61025	BOLT	4	
2	6754-11-4130	SCREW	2	

Reference: |AA00001




JD027563

Reference: |AA00002

|AA00002 LIFTING BRACKET

Item	Part No.	Part Name	Qty	Options
1	6754-11-1710	BRACKET	1	
2	6754-11-1960	BRACKET	1	

Reference: |AA00002




JY029368

Reference: |AA00003

|AA00003 BREATHER AND HOSE

Item	Part No.	Part Name	Qty	Options
1	6754-21-6140	BREATHER	1	
2	1241155H1	O-RING	1	
3	6754-21-6150	PLATE	1	
4	6754-21-6160	BOLT	1	
5	6754-21-6170	HOSE	1	
6	6754-21-6180	CLAMP	1	
	6754-21-6100	TUBE ASSEMBLY	1	
7		• TUBE	1	
8	6754-21-6250	• O-RING	1	
9	6754-21-6240	• O-RING	2	
10	6754-21-6280	BOLT	2	

Reference: |AA00003




JY025301

Reference: |AA00004

|AA00004 EXHAUST CONNECTOR CLAMP

Item	Part No.	Part Name	Qty	Options
1	6732-81-8220	CLAMP	1	

Reference: |AA00004




00050924

Reference: |AA00005

|AA00005 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6754-11-1211	CYLINDER HEAD ASSEMBLY	1	
		• HEAD ASSEMBLY	1	
1		•• CYLINDER HEAD	1	
2	6754-11-1170	•• INSERT{INTAKE VALVE}	12	
3	6754-11-1180	•• INSERT{EXHAUST VALVE}	12	
4	6754-11-1150	•• PLUG	7	
5	6732-21-1820	•• PLUG	13	
6	6735-21-5531	•• PLUG,EXPANSION	11	
7	6744-11-1070	•• PLUG	2	
8	6754-11-1160	•• PLUG	2	
9	6732-21-1981	• PLUG,PIPE	4	
10	6732-11-1920	• PLUG	3	
11	6732-61-2240	• PLUG	1	
12	6216-14-6820	• PLUG ASSEMBLY	1	
	6216-14-6860	•• O-RING	1	
13	6754-41-4541	SEAL	12	
	6754-41-4540	SEAL	12	
	6754-41-4100	VALVE KIT{INTAKE}	12	
14	6754-41-4110	• VALVE	1	
15	6744-11-1020	• COLLET	2	
16	6754-41-4541	• SEAL	1	
	6754-41-4540	• SEAL	1	
	6754-41-4200	VALVE KIT{EXHAUST}	12	
17	6754-41-4210	• VALVE	1	
18	6744-11-1020	• COLLET	2	
19	6754-41-4432	SPRING	24	
	6754-41-4431	SPRING	24	
	6754-41-4430	SPRING	24	
20	6754-41-4510	RETAINER	24	
21	6754-11-1610	BOLT	26	
22	6754-11-1811	GASKET	1	

Reference: |AA00005




JY018207

Reference: |AA00006

|AA00006 CYLINDER HEAD COVER (SN 26598590-26624208)

Item	Part No.	Part Name	Qty	Options
1	6754-11-8310	COVER	1	
		• COVER	1	
	6754-11-8340	BOLT	5	
2	6754-11-8260	• ISOLATOR	1	
3		• SCREW	1	
4	6754-11-8330	GASKET	1	

Reference: |AA00006




JY026039

Reference: |AA00007

|AA00007 CYLINDER HEAD COVER (SN 26624209-)

Item	Part No.	Part Name	Qty	Options
1	6754-11-8311	COVER	1	
	6754-11-8310	• COVER	1	
		•• COVER	1	
2	6754-11-8371	TUBE	1	
	6754-11-8340	BOLT	5	
3	6754-11-8260	• ISOLATOR	1	
4		• SCREW	1	
5	6754-11-8330	GASKET	1	

Reference: |AA00007




JD027548

Reference: |AA00008

|AA00008 AIR INTAKE PORT COVER (SN 26598590-26598954)

Item	Part No.	Part Name	Qty	Options
1	6754-11-4230	COVER	1	
	6735-21-1910	PLUG ASSEMBLY	1	
2	6735-21-1920	• PLUG	1	
3	6735-21-1930	• O-RING	1	
4	6754-11-4280	GASKET	1	
5	6732-11-4160	BOLT	4	
6	6754-11-4221	CONNECTOR	1	
7	6754-11-4390	GASKET	1	
8	6743-12-4110	BOLT	6	

Reference: |AA00008




00063092

Reference: |AA00009

|AA00009 AIR INTAKE PORT COVER (SN 26598955-)

Item	Part No.	Part Name	Qty	Options
1	6754-11-4230	COVER	1	
	6735-21-1910	PLUG ASSEMBLY	1	
2	6735-21-1920	• PLUG	1	
3	6735-21-1930	• O-RING	1	
4	6754-11-4280	GASKET	1	
5	6732-11-4160	BOLT	4	
6	6754-11-4221	CONNECTOR	1	
7	6732-11-1920	PLUG	1	
8	6754-11-4390	GASKET	1	
9	6743-12-4110	BOLT	6	

Reference: |AA00009



JY025184

Reference: |AA00010

|AA00010 AIR INTAKE CONNECTOR

Item	Part No.	Part Name	Qty	Options
1	6754-11-4440	CONNECTOR{AIR INTAKE}	1	
2	6754-11-4120	GASKET	1	

Reference: |AA00010

Get the complete PDF catalogue

Komatsu PC220LC-8M0 S/N Y221001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.