




PES5109


Reference: |AAA0001

|AAA0001 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6151-12-1101	CYLINDER HEAD ASS'Y{VALVE LESS}	6	
1		• HEAD{CYLINDER}	1	
2	6136-11-1130	• SLEEVE{(STD)\}	1	
3	6150-11-1320	• INSERT{EXHAUST VALVE}\{(OS)\}	2	
	6150-19-1320	• INSERT, 0.25MM{EXHAUST VALVE}\{(OS)\}	2	
	6150-18-1320	• INSERT, 0.50MM{EXHAUST VALVE}\{(OS)\}	2	
	6150-17-1320	• INSERT, 0.75MM{EXHAUST VALVE}\{(OS)\}	2	
	6150-16-1320	• INSERT, 1.00MM{EXHAUST VALVE}\{(OS)\}	2	
4	6151-11-1330	• INSERT{INTAKE VALVE}\{(STD)\}	2	
	6151-19-1330	• INSERT, 0.25MM{INTAKE VALVE}\{(OS)\}	2	
	6151-18-1330	• INSERT, 0.50MM{INTAKE VALVE}\{(OS)\}	2	
	6151-17-1330	• INSERT, 0.75MM{INTAKE VALVE}\{(OS)\}	2	
	6151-16-1330	• INSERT, 1.00MM{INTAKE VALVE}\{(OS)\}	2	
5	6150-12-1370	• GUIDE{VALVE}	4	
6	07043-70108	• PLUG	1	
7	6162-13-1150	• PLUG	10	
8	6150-11-1140	• GUIDE	2	
9	04020-00820	• PIN{DOWEL}	2	
10	07046-41810	• PLUG	1	
11	6150-42-4110	VALVE{INTAKE}	12	
12	6150-42-4210	VALVE{EXHAUST}	12	
13	6150-41-4510	SEAT{UPPER}	24	
14	6150-41-4430	SEAT{LOWER}	24	
15	6136-42-4520	COTTER{VALVE}	48	
16	6150-41-4450	SPRING	24	
17	6150-41-4570	SEAL{VALVE STEM}\{(K1)\}	24	
	6150-42-5600	CROSSHEAD ASS'Y	12	
18	6150-42-5610	• CROSSHEAD	1	
19	6150-41-5621	• SCREW	1	
20	6150-41-5630	• NUT	1	
B	GSTD	STANDARD	-2	
21	6151-12-1810	GASKET\{(K1)\}	6	
22	6150-11-1920	• GROMMET{OIL}	1	
23	6150-11-1930	• GROMMET{OIL}	1	

Item	Part No.	Part Name	Qty	Options
24		• GROMMET{WATER}	4	
25	6150-12-1960	• GROMMET{WATER}	1	
B	GOS04	OVERSIZE 0.4MM	-2	
21	6151-19-1810	GASKET, 0.4MM OS	6	
22	6150-19-1920	• GROMMET{OIL}	1	
23	6150-19-1930	• GROMMET{OIL}	1	
24		• GROMMET{WATER}	4	
25	6150-19-1960	• GROMMET{WATER}	1	
26	6150-11-1610	BOLT	36	
27	01438-01020	BOLT	6	

Reference: |AAA0001



PES5109


Reference: |AAA0002

|AAA0002 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6151-12-1500	CYLINDER HEAD ASS'Y{VALVE LESS}	6	
1		• HEAD{CYLINDER}	1	
2	6136-11-1130	• SLEEVE	1	
3	6150-11-1320	• INSERT{EXHAUST VALVE}\((STD)\)	2	
	6150-19-1320	• INSERT, 0.25MM{EXHAUST VALVE}\((OS)\)	2	
	6150-18-1320	• INSERT, 0.50MM{EXHAUST VALVE}\((OS)\)	2	
	6150-17-1320	• INSERT, 0.75MM{EXHAUST VALVE}\((OS)\)	2	
	6150-16-1320	• INSERT, 1.00MM{EXHAUST VALVE}\((OS)\)	2	
4	6150-12-1380	• INSERT{INTAKE VALVE}\((STD)\)	2	
	6150-19-1380	• INSERT, 0.25MM{INTAKE VALVE}\((OS)\)	2	
	6150-18-1380	• INSERT, 0.50MM{INTAKE VALVE}\((OS)\)	2	
	6150-17-1380	• INSERT, 0.75MM{INTAKE VALVE}\((OS)\)	2	
	6150-16-1380	• INSERT, 1.00MM{INTAKE VALVE}\((OS)\)	2	
5	6150-12-1370	• GUIDE{VALVE (FOR SERVICE PARTS)}	4	
6	07043-70108	• PLUG	1	
7	6162-13-1150	• PLUG	10	
8	6150-11-1140	• GUIDE	2	
9	04020-00820	• PIN{DOWEL}	2	
10	07046-41810	• PLUG	1	
11	6150-42-4110	VALVE{INTAKE}	12	
12	6150-42-4210	VALVE{EXHAUST}	12	
13	6150-41-4510	SEAT{UPPER}	24	
14	6150-41-4430	SEAT{LOWER}	24	
15	6136-42-4520	COTTER{VALVE}	48	
16	6150-41-4450	SPRING	24	
17	6150-41-4570	SEAL{VALVE STEM}	24	
	6150-42-5600	CROSSHEAD ASS'Y	12	
18	6150-42-5610	• CROSSHEAD	1	
19	6150-41-5621	• SCREW	1	
20	6150-41-5630	• NUT	1	
B	GSTD	STANDARD	-2	
21	6151-12-1810	GASKET{HEAD}	6	
22	6150-11-1920	• GROMMET{OIL}	1	
23	6150-11-1930	• GROMMET{OIL}	1	

Item	Part No.	Part Name	Qty	Options
24		• GROMMET{WATER}	4	
25	6150-12-1960	• GROMMET{WATER}	1	
B	GOS04	OVERSIZE 0.4MM	-2	
21	6151-19-1810	GASKET, 0.4MM OS{HEAD}	6	
22	6150-19-1920	• GROMMET{OIL}	1	
23	6150-19-1930	• GROMMET{OIL}	1	
24		• GROMMET{WATER}	4	
25	6150-19-1960	• GROMMET{WATER}	1	
26	6150-11-1610	BOLT	36	
27	01438-01020	BOLT	6	

Reference: |AAA0002



PJ6C858


Reference: JAAA0003

JAAA0003 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
	6156-11-1101	CYLINDER HEAD ASS'Y{PARTS FOR LESS VALVE}	6	
	6156-11-1100	CYLINDER HEAD ASS'Y{PARTS FOR LESS VALVE}	6	
1		• HEAD{CYLINDER}	1	
2	6136-11-1130	• SLEEVE	1	
3	6150-11-1320	• INSERT{EXHAUST VALVE}\((STD)\)	2	
	6150-19-1320	• INSERT, 0.25MM{EXHAUST VALVE}\((OS)\)	2	
	6150-18-1320	• INSERT, 0.50MM{EXHAUST VALVE}\((OS)\)	2	
	6150-17-1320	• INSERT, 0.75MM{EXHAUST VALVE}\((OS)\)	2	
	6150-16-1320	• INSERT, 1.00MM{EXHAUST VALVE}\((OS)\)	2	
4	6150-12-1380	• INSERT{INTAKE VALVE}\((STD)\)	2	
	6150-19-1380	• INSERT, 0.25MM{INTAKE VALVE}\((OS)\)	2	
	6150-18-1380	• INSERT, 0.50MM{INTAKE VALVE}\((OS)\)	2	
	6150-17-1380	• INSERT, 0.75MM{INTAKE VALVE}\((OS)\)	2	
	6150-16-1380	• INSERT, 1.00MM{INTAKE VALVE}\((OS)\)	2	
5	6150-12-1370	• GUIDE{VALVE (SERVICE ONLY)}	4	
6	6162-13-1150	• PLUG	10	
7	07046-41810	• PLUG	1	
8	07043-70108	• PLUG	1	
9	6150-11-1140	• GUIDE	2	
10	04020-00820	• PIN{DOWEL}	2	
11	6150-42-4110	VALVE{INTAKE}	12	
12	6150-42-4210	VALVE{EXHAUST}	12	
13	6150-41-4510	SEAT{UPPER}	24	
14	6150-41-4430	SEAT{LOWER}	24	
15	6136-42-4520	COTTER{VALVE}	48	
16	6150-41-4450	SPRING	24	
17	6150-41-4570	SEAL{VALVE STEM}\((K1)\)	24	
	6150-42-5600	CROSSHEAD ASS'Y	12	
18	6150-42-5610	• CROSSHEAD	1	
19	6150-41-5621	• SCREW	1	
20	6150-41-5630	• NUT	1	
B	GSTD	STANDARD	0	

Item	Part No.	Part Name	Qty	Options
21	6151-12-1810	GASKET\((K1)\)	6	
22	6150-11-1920	• GROMMET{OIL}	1	
23	6150-11-1930	• GROMMET{OIL}	1	
24		• GROMMET{WATER}	4	
25	6150-12-1960	• GROMMET{WATER}	1	
B	GOS04	OVERSIZE 0.4MM	0	
21	6151-19-1810	GASKET, 0.4MM OS	6	
22	6150-19-1920	• GROMMET{OIL}	1	
23	6150-19-1930	• GROMMET{OIL}	1	
24		• GROMMET{WATER}	4	
25	6150-19-1960	• GROMMET{WATER}	1	
26	6150-11-1610	BOLT	36	
27	01438-01020	BOLT	6	

Reference: |AAA0003




PE38882

Reference: |AAA0004

|AAA0004 HEAD COVER

Item	Part No.	Part Name	Qty	Options
1	6150-11-8111	COVER{HEAD}	6	
2	6150-11-8810	GASKET	6	
3	6150-11-8820	RUBBER\((K1)\)	24	
4	6150-81-9370	BOLT	24	
5	01640-21016	WASHER	24	

Reference: |AAA0004




PE38382

Reference: |AAA0005

|AAA0005 HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6150-11-8200	COVER ASS'Y	6	
1	6150-11-8111	• COVER{HEAD}	1	
2	6150-11-8810	• GASKET	1	
3	6150-11-8820	RUBBER\(((K1))\)	24	
4	6150-81-9370	BOLT	24	
5	01640-21016	WASHER	24	

Reference: |AAA0005




00083546

Reference: |AAA0006

|AAA0006 HEAD COVER

Item	Part No.	Part Name	Qty	Options
	6156-11-8500	COVER ASS'Y	5	
1	6156-11-8110	• COVER{HEAD, NO.1,2,3,4,5}	1	
2	6156-11-8810	• GASKET\((K1)\)	1	
3	6150-11-8820	RUBBER\((K1)\)	10	
4	6150-81-9370	BOLT	10	
5	01640-21016	WASHER	10	
6	6156-11-8831	SEAL\((K1)\)	5	
	6156-11-8600	COVER ASS'Y	1	
7	6156-11-8150	• COVER{HEAD, NO.6}	1	
8	6156-11-8810	• GASKET\((K1)\)	1	
9	6150-11-8820	RUBBER\((K1)\)	2	
10	6150-81-9370	BOLT	2	
11	01640-21016	WASHER	2	
12	6156-11-8831	SEAL\((K1)\)	1	

Reference: |AAA0006



PJ6C860

Reference: |AAA0007

|AAA0007 HEAD COVER

Item	Part No.	Part Name	Qty	Options
1	6156-11-8110	COVER{HEAD, NO.1,2,3,4,5}	5	
2	6156-11-8150	COVER{HEAD, NO.6}	1	
3	6156-11-8810	GASKET\((K1)\)	6	
4	6150-11-8820	RUBBER\((K1)\)	12	
5	6150-81-9370	BOLT	12	
6	01640-21016	WASHER	12	
7	6156-11-8831	SEAL\((K1)\)	6	
	6156-11-8830	SEAL\((K1)\)	6	

Reference: |AAA0007

Get the complete PDF catalogue

Komatsu PC400LC-7 S/N Y400001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.