


エンジン取付部品
FIG. 1101 ENGINE MOUNTING PARTS



Reference: 1101


030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	10E-01-11350	BOLT	2	SN: 6001-UP
2	01643-31445	WASHER	2	SN: 6001-UP
3	10E-01-11210	NAT	2	SN: 6001-UP
4	10E-01-05020	SIM ASSEMBLY	2	SN: 6001-UP
4		• ☆ SHIM, 0.5MM	1	SN: 6001-UP
4		• ☆ SHIM, 1.0MM	2	SN: 6001-UP
5	01010-31230	BOLT	4	SN: 6001-UP
6	01602-01236	WASHER, SPRING	4	SN: 6001-UP
7	10E-01-05010	SIM ASSEMBLY	2	SN: 6001-UP
7		• ☆ SHIM, 2.0MM	1	SN: 6001-UP
7		• ☆ SHIM, 1.0MM	2	SN: 6001-UP
7		• ☆ SHIM, 0.4MM	4	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1101

FIG. 1121 FUEL CONTROL LEVER




Reference: 1121

030020 FUEL CONTROL LEVER

Item	Part No.	Part Name	Qty	Options
1	10E-43-21110	LEVER	1	SN: 6001-UP
2	09304-00835	NOBU	1	SN: 6001-UP
3	10E-43-21120	BRACKET	1	SN: 6001-UP
4	01010-31025	BOLT	2	SN: 6001-UP
5	01602-01030	WASHER, SPRING	2	SN: 6001-UP
6	01643-31032	WASHER	2	SN: 6001-UP
7	10E-43-11140	SHAFT	1	SN: 6001-UP
8	04010-00516	KEY	1	SN: 6001-UP
9	01010-30830	BOLT	1	SN: 6001-UP
10	01602-00825	WASHER, SPRING	1	SN: 6001-UP
11	10E-43-11150	BOSS	1	SN: 6001-UP
12	10E-43-11160	FACING	2	SN: 6001-UP
13	10E-43-21131	LEVER	1	SN: 6001-UP
14	04010-00516	KEY	1	SN: 6001-UP
15	10E-43-11190	SPRING	1	SN: 6001-UP
16	10E-43-11180	RETAINER	1	SN: 6001-UP
17	01590-01215	NAT	1	SN: 6001-UP
18	01641-21223	WASHER	1	SN: 6001-UP
19	04050-03022	PIN, COTTER	1	SN: 6001-UP
20	01016-31035	BOLT	1	SN: 6001-UP
21	01580-01008	NAT	1	SN: 6001-UP
22	10E-43-21140	CABLE	1	SN: 6001-UP
23	04210-20500	YOKE	1	SN: 6001-UP
24	103-43-25160	END, ROD	1	SN: 6001-UP
25	04205-00514	PIN	1	SN: 6001-UP
26	04050-01208	PIN, COTTER	1	SN: 6001-UP
27	01580-00504	NAT	1	SN: 6001-UP
28	01601-00513	WASHER, SPRING	1	SN: 6001-UP

Reference: 1121

ラジエータ および パイピング
FIG. 1131 RADIATOR AND PIPING




Reference: 1131

030030 RADIATOR AND PIPING

Item	Part No.	Part Name	Qty	Options
	10E-03-00012	RADIATOR ASSEMBLY	1	SN: 6001-UP
1	10E-03-21110	• CORE	1	SN: 6001-UP
2	10E-03-11130	• CAP	1	SN: 6001-UP
3	07730-10003	VALVE	1	SN: 6001-UP
4	100-03-12140	SEAT	4	SN: 6001-UP
5	01012-31270	BOLT	2	SN: 6001-UP
6	100-03-12150	WASHER	2	SN: 6001-UP
7	01590-11215	NAT	2	SN: 6001-UP
8	01640-21223	WASHER	4	SN: 6001-UP
9	04050-03025	PIN, COTTER	2	SN: 6001-UP
10	10E-03-21230	ROD	2	SN: 6001-UP
11	10E-03-11250	BRACKET	2	SN: 6001-UP
12	01580-00806	NAT	4	SN: 6001-UP
13	01010-31025	BOLT	2	SN: 6001-UP
14	01602-01030	WASHER, SPRING	2	SN: 6001-UP
15	01641-20812	WASHER	2	SN: 6001-UP
16	04050-03015	PIN, COTTER	2	SN: 6001-UP
17	10E-03-21120	SHROUD	1	SN: 6001-UP
18	01010-30814	BOLT	4	SN: 6001-UP
19	01602-00825	WASHER, SPRING	4	SN: 6001-UP
20	01643-30823	WASHER	4	SN: 6001-UP
21	10E-03-21210	HOSE	1	SN: 6001-UP
22	10E-03-21220	HOSE	1	SN: 6001-UP
23	07280-04426	CLAMP	4	SN: 6001-UP

Reference: 1131

FIG. 1141 フュエル タンク および パイピング
FUEL TANK AND PIPING



Reference: 1141


030040 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
	10E-04-00012	FUEL TANK ASSEMBLY	1	SN: 6001-UP
1		• ☆ TANK	1	SN: 6001-UP
2	07050-20920	• CAP ASSEMBLY	1	SN: 6001-UP
2	07091-10920	• CAP, WITH LOCK	1	SN: .-UP
2	07091-00920	• □ CAP ASSEMBLY, WITH LOCK	1	SN: 6001-.
3	07050-20922	• • GASKET	1	SN: 6001-UP
4	07057-03266	• RING, SNAP	1	SN: 6001-UP
5	07056-16415	• STRAINER	1	SN: 6001-UP
6	10E-04-21120	• CAUGE	1	SN: 6001-UP
7	113-04-22120	VALVE	1	SN: 6001-UP
8	01010-31230	BOLT	4	SN: 6001-UP
9	01602-01236	WASHER, SPRING	4	SN: 6001-UP
10	10E-04-21141	TUBE	1	SN: .-UP
10	10E-04-21140	■ TUBE (10E-04-21141,07281-00137(2))	1	SN: 6001-.
11	07281-00137	CLAMP	2	SN: 6319-UP
11	07280-01418	CLAMP	2	SN: .-6318
11	07280-00810	CLAMP	2	SN: 6001-.
12	08034-00414	BAND	2	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead ■ may be used instead of described part

Reference: 1141

FIG. 1151 バッテリー
BATTERY



Reference: 1151


030050 Battery

Item	Part No.	Part Name	Qty	Options
1	08000-02208	BATTERY (75D31R)	1	SN: .-UP
1	08000-01208	□ BATTERY (75D31R)	1	SN: 6001-.
1	10E-06-11210	BATTERY (95D31R), (B)	1	SN: 6001-UP
1	08000-11208	BATTERY (75D31R), (OVERSEAS)	1	SN: 6001-UP
2	08000-00000	• TERMINAL, (+)	1	SN: 6001-UP
2	08000-00001	• TERMINAL, (-)	1	SN: 6001-UP
3	01010-30830	• BOLT	2	SN: 6001-UP
4	01580-00806	• NAT	2	SN: 6001-UP
5	01050-31018	• BOLT	2	SN: 6001-UP
6	01640-01016	• WASHER	2	SN: 6001-UP
7	10E-06-21110	PLATE	1	SN: 6001-UP
8	01010-31025	BOLT	4	SN: 6001-UP
9	01602-01030	WASHER, SPRING	4	SN: 6001-UP
10	10E-06-21120	PLATE	1	SN: 6001-UP
11	10E-06-21130	BOLT	1	SN: 6001-UP
12	01580-00806	NAT	4	SN: 6001-UP
13	01643-30823	WASHER	2	SN: 6001-UP

Catalog signs: □ part above may be used instead

Reference: 1151

FIG. 1155 インストルメント パネル
INSTRUMENT PANEL



Reference: 1155


030060 INSTRUMENT PANEL

Item	Part No.	Part Name	Qty	Options
1	10E-06-22110	PANEL	1	SN: 6001-UP
2	01010-31025	BOLT	4	SN: 6001-UP
3	01602-01030	WASHER, SPRING	4	SN: 6001-UP
4	01643-31032	WASHER	4	SN: 6001-UP
5	08086-10000	SWITCH, STARTING	1	SN: .-UP
5	08086-00000	☐ SWITCH, STARTING	1	SN: 6001-.
6	08043-04000	BOX, FUSES	1	SN: 6001-UP
7	08040-00500	FUSE, 5A	1	SN: 6001-UP
7	08040-01000	FUSE, 10A	2	SN: 6001-UP
7	08040-02000	HOSE, 20A	1	SN: 6001-UP
8	01220-40520	SCREW	2	SN: 6001-UP
9	01580-10504	NAT	2	SN: 6001-UP
10	01601-00513	WASHER, SPRING	2	SN: 6001-UP
11	08061-60010	SWITCH, LAMP	1	SN: 6001-UP
12	10E-06-22130	LAMP	1	SN: 6001-UP
13	08655-01000	GAUGE, WATER	1	SN: 6001-UP
14	08687-21202	METER, SERVICE	1	SN: .-UP
14	08687-21200	☒ METER, SERVICE	1	SN: (. -6525)
14	20T-06-11180	☐ METER, SERVICE	1	SN: 6001-.
15	600-815-1361	SIGNAL, HEATER	1	SN: 6001-UP
16	10E-06-22140	LAMP, PRESSURE	1	SN: 6001-UP
17	10E-06-22150	LAMP, CHARGE	1	SN: 6001-UP
18	10E-06-23141	CLIP	1	SN: 6001-UP
19	01010-30816	BOLT	1	SN: 6001-UP
20	01602-00825	WASHER, SPRING	1	SN: 6001-UP

Catalog signs: ☐ part above may be used instead ☒ discontinued: use part above

Reference: 1155

FIG. 1161 エレクトリカル システム
ELECTRICAL SYSTEM



Reference: 1161


030070 ELECTRICAL SYSTEM

Item	Part No.	Part Name	Qty	Options
1	10E-06-22210	WIRE ASSEMBLY	1	SN: 6001-UP
2	10E-06-23120	WOW	2	SN: 6001-UP
3	08125-01200	LAMP ASSEMBLY	3	SN: 6001-UP
3	08107-01260	• BULB, 60W	1	SN: 6001-UP
4	10E-06-21141	WOW	1	SN: .-UP
4	10E-06-21140	□ WOW	1	SN: 6001-.
5	20R-06-11240	WOW	1	SN: 6001-UP
6	10E-06-23112	WIRE ASSEMBLY	1	SN: .-UP
6	10E-06-23111	□ WIRE ASSEMBLY	1	SN: 6001-.
7	08073-00505	SWITCH, PRESSURE	1	SN: 6001-.
8	600-813-1560	STARTING MOTOR ASSEMBLY	1	SN: 6001-UP
9	01010-31245	BOLT	2	SN: 6001-UP
10	01602-01236	WASHER, SPRING	2	SN: 6001-UP
11	08160-21200	HORN	1	SN: 6001-UP
12	01010-30816	BOLT	2	SN: 6001-UP
13	01602-00825	WASHER, SPRING	2	SN: 6001-UP
14	08064-10000	SWITCH, HORN	1	SN: 6001-UP
15	08038-04030	CAP	2	SN: 6001-UP
16	08036-10814	CLIP	1	SN: 6001-UP
17	08036-01414	CLIP	6	SN: 6001-UP
18	01010-31016	BOLT	6	SN: 6001-UP
19	01602-01030	WASHER, SPRING	6	SN: 6001-UP
20	01580-01008	NAT	1	SN: 6001-UP
21	08037-05016	GROMMET	1	SN: 6001-UP
22	08034-00414	BAND	2	SN: .-UP

Catalog signs: □ part above may be used instead

Reference: 1161

ユニバーサル ジョイント
FIG. 1201 UNIVERSAL JOINT




Reference: 1201

060010 UNIVERSAL JOINT

Item	Part No.	Part Name	Qty	Options
	10E-20-12000	UNIVERSAL JOINT ASSEMBLY	1	SN: 6001-UP
1	10E-20-12110	• FLANGE	1	SN: 6001-UP
2	10E-20-12130	• YOKE	1	SN: 6001-UP
3	10E-20-12120	• YOKE	1	SN: 6001-UP
4	10E-20-12140	• PIN, CROSS	2	SN: 6001-UP
5	10E-20-12150	• RING, SNAP	8	SN: 6001-UP
6	01010-30822	BOLT	4	SN: 6001-UP
7	01602-00825	WASHER, SPRING	4	SN: 6001-UP

Reference: 1201

FIG. 1211 メイン クラッチ ケース および ヨーク
MAIN CLUTCH CASE AND YOKE



Reference: 1211

060020 MAIN CLUTCH CASE AND YOKE

Item	Part No.	Part Name	Qty	Options
1	10E-10-11110	CASE	1	SN: 6001-UP
2	07042-00415	PLUG	1	SN: 6001-UP
3	10E-10-11120	GASKET	1	SN: 6001-UP
4	01010-31035	BOLT	9	SN: 6001-UP
5	01010-31040	BOLT	2	SN: 6001-UP
6	01602-01030	WASHER, SPRING	11	SN: 6001-UP
7	10E-10-11640	RETAINER	1	SN: 6001-UP
8	130-09-13790	BEARING	1	SN: 6001-UP
9	10E-10-11740	SLEEVE	1	SN: 6001-UP
10	10E-10-11650	SEAL, OIL	1	SN: 6001-UP
11	04064-03015	RING, SNAP	1	SN: 6001-UP
12	06040-06006	BEARING	1	SN: 6001-UP
13	10E-10-11620	CAGE	1	SN: 6001-UP
14	10E-10-11630	GASKET	1	SN: 6001-UP
15	01010-30825	BOLT	8	SN: 6001-UP
16	01602-00825	WASHER, SPRING	8	SN: 6001-UP
17	07012-00038	SEAL, OIL	1	SN: 6001-UP
18	10E-10-11610	SHAFT	1	SN: 6001-UP
19	07020-00675	FITTING, GREASE	3	SN: 6001-UP
20	07030-00252	BREATHER	1	SN: 6001-UP
21	10E-10-11530	BEARING	2	SN: 6001-UP
22	10E-10-11540	SEAL	4	SN: 6001-UP
23	10E-10-11710	YOKE	1	SN: 6001-UP
24	04000-00725	KEY	2	SN: 6001-UP
25	10E-10-11520	SHAFT	1	SN: 6001-UP
26	01306-00616	SCREW	1	SN: 6001-UP
27	04059-01016	WOW	1	SN: 6001-UP
28	10E-10-11720	SPRING, LEFT	1	SN: 6001-UP
28	10E-10-11730	SPRING, RIGHT	1	SN: 6001-UP
29	10E-10-11750	HOSE	1	SN: 6001-UP
30	01580-00806	NAT	1	SN: 6001-UP
31	01580-01613	NAT	1	SN: 6001-UP
32	07020-00900	FITTING, GREASE	1	SN: 6001-UP
33	08036-01414	CLIP	1	SN: .-UP

Get the complete PDF catalogue

Komatsu D10Q-2 (JPN) S/N 6001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.