


エンジン 取 付 部 品
Fig. 1101 ENGINE MOUNTING PARTS




Reference: 1101

030010 ENGINE ATTACHING PARTS

Item	Part No.	Part Name	Qty	Options
1	01010-31435	BOLT	8	SN: 32912-UP
2	01602-01442	WASHER, SPRING	8	SN: 32912-UP

Reference: 1101

Fig. 1102 FUEL CONTROL LEVER



Reference: 1102


030020 FUEL CONTROL LEVER

Item	Part No.	Part Name	Qty	Options
	101-43-00014	FUEL LEVER ASSEMBLY	1	SN: 32912-UP
1	102-43-11113	• BRACKET, FUEL CONTROL LEVER	1	SN: 32912-UP
2	01010-30816	• BOLT	2	SN: 32912-UP
3	01602-00825	• WASHER, SPRING	2	SN: 32912-UP
4	101-43-11310	• DISK	1	SN: 32912-UP
5	101-43-11281	• FACING	2	SN: 32912-UP
6	101-43-11320	• DISK	1	SN: 32912-UP
7	04020-00616	• PIN, DOWEL	2	SN: 32912-UP
8	101-43-11380	• COVER	1	SN: 32912-UP
9	130-43-18134	• SPRING	1	SN: 32912-UP
10	101-43-11390	• BOLT	1	SN: 32912-UP
11	01641-01223	• WASHER	1	SN: 32912-UP
12	01593-01210	• NAT	1	SN: 32912-UP
13	04050-03020	• PIN, COTTER	1	SN: 32912-UP
14	101-43-11330	• PLATE	1	SN: 32912-UP
15	01010-30825	• BOLT	2	SN: 32912-UP
16	01602-00825	• WASHER, SPRING	2	SN: 32912-UP
17	101-43-11340	• PLATE	1	SN: 32912-UP
18	101-43-11350	• PLATE	1	SN: 32912-UP
19	01010-30830	• BOLT	2	SN: 32912-UP
20	01602-00825	• WASHER, SPRING	2	SN: 32912-UP
21	01016-30830	• BOLT	1	SN: 32912-UP
22	01580-00806	• NAT	1	SN: 32912-UP
23	101-43-21190	• LEVER, FUEL CONTROL	1	SN: 32912-UP
24	01580-01210	• NAT	1	SN: 32912-UP
25	01602-01236	• WASHER, SPRING	1	SN: 32912-UP
26	09304-01250	• KNOB, FUEL CONTROL LEVER	1	SN: 32912-UP
27	101-43-21160	ROD	1	SN: 32912-UP
28	04050-02012	PIN, COTTER	2	SN: 32912-UP
29	101-43-21170	BRACKET	1	SN: 32912-UP
30	01010-30820	BOLT	2	SN: 32912-UP
31	01580-00806	NAT	2	SN: 32912-UP
32	01602-00825	WASHER, SPRING	2	SN: 32912-UP
33	101-43-21150	LEVER	1	SN: 32912-UP
34	101-43-21140	ROD	1	SN: 32912-UP
35	04211-00634	YOKE	1	SN: 32912-UP
36	04205-00620	PIN	2	SN: 32912-UP
37	04050-01610	PIN, COTTER	2	SN: 32912-UP
38	01642-01016	WASHER	1	SN: 32912-UP
39	01590-01012	NAT	1	SN: 32912-UP
40	04050-02018	PIN, COTTER	1	SN: 32912-UP
41	01580-00605	NAT	1	SN: 32912-UP
42	04221-00634	YOKE, LEFT SCREW	1	SN: 32912-UP
43	01508-10603	NUT, LEFT HAND THREAD, LEFT HAND THREAD	1	SN: 32912-UP
44	101-43-21110	BRACKET	1	SN: 32912-UP
45	01010-31020	BOLT	2	SN: 32912-UP
46	01602-01030	WASHER, SPRING	2	SN: 32912-UP

Item	Part No.	Part Name	Qty	Options
47	101-43-21280	PIN	1	SN: 32912-UP
48	04025-00620	PIN, ROLL	2	SN: 32912-UP
49	101-43-21120	LEVER	1	SN: 32912-UP
50	101-43-21130	LEVER	1	SN: 32912-UP
51	101-43-21180	ROD	1	SN: 32912-UP
52	01580-00806	NAT	2	SN: 32912-UP
54	101-43-21350	JOINT, BALL	2	SN: 32912-UP
57	01590-00607	NAT	2	SN: 32912-UP
58	01641-00608	WASHER	2	SN: 32912-UP
59	04050-01210	PIN, COTTER	2	SN: 32912-UP

Reference: 1102

コンプレッション リリース レバー
Fig. 1103 COMPRESSION RELEASE LEVER




Reference: 1103

030030 COMPRESSION RELEASE LEVER

Item	Part No.	Part Name	Qty	Options
1	101-43-21251	LEVER, COMPRESSION RELEASE	1	SN: 32912-UP
2	01010-30830	BOLT	1	SN: 32912-UP
3	01602-00825	WASHER, SPRING	1	SN: 32912-UP
4	101-43-21242	SHAFT	1	SN: 32912-UP
5	04010-00413	KEY	1	SN: 32912-UP
6	101-43-21341	BRACKET	1	SN: 32912-UP
7	01010-30816	BOLT	3	SN: 32912-UP
8	01602-00825	WASHER, SPRING	3	SN: 32912-UP
10	103-43-12311	BUSHING, NEEDLE	2	SN: 32912-UP
11	101-43-21211	LEVER	1	SN: 32912-UP
12	04025-00624	PIN, ROLL	1	SN: 32912-UP
13	101-43-21271	YOKE	1	SN: 32912-UP
14	04205-00618	PIN	2	SN: 32912-UP
15	04050-01610	PIN, COTTER	2	SN: 32912-UP

Reference: 1103

ラジエータ
Fig. 1121 RADIATOR



11-10

D20F

Reference: 1121


030040 RADIATOR

Item	Part No.	Part Name	Qty	Options
	101-03-00017	RADIATOR ASSEMBLY	1	SN: 32912-UP
1	101-03-21102	• CORE ASSEMBLY	1	SN: 32912-UP
2	101-03-15130	• STRAINER	1	SN: 32912-UP
3	101-03-13141	• CAP	1	SN: 32912-UP
4	07730-10003	• VALVE	1	SN: 32912-UP
5	101-03-13170	• PIPE, OVER FLOW	1	SN: 32912-UP
6	101-03-13180	• CLIP	2	SN: 32912-UP
7	101-03-21113	• SHROUD, FAN	1	SN: 32912-UP
8	01010-30814	• BOLT	6	SN: 32912-UP
9	01580-00806	• NAT	6	SN: 32912-UP
10	01602-00825	• WASHER, SPRING	6	SN: 32912-UP
11	101-03-21121	• NET, WIRE	1	SN: 32912-UP
12	01010-30610	• BOLT	4	SN: 32912-UP
13	01602-00619	• WASHER, SPRING	4	SN: 32912-UP
14	101-03-12122	BRACKET, RADIATOR, LEFT	1	SN: 32912-UP
14	101-965-1310	BRACKET, RADIATOR, RIGHT	1	SN: 32912-UP
15	01010-31225	BOLT	4	SN: 32912-UP
16	01602-01236	WASHER, SPRING	4	SN: 32912-UP
17	01052-31260	BOLT	2	SN: 32912-UP
18	100-03-12150	WASHER	2	SN: 32912-UP
19	100-03-12140	SEAT, RADIATOR MOUNT	4	SN: 32912-UP
20	01593-01210	NAT	2	SN: 32912-UP
21	01640-01223	WASHER	2	SN: 32912-UP
22	04050-03025	PIN, COTTER	2	SN: 32912-UP
23	103-03-11110	BRACKET, SUPPORTING ROD	2	SN: 32912-UP
24	01010-31025	BOLT	2	SN: 32912-UP
25	01602-01030	WASHER, SPRING	2	SN: 32912-UP
26	103-03-11121	ROD, SUPPORTING	2	SN: 32912-UP
27	01580-01008	NAT	4	SN: 32912-UP
28	01641-01223	WASHER	2	SN: 32912-UP
29	04050-03015	PIN, COTTER	2	SN: 32912-UP
30	101-03-14151	PLATE, RUBBER	2	SN: 32912-UP
31	101-03-21171	PLATE, RUBBER	1	SN: 32912-UP
32	101-03-21220	PLATE	1	SN: 32912-UP

Item	Part No.	Part Name	Qty	Options
33	01010-30616	BOLT	13	SN: 32912-UP
34	01602-00619	WASHER, SPRING	13	SN: 32912-UP
35	101-965-1330	PLATE	1	SN: 32912-UP
36	101-965-1320	PLATE	1	SN: 32912-UP
37	01010-30616	BOLT	4	SN: 32912-UP
38	01602-00619	WASHER, SPRING	4	SN: 32912-UP
39	01642-20608	WASHER	4	SN: 32912-UP
40	101-03-21151	HOSE, INLET	1	SN: 32912-UP
41	101-03-21160	HOSE, OUTLET	1	SN: 32912-UP
42	07281-00549	CLAMP	4	SN: 32912-UP

Reference: 1121

Fig. 1131 FUEL TANK AND PIPING
Fig. 1131 FUEL TANK AND PIPING




Reference: 1131

030050 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
	101-04-00015	FUEL TANK ASSEMBLY	1	SN: 32912-UP
1	101-04-21142	• TANK	1	SN: 32912-UP
2	101-04-11123	• GAUGE, FUEL LEVEL	1	SN: 32912-UP
3	101-04-11240	• CAP ASSEMBLY	1	SN: 32912-UP
4	07057-03266	• LINK	1	SN: 32912-UP
5	07056-06416	• STRAINER, FUEL	1	SN: 32912-UP
6	01010-31425	• BOLT	4	SN: 32912-UP
7	01602-01442	• WASHER, SPRING	4	SN: 32912-UP
8	07700-20502	VALVE, DRAIN	1	SN: 32912-UP
9	101-04-11230	NIPPLE	1	SN: 32912-UP
10	101-04-11170	NIPPLE, DRAIN	1	SN: 32912-UP
11	07700-20502	VALVE, FUEL SHUT OFF	1	SN: 32912-UP
12	07213-51013	CONNECTOR	1	SN: 32912-UP
13	101-04-21171	PIPE ASSEMBLY	1	SN: 32912-UP
20	101-04-21161	PIPE	1	SN: 32912-UP
23	08036-11210	CLIP	1	SN: 32912-UP
24	130-04-44130	CLIP	1	SN: 32912-UP
25	130-802-5110	CLIP	1	SN: 32912-UP

Reference: 1131

Fig. 1141 INSTRUMENT PANEL REGULATOR AND FUSE BOX



11-16

230P

Reference: 1141


030060 INSTRUMENT PANEL REGULATOR AND FUSE BOX

Item	Part No.	Part Name	Qty	Options
1	101-06-21112	PANEL	1	SN: 32912-UP
2	08064-10000	SWITCH, HORN	1	SN: 32912-UP
3	01010-30816	BOLT	4	SN: 32912-UP
4	01602-00825	WASHER, SPRING	4	SN: 32912-UP
5	01640-00816	WASHER	4	SN: 32912-UP
6	102-06-12140	PLATE	1	SN: 32912-UP
7	01210-40308	SCREW	2	SN: 32912-UP
8	01601-00307	WASHER, SPRING	2	SN: 32912-UP
9	08631-02000	GAUGE, PRESSURE	1	SN: 32912-UP
9	01580-10504	• NAT	2	SN: 32912-UP
9	01601-20513	• WASHER, SPRING	2	SN: 32912-UP
10	101-06-21121	TUBE	1	SN: 32912-UP
11	07201-50512	NUT, SLEEVE	1	SN: 32912-UP
12	08661-11500	GAUGE, SUCTION	1	SN: 32912-UP
12	01580-10504	• NAT	2	SN: 32912-UP
12	01601-20513	• WASHER, SPRING	2	SN: 32912-UP
13	08601-13000	AMMETER	1	SN: 32912-UP
14	08143-12400	LAMP, PANEL	1	SN: 32912-UP
14	08112-02410	• BULB, 10W	1	SN: 32912-UP
15	101-06-12140	WASHER	1	SN: 32912-UP
16	6130-81-8211	SIGNAL, HEATER	1	SN: 32912-UP
17	08060-00000	SWITCH, THERMOSTAT	1	SN: 32912-UP
18	150-01-11440	CLAMP	1	SN: 32912-UP
19	08061-11000	SWITCH, LAMP	1	SN: 32912-UP
20	08086-00000	SWITCH, STARTING	1	SN: 32912-UP
21	08043-04000	BOX, FUSE	1	SN: 32912-UP
22	08040-01000	FUSE, 10A	2	SN: 32912-UP
23	08040-02000	FUSE, 20A	2	SN: 32912-UP
24	01210-40520	SCREW	2	SN: 32912-UP
25	01601-00513	WASHER, SPRING	2	SN: 32912-UP
26	01580-00504	NAT	2	SN: 32912-UP
29	600-824-4930	SAFETY RELAY ASSEMBLY	1	SN: 32912-UP
30	01010-30614	BOLT	4	SN: 32912-UP
31	01602-00619	WASHER, SPRING	4	SN: 32912-UP
32	01580-00605	NAT	4	SN: 32912-UP
33	102-06-21115	WIRE ASSEMBLY	1	SN: 32912-UP
34	08036-10810	CLIP	1	SN: 32912-UP
35	01010-30816	BOLT	1	SN: 32912-UP
36	01602-00825	WASHER, SPRING	1	SN: 32912-UP
37	01580-00806	NAT	1	SN: 32912-UP
38	102-06-14160	CLIP	3	SN: 32912-UP
39	01010-30616	BOLT	3	SN: 32912-UP
40	01601-00615	WASHER, SPRING	3	SN: 32912-UP
41	01580-00605	NAT	3	SN: 32912-UP
42	08160-22400	HORN	1	SN: 32912-UP
43	01010-30816	BOLT	2	SN: 32912-UP
44	01580-00806	NAT	2	SN: 32912-UP

Item	Part No.	Part Name	Qty	Options
45	01602-00825	WASHER, SPRING	2	SN: 32912-UP
46	101-54-35440	DASHBOARD	1	SN: 32912-UP
47	102-965-8830	BRACKET	1	SN: 32912-UP
48	01010-30816	BOLT	4	SN: 32912-UP
49	01602-00825	WASHER, SPRING	4	SN: 32912-UP
50	102-965-8810	TACHOMETER	1	SN: 32912-UP
51	08603-50018	CABLE	1	SN: 32912-UP
52	08036-10814	CLIP	1	SN: 32912-UP
53	01010-31016	BOLT	2	SN: 32912-UP
54	01602-01030	WASHER, SPRING	2	SN: 32912-UP
55	102-965-8820	WOW	1	SN: 32912-UP
56	08037-01610	GROMMET	1	SN: 32912-UP
57	08037-01008	GROMMET	1	SN: 32912-UP

Reference: 1141

ヘッド ランプ および ワイヤリング
Fig. 1143 HEAD LAMP AND WIRING (20QF)



Reference: 1143

030070 HEAD LAMP AND WIRING

Item	Part No.	Part Name	Qty	Options
1	102-06-12131	BRACKET	2	SN: 32912-UP
2	01010-31235	BOLT	6	SN: 32912-UP
3	01602-01236	WASHER, SPRING	6	SN: 32912-UP
4	08125-02400	LAMP ASSEMBLY	3	SN: 32912-UP
4	08125-00000	• BODY, LAMP	1	SN: 32912-UP
4	08107-02460	• ELECTRIC LAMP, 60W	1	SN: 32912-UP
4	08125-00016	• NAT	1	SN: 32912-UP
5	101-06-11120	GROMMET	2	SN: 32912-UP
6	08036-10614	CLIP	2	SN: 32912-UP
7	101-06-14200	WIRE ASSEMBLY	1	SN: 32912-UP
8	08038-00519	CAP	4	SN: 32912-UP
9	08038-00519	CAP	4	SN: 32912-UP
10	08036-11210	CLIP	1	SN: 32912-UP
11	102-06-21114	WIRE ASSEMBLY	1	SN: 32912-UP

Reference: 1143

Get the complete PDF catalogue

Komatsu D20QF-3 (JPN) S/N 32912-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.