





Reference: 1001

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	103-01-31130	CUSHION	4	SN: 60001-UP
2	103-01-31120	CUSHION	4	SN: 60001-UP
3	113-01-21120	WASHER	4	SN: 60001-UP
4	01011-51610	BOLT	4	SN: 60001-UP

Reference: 1001




Reference: 1201

030020 RADIATOR AND PIPING

Item	Part No.	Part Name	Qty	Options
	103-03-00110	RADIATOR ASSEMBLY	1	SN: 60001-UP
1		• ☆ CORE ASSEMBLY	1	SN: 60001-UP
2	10E-03-11130	• CAP	1	SN: 60001-UP
3	07730-10003	VALVE	1	SN: 60001-UP
4	113-03-21140	TUBE	1	SN: 60001-UP
5	08036-10814	CLIP	2	SN: 60001-UP
6	103-03-31121	SHROUD	1	SN: 60001-UP
7	01010-50816	BOLT	4	SN: 60001-UP
8	01602-20825	WASHER,SPRING	4	SN: 60001-UP
9	01643-30823	WASHER	4	SN: 60001-UP
10	103-03-31130	NET, WIRE	1	SN: 60001-UP
11	01010-51020	BOLT	3	SN: 60001-UP
12	01602-21030	WASHER,SPRING	3	SN: 60001-UP
13	100-03-12140	SEAT	4	SN: 60001-UP
14	20T-03-11130	SPACER	2	SN: 60001-UP
15	103-03-21160	PLATE	2	SN: 60001-UP
16	01010-51060	BOLT	2	SN: 60001-UP
17	01602-21030	WASHER,SPRING	2	SN: 60001-UP
18	103-03-31190	BRACKET	1	SN: 60001-UP
19	01010-51025	BOLT	2	SN: 60001-UP
20	01602-21030	WASHER,SPRING	2	SN: 60001-UP
21	135-03-12110	DUMPER	1	SN: 60001-UP
22	01010-51460	BOLT	1	SN: 60001-UP
23	01602-21442	WASHER,SPRING	1	SN: 60001-UP
24	01010-51025	BOLT	1	SN: 60001-UP
25	103-03-31141	HOSE	1	SN: 60001-UP
26	103-03-31151	HOSE	1	SN: 60001-UP
27	207-09-11110	CLAMP	4	SN: 68991-UP
27	07281-00549	□ CLAMP	4	SN: 60001-68990
28	103-03-31171	BAFFLE	1	SN: 60001-UP
29	103-03-31180	BAFFLE	1	SN: 60001-UP
30	01010-51020	BOLT	4	SN: 60001-UP
31	01602-21030	WASHER,SPRING	4	SN: 60001-UP

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead




Reference: 1221

030030 RADIATOR SHUTTER

Item	Part No.	Part Name	Qty	Options
1	104-03-21110	SHUTTER	1	SN: 60001-UP
2	01220-40416	SCREW	4	SN: 60001-UP
3	01640-20408	WASHER	4	SN: 60001-UP
4	01601-20410	WASHER,SPRING	4	SN: 60001-UP
5	01580-10403	NAT	4	SN: 60001-UP
6	103-03-31310	BRACKET	1	SN: 60001-UP
7	01010-51025	BOLT	2	SN: 60001-UP
8	01602-21030	WASHER,SPRING	2	SN: 60001-UP


Reference: 1221



Reference: 1302

030040 FUEL TANK AND PIPING (F2-R2 TRANSMISSION USE)


Item	Part No.	Part Name	Qty	Options
	103-04-00110	FUEL TANK ASSEMBLY	1	SN: 60001-63878
1	103-04-31114	• TANK	1	SN: 65861-UP
1	103-04-31113	• TANK	1	SN: 63879-65860
1	103-04-31111	• TANK	1	SN: 60001-63878
2	07050-20920	• CAP ASSEMBLY	1	SN: 60001-UP
2	07050-20922	• • GASKET	1	SN: 60001-UP
3	07056-16415	• STRAINER	1	SN: 60001-UP
4	07057-03266	• RING, SNAP	1	SN: 60001-UP
5	103-04-31120	• GAUGE	1	SN: 60001-UP
6	01010-51240	BOLT	4	SN: 63879-UP
6	01010-51230	BOLT	4	SN: 60001-63878
6A	103-54-34450	PLATE	2	SN: 63879-UP
7	01602-21236	WASHER, SPRING	4	SN: 60001-UP
8	01643-31232	WASHER	4	SN: 60001-UP
9	103-54-34320	PLATE	1	SN: 60001-UP
10	01010-51020	BOLT	4	SN: 60001-UP
11	01643-31032	WASHER	4	SN: 60001-UP
12	07288-01016	HOSE	1	SN: 60001-UP
12	07288-01020	HOSE, (FOR WATER SEPARATOR)	1	SN: 60001-UP
12	07288-01018	HOSE, (FOR FUEL STRAINER)	1	SN: 60001-UP
13	07288-01022	HOSE	1	SN: 60001-UP
14	08034-00414	BAND	1	SN: 60001-UP
14	08034-00414	BAND, (FOR WATER SEPARATOR)	2	SN: 60001-UP
15	07281-00197	CLAMP	4	SN: 60001-UP
16	08036-03014	CLIP	3	SN: 60001-UP
17	08036-02514	CLIP	1	SN: 60001-UP
18	01010-51016	BOLT	4	SN: 60001-UP
19	01602-21030	WASHER, SPRING	4	SN: 60001-UP
20	07700-40240	VALVE	1	SN: 60001-UP
21	124-04-21250	ERBO	1	SN: 60001-UP
22	07270-01235	TUBE	1	SN: 61663-UP
22	07270-01225	TUBE	1	SN: 60001-61662
23	07285-00150	CLIP	1	SN: 60001-UP



Reference: 1303

030050 FUEL TANK AND PIPING (FOR F3-R3 TRANSMISSION)

Item	Part No.	Part Name	Qty	Options
	103-04-00130	FUEL TANK ASSEMBLY	1	SN: 60001-63878
1	103-04-39112	• TANK	1	SN: 65861-UP
1	103-04-39111	• TANK	1	SN: 63879-65860
1	103-04-39110	• TANK	1	SN: 60001-63878
2	07050-20920	• CAP ASSEMBLY	1	SN: 60001-UP
2	07050-20922	• • GASKET	1	SN: 60001-UP
3	07056-16415	• STRAINER	1	SN: 60001-UP
4	07057-03266	• RING, SNAP	1	SN: 60001-UP
5	103-04-31120	• GAUGE	1	SN: 60001-UP
6	01010-51240	BOLT	4	SN: 63879-UP
6	01010-51230	BOLT	4	SN: 60001-63878
6A	103-54-34450	PLATE	2	SN: 63879-UP
7	01602-21236	WASHER,SPRING	4	SN: 60001-UP
8	01643-31232	WASHER	4	SN: 60001-UP
9	103-54-34320	PLATE	1	SN: 60001-UP
10	01010-51020	BOLT	4	SN: 60001-UP
11	01643-31032	WASHER	4	SN: 60001-UP
12	07288-01016	HOSE	1	SN: 60001-UP
12	07288-01020	HOSE, (FOR WATER SEPARATOR)	1	SN: 60001-UP
12	07288-01018	HOSE, (FOR FUEL STRAINER)	1	SN: 60001-UP
13	07288-01022	HOSE	1	SN: 60001-UP
14	08034-00414	BAND	1	SN: 60001-UP
14	08034-00414	BAND, (FOR WATER SEPARATOR)	2	SN: 60001-UP
15	07281-00197	CLAMP	4	SN: 60001-UP
16	08036-03014	CLIP	3	SN: 60001-UP
17	08036-02514	CLIP	1	SN: 60001-UP
18	01010-51016	BOLT	4	SN: 60001-UP
19	01602-21030	WASHER,SPRING	4	SN: 60001-UP
20	07700-40240	VALVE	1	SN: 60001-UP
21	124-04-21250	ERBO	1	SN: 60001-UP
22	07270-01235	TUBE	1	SN: 61663-UP
22	07270-01225	TUBE	1	SN: 60001-61662
23	07285-00150	CLIP	1	SN: 60001-UP




Reference: 1305

030060 FUEL TANK AND PIPING (WITH ROPS CAB)

Item	Part No.	Part Name	Qty	Options
1	103-04-39161	TANK	1	SN: 63438-UP
1	103-04-39160	TANK	1	SN: 60001-63437
2	07050-20920	CAP ASSEMBLY	1	SN: 60001-UP
2	07050-20922	• GASKET	1	SN: 60001-UP
3	07056-16415	STRAINER	1	SN: 60001-UP
4	07057-03266	RING, SNAP	1	SN: 60001-UP
5	103-04-31120	GAUGE	1	SN: 60001-UP
6	01010-51230	BOLT	4	SN: 60001-UP
7	01602-21236	WASHER, SPRING	4	SN: 60001-UP
8	01643-31232	WASHER	4	SN: 60001-UP
9	103-54-34320	PLATE	1	SN: 60001-UP
10	01010-51020	BOLT	4	SN: 60001-UP
11	01643-31032	WASHER	4	SN: 60001-UP
12	07288-01016	HOSE	1	SN: 60001-UP
13	07288-01022	HOSE	1	SN: 60001-UP
14	08034-00414	BAND	1	SN: 60001-UP
15	07281-00197	CLAMP	4	SN: 60001-UP
16	08036-03014	CLIP	3	SN: 60001-UP
17	08036-02514	CLIP	1	SN: 60001-UP
18	01010-51016	BOLT	4	SN: 60001-UP
19	01602-21030	WASHER, SPRING	4	SN: 60001-UP
20	07700-40240	VALVE	1	SN: 60001-UP
21	124-04-21250	ERBO	1	SN: 60001-UP
22	07270-01235	TUBE	1	SN: 61663-UP
22	07270-01225	TUBE	1	SN: 60001-61662
23	07285-00150	CLIP	1	SN: 60001-UP

Reference: 1305



Reference: 1311

030070 FUEL TANK INSTALLATION STRAINER AND PIPING

Item	Part No.	Part Name	Qty	Options
1	07058-00001	CASE	1	SN: 60001-UP
2	154-04-12531	STRAINER	1	SN: 60001-UP
3	07002-04234	O RING	1	SN: 60001-UP
4	103-04-32220	BRACKET	1	SN: 60001-UP
5	01010-50830	BOLT	2	SN: 60001-UP
6	01643-30823	WASHER	2	SN: 60001-UP
7	01010-50820	BOLT	2	SN: 60001-UP
8	01602-20825	WASHER,SPRING	2	SN: 60001-UP
9	195-04-11430	ERBO	1	SN: 60001-UP
10	135-A90-1970	NIPPLE	1	SN: 60001-UP
11	07700-40240	VALVE	1	SN: 60001-UP
12	22W-44-14580	ERBO	1	SN: 60001-UP
13	103-04-32210	TUBE	1	SN: 60001-UP
14	07260-20906	HOSE	1	SN: 60001-UP
15	07281-00197	CLAMP	2	SN: 60001-UP
16	103-21-31260	BOSS	1	SN: 60001-UP
17	08036-01814	CLIP	1	SN: 60001-UP
18	01010-51050	BOLT	1	SN: 60001-UP

Reference: 1311

Get the complete PDF catalogue

Komatsu D21AG-6 (JPN) S/N 60001-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.