


PMD0811

Reference: B0000-01A0

030010 HEATER SWITCH (FORWARDED INDIVIDUALLY PARTS)

Item	Part No.	Part Name	Qty	Options
1	600-815-2170	SWITCH	1	SN: 45001-UP

Reference: B0000-01A0




Reference: B0000-02A0

030020 AIR CLEANER (FORWARDED INDIVIDUALLY PARTS)

Item	Part No.	Part Name	Qty	Options
1	6732-81-7510	BODY	1	SN: 45001-UP
1	600-181-6050	ELEMENT ASS'Y	1	SN: 45001-UP
1	600-181-6540	• ELEMENT ASS'Y, OUTER	1	SN: 45001-UP
2		• ☆ ELEMENT, OUTER	1	SN: 45001-UP
3	600-181-6570	• NUT, WING	1	SN: 45001-UP
4	600-181-6580	• WASHER, SEAL	1	SN: 45001-UP
5		• ☆ ELEMENT, INNER	1	SN: 45001-UP
6	600-181-9671	• NUT, AIR	1	SN: 45001-UP
7	600-181-7511	• WASHER, SEAL	1	SN: 45001-UP
8	600-181-6590	VALVE, DUST	1	SN: 45001-UP
9	08089-00000	SWITCH	1	SN: 45001-UP
10	565-44-15331	JOINT	1	SN: 49225-UP
10	07323-20100	ELBOW	1	SN: 45001-49224
11	281-35-13650	NIPPLE	1	SN: 45001-49224
12	6130-11-4511	BAND	2	SN: 45001-UP
12	6207-81-7190	□ BAND	2	SN: 45001-UP
13	6110-23-6520	BOLT	2	SN: 45001-UP
14	6110-21-6530	PIN	2	SN: 45001-UP
15	6110-21-6540	PIN, WITH THREAD	2	SN: 45001-UP

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead

Reference: B0000-02A0



00054820


Reference: B0000-02A1

030030 AIR CLEANER (FOR TRIMING DOZER)

Item	Part No.	Part Name	Qty	Options
1	6732-81-7510	BODY	1	SN: 45001-UP
	600-182-3400	ELEMENT ASS'Y	1	SN: 45001-UP
	600-181-6540	• ELEMENT ASS'Y, OUTER	1	SN: 45001-UP
2		• ☆ ELEMENT, OUTER	1	SN: 45001-UP
3	600-181-6570	• NUT, WING	1	SN: 45001-UP
4	600-181-6580	• WASHER, SEAL	1	SN: 45001-UP
5		• ☆ ELEMENT, INNER	1	SN: 45001-UP
6	600-181-9671	• NUT, AIR	1	SN: 45001-UP
7	600-181-7511	• WASHER, SEAL	1	SN: 45001-UP
8	600-181-6590	VALVE, DUST	1	SN: 45001-UP
9	08089-00000	SWITCH	1	SN: 45001-UP
10	565-44-15331	JOINT	1	SN: 49225-UP
10	07323-20100	ELBOW	1	SN: 45001-49224
11	281-35-13650	NIPPLE	1	SN: 45001-49224
12	6130-11-4511	BAND	2	SN: 45001-UP
12	6207-81-7190	□ BAND	2	SN: 45001-UP
13	6110-21-6530	PIN	2	SN: 45001-UP
14	6110-21-6540	PIN, WITH THREAD	2	SN: 45001-UP
15	6110-23-6520	BOLT	2	SN: 45001-UP
16	104-01-51610	PRE-CLEANER ASS'Y	1	SN: 49555-UP
16	600-182-8110	□ PRE-CLEANER ASS'Y	1	SN: 45001-49554

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead

Reference: B0000-02A1



P V 0 6 4 1 6


Reference: B0000-02A3

030040 AIR CLEANER (FORWARDED INDIVIDUALLY PARTS) (SANDY AND DUSTY SPEC.)

Item	Part No.	Part Name	Qty	Options
1	6732-81-7510	BODY	1	SN: 45001-UP
	600-181-6050	ELEMENT ASS'Y	1	SN: 45001-UP
	600-181-6540	• ELEMENT ASS'Y, OUTER	1	SN: 45001-UP
2		• • ☆ ELEMENT, OUTER	1	SN: 45001-UP
3	600-181-6570	• • NUT, WING	1	SN: 45001-UP
4	600-181-6580	• • WASHER, SEAL	1	SN: 45001-UP
5		• ☆ ELEMENT, INNER	1	SN: 45001-UP
6	600-181-9671	• NUT, AIR	1	SN: 45001-UP
7	600-181-7511	• WASHER, SEAL	1	SN: 45001-UP
8	600-181-6590	VALVE, DUST	1	SN: 45001-UP
9	08089-00000	SWITCH	1	SN: 45001-UP
10	565-44-15331	JOINT	1	SN: 49225-UP
10	07323-20100	ELBOW	1	SN: 45001-49224
11	281-35-13650	NIPPLE	1	SN: 45001-49224
12	6130-11-4511	BAND	2	SN: 45001-UP
12	6207-81-7190	□ BAND	2	SN: 45001-UP
13	6110-23-6520	BOLT	2	SN: 45001-UP
14	6110-21-6530	PIN	2	SN: 45001-UP
15	6110-21-6540	PIN, WITH THREAD	2	SN: 45001-UP
16	600-181-9390	CAP	1	SN: 45001-UP

Catalog signs: ☆ not supplied separately: assembly only □ part above may be used instead

Reference: B0000-02A3




P W 0 6 4 1 8

Reference: B0000-03A0

030050 SPARK ARESTER

Item	Part No.	Part Name	Qty	Options
1	6206-11-5380	SPARK ARRESTER	1	SN: 45001-UP

Reference: B0000-03A0




PJ6C483

Reference: B0000-03A1

030060 EXHAUST PIPE

Item	Part No.	Part Name	Qty	Options
1	6732-11-5730	PIPE,EXHAUST	1	SN: 45001-UP
2	6134-12-5910	CLAMP	1	SN: 45001-UP
3	6151-11-5670	WASHER	2	SN: 45001-UP
4	6114-11-5920	BOLT	1	SN: 45001-UP
5	01582-21411	NUT	2	SN: 45001-UP

Reference: B0000-03A1




PJ6C484

Reference: B0000-03A2

030070 EXHAUST PIPE (SHORT EXHAUST PIPE)

Item	Part No.	Part Name	Qty	Options
1	6151-11-5670	WASHER	2	SN: 45001-UP
2	01582-21411	NUT	2	SN: 45001-UP
3	6732-11-5750	PIPE,EXHAUST	1	SN: 45001-UP
4	6732-11-5760	CLAMP	1	SN: 45001-UP
5	01051-31415	BOLT	1	SN: 45001-UP

Reference: B0000-03A2



P0D3068


Reference: B0000-04A0

030080 WATER SEPARATOR (FORWARDED INDIVIDUALLY PARTS)

Item	Part No.	Part Name	Qty	Options
1	600-311-9732	WATER SEPARATOR A.,(SEE FIG.B9999-02D9)	1	SN: 48972-UP
1	600-311-9731	☐ WATER SEPARATOR A.,(SEE FIG.B9999-02D9)	1	SN: 45001-48971
2	07270-00850	TUBE	1	SN: 45001-UP
3	07285-00110	CLIP	1	SN: 45001-UP
4	6144-73-5750	JOINT	1	SN: 45001-UP
5	6144-71-5750	JOINT	1	SN: 45001-UP
5	07205-21014	JOINT	1	SN: 45001-UP
6	07005-01412	SEAL, WASHER	4	SN: 45001-UP
7	07206-31014	BOLT,JOINT	2	SN: 45001-UP

Catalog signs: ☐ part above may be used instead

Reference: B0000-04A0




PJ6A018

Reference: B0000-05A0

030090 FUEL LIFT PUMP (ORDERING TRANSFERRED PARTS)

Item	Part No.	Part Name	Qty	Options
1	6732-81-4111	PUMP,SUCTION	1	SN: 45001-UP

Reference: B0000-05A0



PJD4861

Reference: B0000-06A0

030100 CORROSION RESISTOR (ORDERING TRANSFERRED PARTS)

Item	Part No.	Part Name	Qty	Options
	6732-61-8300	HEAD ASS'Y	1	SN: 45001-UP
1	600-411-2410	• HEAD	1	SN: 45001-UP
2	600-411-2120	• VALVE ASS'Y	2	SN: 45001-UP
3	600-411-2130	• GASKET,CORROSION	2	SN: 45001-UP
4	600-411-1151	CARTRIDGE	1	SN: 45001-UP

Reference: B0000-06A0

Get the complete PDF catalogue

Komatsu D31P-20 S/N 45001-UP (Straight Tilt Dozer)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.