


FIG.1101
エンジン・トランス・アセンブリ
ENGINE MOUNTING PARTS




Reference: 1101

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	01011-31620	BOLT	2	SN: 6001-UP
2	113-01-21120	WASHER	4	SN: 6001-UP
3	113-01-21110	CUSHION	4	SN: 6001-UP
4	01011-31845	BOLT	2	SN: 6001-UP
5	135-01-31170	WASHER	2	SN: 6001-UP
6	135-01-31260	CUSHION	4	SN: 6001-UP
7	125-01-21230	SHIM, 1.2MM	4	SN: 6001-UP
8	120-01-31461	SPACER	2	SN: 6001-UP
9	01011-32030	BOLT	2	SN: 6001-UP
10	124-01-21330	SPACER	2	SN: 6001-UP
11	120-01-31451	SPACER	2	SN: 6001-UP
12	135-01-05120	SHIM KIT	2	SN: 6001-UP
12		• ☆ SHIM, 0.2MM	4	SN: 6001-UP
12		• ☆ SHIM, 1.0MM	4	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1101



Reference: 1123


030020 FUEL CONTROL LEVER AND LINKAGE

Item	Part No.	Part Name	Qty	Options
1	124-43-32151	LEVER	1	SN: 6001-UP
2	09304-00835	KNOB	1	SN: 6001-UP
3	04010-00516	KEY	1	SN: 6001-UP
4	01010-30830	BOLT	1	SN: 6001-UP
5	01602-00825	WASHER,SPRING	1	SN: 6001-UP
6	145-43-43190	BRACKET	1	SN: 6001-UP
7	01010-31020	BOLT	2	SN: 6001-UP
8	01602-01030	WASHER,SPRING	2	SN: 6001-UP
9	10E-43-11141	SHAFT	1	SN: 6001-UP
10	124-43-32161	LEVER	1	SN: 6001-UP
11	04010-00516	KEY	1	SN: 6001-UP
12	10E-43-11160	FACING	2	SN: 6001-UP
13	10E-43-11190	SPRING	1	SN: 6001-UP
14	10E-43-11180	RETAINER	1	SN: 6001-UP
15	01590-11215	NUT	1	SN: 6001-UP
16	01641-21223	WASHER	1	SN: 6001-UP
17	04050-03022	PIN,COTTER	1	SN: 6001-UP
18	124-43-32171	BRACKET	1	SN: 6001-UP
19	01010-31025	BOLT	2	SN: 6001-UP
20	01602-01030	WASHER,SPRING	2	SN: 6001-UP
21	01643-31032	WASHER	2	SN: 6001-UP
22	124-43-26310	PIN	1	SN: 6001-UP
23	124-43-21170	SPRING	1	SN: 6001-UP
24	04025-00424	PIN,SPRING	1	SN: 6001-UP
25	125-43-24190	ROD	1	SN: 6001-UP
26	04205-10616	PIN	1	SN: 6001-UP
27	04050-11610	PIN,COTTER	1	SN: 6001-UP
28	10E-43-12630	SPRING	1	SN: 6001-UP
29	01016-31070	BOLT	2	SN: 6001-UP
30	01580-11008	NUT	2	SN: 6001-UP
31	01643-31032	WASHER	2	SN: 6001-UP
32	124-43-32192	CABLE	1	SN: 6001-UP
33	04211-20500	YOKE	1	SN: 6001-UP
34	04250-41056	END,ROD	1	SN: 6001-UP
35	01582-11008	NUT	1	SN: 6001-UP
36	04205-10514	PIN	1	SN: 6001-UP
37	04050-11208	PIN,COTTER	1	SN: 6001-UP
38	120-43-32391	BOLT	1	SN: 6001-UP
39	04254-01032	SPACER	1	SN: 6001-UP
40	01590-10809	NUT	1	SN: 6001-UP
41	04050-12015	PIN,COTTER	1	SN: 6001-UP
42	125-43-24430	CAP	1	SN: 6001-UP
43	124-43-32221	PLATE	1	SN: .-UP
43	124-43-32351	□ PLATE	1	SN: 6001-.
44	01010-30820	BOLT	2	SN: 6001-UP
45	01602-00825	WASHER,SPRING	2	SN: 6001-UP
46	08036-10814	CLIP	1	SN: 6001-UP

Catalog signs: ☐ part above may be used instead

Reference: 1123

FIG-1124 D41A-3 S/N 6001-UP (Power Angle Tilt Dozer)
FUEL CONTROL LEVER AND LINKAGE (WITH DECELERATOR PEDAL)



Reference: 1124

030030 FUEL CONTROL LEVER AND LINKAGE (WITH DECELERATOR PEDAL)

Item	Part No.	Part Name	Qty	Options
1	124-43-32151	LEVER	1	SN: 6001-UP
2	09304-00835	KNOB	1	SN: 6001-UP
3	04010-00516	KEY	1	SN: 6001-UP
4	01010-50830	BOLT	1	SN: 6001-UP
5	01602-20825	WASHER,SPRING	1	SN: 6001-UP
6	145-43-43190	BRACKET	1	SN: 6001-UP
7	01010-51020	BOLT	2	SN: 6001-UP
8	01602-21030	WASHER,SPRING	2	SN: 6001-UP
9	10E-43-11141	SHAFT	1	SN: 6001-UP
10	124-43-32161	LEVER	1	SN: 6001-UP
11	04010-00516	KEY	1	SN: 6001-UP
12	10E-43-11160	FACING	2	SN: 6001-UP
13	10E-43-11190	SPRING	1	SN: 6001-UP
14	10E-43-11180	RETAINER	1	SN: 6001-UP
15	01590-11215	NUT	1	SN: 6001-UP
16	01641-21223	WASHER	1	SN: 6001-UP
17	04050-13022	PIN,COTTER	1	SN: 6001-UP
18	124-43-32171	BRACKET	1	SN: 6001-UP
19	01010-51025	BOLT	2	SN: 6001-UP
20	01602-21030	WASHER,SPRING	2	SN: 6001-UP
21	01643-31032	WASHER	2	SN: 6001-UP
22	124-43-26310	PIN	1	SN: 6001-UP
23	124-43-21170	SPRING	1	SN: 6001-UP
24	04025-00424	PIN,SPRING	1	SN: 6001-UP
25	125-43-24190	ROD	1	SN: 6001-UP
26	04205-10616	PIN	1	SN: 6001-UP
27	04050-11610	PIN,COTTER	1	SN: 6001-UP
28	10E-43-12630	SPRING	1	SN: 6001-UP
29	01016-51070	BOLT	2	SN: 6001-UP
30	01580-11008	NUT	2	SN: 6001-UP
31	01643-31032	WASHER	2	SN: 6001-UP
32	124-43-32341	CABLE	1	SN: 6001-UP
33	04211-20500	YOKE	1	SN: 6001-UP
34	04205-10514	PIN	1	SN: 6001-UP
35	04050-11208	PIN,COTTER	1	SN: 6001-UP
36	124-43-32311	COUPLING	1	SN: 6001-UP
37	124-43-26372	PLATE	1	SN: 6001-UP
38	01598-10608	NUT	2	SN: 6001-UP
39	01640-20610	WASHER	2	SN: 6001-UP
40	135-43-15821	SPRING	1	SN: 6001-UP
41	124-43-32321	NUT	1	SN: 6001-UP


Item	Part No.	Part Name	Qty	Options
42	01583-11006	NUT	1	SN: 6001-UP
43	04250-41056	END	1	SN: 6001-UP
44	01582-11008	NUT	1	SN: 6001-UP
45	124-43-32331	LEVER	1	SN: 6001-UP
46	120-43-32391	BOLT	1	SN: 6001-UP
47	04254-01032	SPACER	1	SN: 6001-UP
48	01590-10809	NUT	1	SN: 6001-UP
49	04050-12015	PIN,COTTER	1	SN: 6001-UP
50	125-43-24430	CAP	1	SN: 6001-UP
51	124-43-32221	PLATE	1	SN: .-UP
51	124-43-32351	 PLATE	1	SN: 6001-.
52	01010-50820	BOLT	2	SN: 6001-UP
53	01602-20825	WASHER,SPRING	2	SN: 6001-UP
54	08036-10814	CLIP	1	SN: 6001-UP

Catalog signs:  part above may be used instead

Reference: 1124

FIG.1125

デシレターペダルとリンク
DECELERATOR PEDAL AND LINKAGE (#7424-)



Reference: 1125


030040 DECELERATOR PEDAL AND LINKAGE (WITH DECELERATOR PEDAL)

Item	Part No.	Part Name	Qty	Options
1	124-43-32391	FLOOR,PLATE	1	SN: 6001-UP
2	06120-02016	BEARING,NEEDLE	2	SN: 6001-UP
3	06122-02004	SEAL,BEARING	4	SN: 6001-UP
4	07020-00000	FITTING,GREASE	2	SN: 6001-UP
5	01016-50840	BOLT	1	SN: 6001-UP
6	01016-50850	BOLT	1	SN: 6001-UP
7	01580-10806	NUT	2	SN: 6001-UP
8	124-43-32381	PEDAL	1	SN: 6001-UP
9	124-43-32361	LEVER	1	SN: 6001-UP
10	04010-00519	KEY	1	SN: 6001-UP
11	01010-50830	BOLT	1	SN: 6001-UP
12	01602-20825	WASHER,SPRING	1	SN: 6001-UP
13	01640-22032	WASHER	1	SN: 6001-UP
14	04250-40847	END	1	SN: 6001-UP
15	04245-40862	ROD	1	SN: 6001-UP
16	131-43-58210	JOINT	1	SN: 6001-UP

Item	Part No.	Part Name	Qty	Options
17	01508-20805	NUT	1	SN: 6001-UP
18	01580-10806	NUT	2	SN: 6001-UP
19	124-43-32371	ROD	1	SN: 6001-UP
20	124-43-26430	PIN	1	SN: 6001-UP
21	01580-10806	NUT	1	SN: 6001-UP
22	01602-20825	WASHER,SPRING	1	SN: 6001-UP
23	01593-11008	NUT	1	SN: 6001-UP
24	01643-31032	WASHER	2	SN: 6001-UP
25	04050-12018	PIN,COTTER	1	SN: 6001-UP

Reference: 1125

FIG.1131
RADIATOR AND PIPING



Reference: 1131

030050 RADIATOR AND PIPING


Item	Part No.	Part Name	Qty	Options
	120-03-00011	RADIATOR ASS'Y	1	SN: 6001-UP
1		• ☆ CORE	1	SN: 6001-UP
2	113-03-21240	• CAP	1	SN: 6001-UP
3	07042-00415	• PLUG	1	SN: 6001-UP
4	07730-20004	VALVE,DRAIN	1	SN: 6001-UP
5	07270-01520	TUBE,DRAIN	1	SN: 6001-UP
6	07280-01920	CLAMP	1	SN: 6001-UP
7	113-03-21160	SEAT	4	SN: 6001-UP
8	113-03-21170	SPACER	2	SN: 6001-UP
9	113-03-21180	PLATE	2	SN: 6001-UP
10	01010-31070	BOLT	2	SN: 6001-UP
11	01602-01030	WASHER,SPRING	2	SN: 6001-UP
12	113-03-21190	BRACKET	1	SN: 6001-UP
13	135-03-12110	DAMPER	1	SN: 6001-UP
14	01010-51235	BOLT	2	SN: 6001-UP
15	01602-21236	WASHER,SPRING	2	SN: 6001-UP
16	01643-31232	WASHER	2	SN: 6001-UP
17	01010-31460	BOLT	1	SN: 6001-UP
18	01602-01442	WASHER,SPRING	1	SN: 6001-UP
19	01010-31035	BOLT	1	SN: 6001-UP
20	01643-31032	WASHER	1	SN: 6001-UP
21	120-03-32122	SHROUD,UPPER	1	SN: 6001-UP
22	120-03-32132	SHROUD,LOWER	1	SN: 6001-UP
23	01010-30816	BOLT	8	SN: 6001-UP
23	01010-30820	BOLT,(FOR CORE GRID)	8	SN: 6001-UP
24	01602-00825	WASHER	8	SN: 6001-UP
25	01643-30823	WASHER	8	SN: 6001-UP
26	120-03-32251	HOSE,INLET	1	SN: 6001-UP
27	120-03-32261	HOSE,OUTLET	1	SN: 6001-UP
28	07281-00709	CLAMP	3	SN: 6001-UP
29	07281-00809	CLAMP	1	SN: 6001-UP
30	113-03-21140	TUBE	1	SN: 6001-UP
31	120-03-32142	GUARD,FAN	1	SN: 6001-UP
31	120-Y79-7210	GUARD,(FOR AIR CONDITIONER TYPE-2)	1	SN: 6001-UP

Item	Part No.	Part Name	Qty	Options
32	120-03-32152	GUARD,FAN	1	SN: 6001-UP
33	01010-31025	BOLT	5	SN: 6001-UP
34	01602-01030	WASHER,SPRING	5	SN: 6001-UP
35	120-03-32281	CORE GRID,CORE	1	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1131

FIG.1142
FUEL TANK AND PIPING



Reference: 1142

030060 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
	120-04-00011	FUEL TANK ASS'Y	1	SN: 6001-UP
1		• ☆ TANK	1	SN: 6001-UP
2	07056-16415	• STRAINER	1	SN: 6001-UP
3	07057-03266	• RING,SNAP	1	SN: 6001-UP
4	120-04-31132	• GAUGE,FUEL	1	SN: 6001-UP
5	07050-20920	• CAP ASS'Y	1	SN: 6001-UP
6	07050-20902	• • GASKET	1	SN: 6001-UP
7	120-04-31121	BLOCK	2	SN: 6001-UP
8	01011-31600	BOLT	4	SN: 6001-UP
9	01643-01645	WASHER	4	SN: 6001-UP
10	113-04-22130	NIPPLE	2	SN: 6001-UP
11	07005-02012	SEAL	2	SN: 6001-UP
12	113-04-22190	BOLT,JOINT	2	SN: 6001-UP
13	07005-01412	GASKET	2	SN: 6001-UP
14	07700-40240	VALVE	2	SN: 6001-UP
15	120-04-31231	NIPPLE	1	SN: 6001-UP
16	120-04-31221	HOSE	1	SN: 6001-UP
17	120-04-31211	TUBE	1	SN: 6001-UP
18	07281-00197	CLAMP	2	SN: 6001-UP
19	08036-21414	CLIP	2	SN: 6001-UP
20	111-04-33180	CLIP	3	SN: 6001-UP
21	01010-31025	BOLT	4	SN: 6001-UP
22	01602-01030	WASHER,SPRING	4	SN: 6001-UP
23	113-04-22150	NIPPLE	1	SN: 6001-UP
24	07270-01260	TUBE	1	SN: 6001-UP
25	07281-00197	CLAMP	1	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1142

Get the complete PDF catalogue

Komatsu D41A-3 S/N 6001-UP (Power Angle Tilt Dozer)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.

Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.