


FIG.1101

エンジン・トランス・アセンブリ
ENGINE MOUNTING PARTS




Reference: 1101

030010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	01011-31620	BOLT	2	SN: 6001-UP
2	113-01-21120	WASHER	4	SN: 6001-UP
3	113-01-21110	CUSHION	4	SN: 6001-UP
4	01011-31845	BOLT	2	SN: 6001-UP
5	135-01-31170	WASHER	2	SN: 6001-UP
6	135-01-31260	CUSHION	4	SN: 6001-UP
7	125-01-21230	SHIM, 1.2MM	4	SN: 6001-UP
8	120-01-31461	SPACER	2	SN: 6001-UP
9	01011-32030	BOLT	2	SN: 6001-UP
10	124-01-21330	SPACER	2	SN: 6001-UP
11	120-01-31451	SPACER	2	SN: 6001-UP
12	135-01-05120	SHIM KIT	2	SN: 6001-UP
12		• ☆ SHIM, 0.2MM	4	SN: 6001-UP
12		• ☆ SHIM, 1.0MM	4	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1101



Reference: 1123


030020 FUEL CONTROL LEVER AND LINKAGE

Item	Part No.	Part Name	Qty	Options
1	124-43-32151	LEVER	1	SN: 6001-UP
2	09304-00835	KNOB	1	SN: 6001-UP
3	04010-00516	KEY	1	SN: 6001-UP
4	01010-30830	BOLT	1	SN: 6001-UP
5	01602-00825	WASHER,SPRING	1	SN: 6001-UP
6	145-43-43190	BRACKET	1	SN: 6001-UP
7	01010-31020	BOLT	2	SN: 6001-UP
8	01602-01030	WASHER,SPRING	2	SN: 6001-UP
9	10E-43-11141	SHAFT	1	SN: 6001-UP
10	124-43-32161	LEVER	1	SN: 6001-UP
11	04010-00516	KEY	1	SN: 6001-UP
12	10E-43-11160	FACING	2	SN: 6001-UP
13	10E-43-11190	SPRING	1	SN: 6001-UP
14	10E-43-11180	RETAINER	1	SN: 6001-UP
15	01590-11215	NUT	1	SN: 6001-UP
16	01641-21223	WASHER	1	SN: 6001-UP
17	04050-03022	PIN,COTTER	1	SN: 6001-UP
18	124-43-32171	BRACKET	1	SN: 6001-UP
19	01010-31025	BOLT	2	SN: 6001-UP
20	01602-01030	WASHER,SPRING	2	SN: 6001-UP
21	01643-31032	WASHER	2	SN: 6001-UP
22	124-43-26310	PIN	1	SN: 6001-UP
23	124-43-21170	SPRING	1	SN: 6001-UP
24	04025-00424	PIN,SPRING	1	SN: 6001-UP
25	125-43-24190	ROD	1	SN: 6001-UP
26	04205-10616	PIN	1	SN: 6001-UP
27	04050-11610	PIN,COTTER	1	SN: 6001-UP
28	10E-43-12630	SPRING	1	SN: 6001-UP
29	01016-31070	BOLT	2	SN: 6001-UP
30	01580-11008	NUT	2	SN: 6001-UP
31	01643-31032	WASHER	2	SN: 6001-UP
32	124-43-32192	CABLE	1	SN: 6001-UP
33	04211-20500	YOKE	1	SN: 6001-UP
34	04250-41056	END,ROD	1	SN: 6001-UP
35	01582-11008	NUT	1	SN: 6001-UP
36	04205-10514	PIN	1	SN: 6001-UP
37	04050-11208	PIN,COTTER	1	SN: 6001-UP
38	120-43-32391	BOLT	1	SN: 6001-UP
39	04254-01032	SPACER	1	SN: 6001-UP
40	01590-10809	NUT	1	SN: 6001-UP
41	04050-12015	PIN,COTTER	1	SN: 6001-UP
42	125-43-24430	CAP	1	SN: 6001-UP
43	124-43-32221	PLATE	1	SN: .-UP
43	124-43-32351	□ PLATE	1	SN: 6001-.
44	01010-30820	BOLT	2	SN: 6001-UP
45	01602-00825	WASHER,SPRING	2	SN: 6001-UP
46	08036-10814	CLIP	1	SN: 6001-UP

Catalog signs: ☐ part above may be used instead

Reference: 1123

FIG.1131
RADIATOR AND PIPING



Reference: 1132

030030 RADIATOR AND PIPING

Item	Part No.	Part Name	Qty	Options
	120-03-00011	RADIATOR ASS'Y	1	SN: 6001-UP
1		• ☆ CORE	1	SN: 6001-UP
2	113-03-21240	• CAP	1	SN: 6001-UP
3	07042-00415	• PLUG	1	SN: 6001-UP
4	07730-20004	VALVE	1	SN: 6001-UP
5	07270-01520	TUBE	1	SN: 6001-UP
6	07280-01920	CLAMP	1	SN: 6001-UP
7	113-03-21160	SEAT	4	SN: 6001-UP
8	113-03-21170	SPACER	2	SN: 6001-UP
9	113-03-21180	PLATE	2	SN: 6001-UP
10	01010-31070	BOLT	2	SN: 6001-UP
11	01602-01030	WASHER,SPRING	2	SN: 6001-UP
12	113-03-21190	BRACKET	1	SN: 6001-UP
13	135-03-12110	DAMPER	1	SN: 6001-UP
14	01010-31035	BOLT	2	SN: 6001-UP
15	01602-01030	WASHER,SPRING	2	SN: 6001-UP
16	01643-31032	WASHER	2	SN: 6001-UP
17	01010-31460	BOLT	1	SN: 6001-UP
18	01602-01442	WASHER,SPRING	1	SN: 6001-UP
19	01010-31035	BOLT	1	SN: 6001-UP
20	01643-31032	WASHER	1	SN: 6001-UP
21	120-03-32122	SHROUD,UPPER	1	SN: 6001-UP
22	120-03-32132	SHROUD,LOWER	1	SN: 6001-UP
23	01010-30816	BOLT	8	SN: 6001-UP
23	01010-30820	BOLT,(FOR CORE GRID)	8	SN: 6001-UP
24	01602-00825	WASHER,SPRING	8	SN: 6001-UP
25	01643-30823	WASHER	8	SN: 6001-UP
26	120-03-32251	HOSE,INLET	1	SN: 6001-UP
27	120-03-32261	HOSE,OUTLET	1	SN: 6001-UP
28	07281-00709	CLAMP	3	SN: 6001-UP
29	07281-00809	CLAMP	1	SN: 6001-UP
30	113-03-21140	TUBE	1	SN: 6001-UP
31	12F-03-31112	GUARD	1	SN: 6001-UP
31	120-Y79-7220	GUARD,(FOR AIR CONDITIONER TYPE-2)	1	SN: 6001-UP


Item	Part No.	Part Name	Qty	Options
32	120-03-32152	GUARD	1	SN: 6001-UP
33	01010-31025	BOLT	5	SN: 6001-UP
34	01602-01030	WASHER,SPRING	5	SN: 6001-UP
35	120-03-32281	CORE GRID,CORE	1	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1132

FIG.1141

燃料タンク及び配管
FUEL TANK AND PIPING



Reference: 1141


030040 FUEL TANK AND PIPING

Item	Part No.	Part Name	Qty	Options
	120-04-00012	FUEL TANK ASS'Y	1	SN: 6001-UP
1		• ☆ TANK	1	SN: 6001-UP
2	07056-16415	• STRAINER	1	SN: 6001-UP
3	07057-03266	• RING,SNAP	1	SN: 6001-UP
4	120-04-31132	• GAUGE,FUEL	1	SN: 6001-UP
5	07050-20920	• CAP ASS'Y	1	SN: 6001-UP
6	07050-20902	• GASKET	1	SN: 6001-UP
7	120-04-31121	BLOCK	2	SN: 6001-UP
8	01011-31600	BOLT	4	SN: 6001-UP
9	01643-01645	WASHER	4	SN: 6001-UP
10	113-04-22130	NIPPLE	2	SN: 6001-UP
11	07005-02012	SEAL	2	SN: 6001-UP
12	113-04-22190	BOLT,JOINT	2	SN: 6001-UP
13	07005-01412	GASKET	2	SN: 6001-UP
14	07700-40240	VALVE	2	SN: 6001-UP
15	120-04-31231	NIPPLE	1	SN: 6001-UP
16	120-04-31221	HOSE	1	SN: 6001-UP
17	120-04-31211	TUBE	1	SN: 6001-UP
18	07281-00197	CLAMP	2	SN: 6001-UP
19	08036-21414	CLIP	2	SN: 6001-UP
20	111-04-33180	CLIP	3	SN: 6001-UP
21	01010-31025	BOLT	4	SN: 6001-UP
22	01602-01030	WASHER,SPRING	4	SN: 6001-UP
22A	01643-31032	WASHER	2	SN: 6001-UP
23	124-04-21250	ELBOW	1	SN: 6001-UP
24	07270-01260	TUBE	1	SN: 6001-UP
25	07281-00197	CLAMP	1	SN: 6001-UP
26	120-04-31141	BRACKET	1	SN: 6001-UP
27	01010-31225	BOLT	4	SN: 6001-UP
28	01602-01236	WASHER,SPRING	4	SN: 6001-UP

Catalog signs: ☆ not supplied separately: assembly only

Reference: 1141

FIG. 1151
BATTERY



D41P-3

Reference: 1151


030050 BATTERY

Item	Part No.	Part Name	Qty	Options
1	08000-32212	BATTERY, WET(115E41R,(FOR JAPAN)	2	SN: 7025-UP
1	08000-02212	■ BATTERY (115F51),(FOR JAPAN) (08000-32212,113-06-21170)	2	SN: 6001-7024
1	08000-12212	BATTERY (115F51),(EXCEPT JAPAN)	2	SN: 6001-UP
1	08000-02220	BATTERY (190H52),(FOR JAPAN)	2	SN: 6001-UP
1	08000-12220	BATTERY (190H52),(EXCEPT JAPAN)	2	SN: 6001-UP
2	08000-00000	TERMINAL, (+)	2	SN: 6001-UP
2	08000-00001	TERMINAL, (-)	2	SN: 6001-UP
3	01010-30830	• BOLT	1	SN: 6001-UP
4	01580-00806	• NUT	1	SN: 6001-UP
5	01050-31018	• BOLT	1	SN: 6001-UP
6	01640-01016	• WASHER	1	SN: 6001-UP
7	120-06-31131	PLATE	1	SN: 6001-UP
8	01010-31230	BOLT	2	SN: 6001-UP
9	01010-31240	BOLT	2	SN: 6001-UP
10	01602-01236	WASHER,SPRING	4	SN: 6001-UP
11	120-06-31141	HOLDER,BATTERY	2	SN: 6001-UP
12	120-06-31151	BOLT	2	SN: 6001-UP
13	120-06-31161	ROD	2	SN: 6001-UP
14	01580-11008	NUT	8	SN: 6001-UP
15	120-06-31171	PLATE	1	SN: 6001-UP
16	08088-10000	SWITCH,BATTERY RELAY	1	SN: 6001-UP
17	01010-30825	BOLT	2	SN: 6001-UP
18	01602-00825	WASHER,SPRING	2	SN: 6001-UP
19	01643-30823	WASHER	2	SN: 6001-UP

Catalog signs: ■ may be used instead of described part

Reference: 1151

FIG.1155
INSTRUMENT PANEL



Reference: 1155


030060 INSTRUMENT PANEL

Item	Part No.	Part Name	Qty	Options
1	120-06-31121	PANEL,L.H.	1	SN: 6001-UP
2	120-06-31111	PANEL,R.H.	1	SN: 6001-UP
3	01225-40616	SCREW	8	SN: 6001-UP
4	08144-12400	LAMP,PANEL	2	SN: 6001-UP
5	08687-22402	METER,SERVICE	2	SN: 6001-UP
5	08687-22400	☒ METER,SERVICE	1	SN: (6001-6292)
6	144-06-32130	GAUGE,WATER TEMPERATURE	1	SN: 6001-UP
7	09414-00053	CAP	2	SN: 6001-UP
8	125-06-22220	LAMP,CHARGE	1	SN: 6001-UP
9	125-06-22210	LAMP,OIL PRESSURE	1	SN: 6001-UP
10	600-815-2371	SIGNAL,HEATER	1	SN: 6001-UP
11	08061-60010	SWITCH,LAMP	1	SN: 6001-UP
12	08061-40070	SWITCH,HEATER	1	SN: 6001-UP
13	08086-10000	SWITCH,STARTING	1	SN: 6001-UP
14	08671-01110	HOSE	1	SN: 6001-UP
15	01010-30610	BOLT	2	SN: 6001-UP
16	01602-00619	WASHER,SPRING	2	SN: 6001-UP
17	08670-50001	INDICATOR,DUST (JAPANESE-ENGLISH)	1	SN: 6001-UP
17	08670-70001	INDICATOR,DUST (GERMAN)	1	SN: 6001-UP
17	08670-50005	INDICATOR,DUST (FRENCH)	1	SN: 6001-UP
18	125-06-21110	BOX,FUSE	1	SN: 6001-UP
19	01220-40520	SCREW	2	SN: 6001-UP
20	01601-00513	WASHER,SPRING	2	SN: 6001-UP
21	08040-01000	FUSE, 10A	2	SN: 6001-UP
21	08040-02000	FUSE, 20A	2	SN: 6001-UP

Catalog signs: ☒ discontinued: use part above

Reference: 1155

FIG. 1161
ELECTRICAL SYSTEM (1/2)



Reference: 1161

030070 ELECTRICAL SYSTEM (1/2)

Item	Part No.	Part Name	Qty	Options
1	120-06-33291	BRACKET,L.H.	1	SN: 6001-UP
1	120-06-33281	BRACKET,R.H.	1	SN: 6001-UP
2	01010-31225	BOLT	6	SN: 6001-UP
3	01602-01236	WASHER,SPRING	6	SN: 6001-UP
4	08128-22400	LAMP ASS'Y	2	SN: 6001-UP
5	08113-02480	• BULB, 80W	1	SN: 6001-UP
6	08128-00003	• HOLDER	1	SN: 6001-UP
7	01640-21426	WASHER	2	SN: 6001-UP
8	120-06-33111	WIRE,L.H.	1	SN: 6001-UP
8	120-06-33121	WIRE,R.H.	1	SN: 6001-UP
9	130-06-44711	GROMMET	2	SN: 6001-UP
10	08160-22400	HORN	1	SN: 6001-UP
11	01010-30816	BOLT	2	SN: 6001-UP
12	01602-00825	WASHER,SPRING	2	SN: 6001-UP
13	120-06-31262	WIRE	1	SN: 6001-UP
14	08035-01510	CLIP	6	SN: 6001-UP
15	01010-31016	BOLT	6	SN: 6001-UP
16	01602-01030	WASHER,SPRING	6	SN: 6001-UP
17	120-06-31272	WIRE	1	SN: 6001-UP
18	08035-01510	CLIP	3	SN: 6001-UP
19	01010-31016	BOLT	3	SN: 6001-UP
20	01602-01030	WASHER,SPRING	3	SN: 6001-UP
21	120-06-33322	WIRE	1	SN: 6001-UP
22	130-06-64160	PLATE	1	SN: 6001-UP
23	01010-30616	BOLT	2	SN: 6001-UP
24	01602-00619	WASHER,SPRING	2	SN: 6001-UP
25	08035-03014	CLIP	1	SN: 6001-UP
26	125-06-22250	CAP	2	SN: 6001-UP
27	120-06-33333	WIRE	1	SN: 6001-UP
28	01580-10605	NUT	1	SN: 6001-UP
29	01602-00619	WASHER,SPRING	1	SN: 6001-UP
30	120-06-33181	WIRE	1	SN: 6001-UP
31	120-06-33312	WIRE	1	SN: 6001-UP
32	08035-02514	CLIP	1	SN: 6001-UP
33	01010-31220	BOLT	1	SN: 6001-UP
34	01602-01236	WASHER,SPRING	1	SN: 6001-UP
35	08035-01510	CLIP	1	SN: 6001-UP
36	08038-02027	CAP	1	SN: 6001-UP
37	08038-00519	CAP	3	SN: 6001-UP
38	08034-00414	BAND	4	SN: 6001-UP
39	120-06-33342	WIRE	1	SN: 6001-UP
40	08035-02510	CLIP	1	SN: 6001-UP
41	08038-00518	CAP	2	SN: 6001-UP
42	08034-00519	BAND	2	SN: 6001-UP
43	08034-00414	BAND	1	SN: 6001-UP
44	08028-14025	WIRE, 250MM	1	SN: 6001-UP

Get the complete PDF catalogue

Komatsu D41P-3 S/N 6001-UP (Straight Tilt Dozer)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.