





Reference: 1201

030010 GENERATOR ASS'Y

Item	Part No.	Part Name	Qty	Options
	DY81913-01302	GENERATOR ASS'Y	1	SN: 5001-UP
1	DY81910-00002	• ROTOR ASS'Y	1	SN: 5001-UP
2	DY81710-70002	• FAN	1	SN: 5001-UP
3	DY00121-12040	• BOLT	8	SN: 5001-UP
4	DY00425-12000	• WASHER, SPRING	8	SN: 5001-UP
5	DY81716-11003	• DISK, COUPLING	9	SN: 5001-UP
6	DY81710-15003	• PLATE, BALANCE	1	SN: 5001-UP
7	DY00121-16040	• BOLT	8	SN: 5001-UP
8	DY00426-16000	• WASHER, SPRING	8	SN: 5001-UP
9	DY81710-26003	• PLATE, RECTIFIER	1	SN: 5001-UP
10	DY06018-21349	• RECTIFIER, PT 3610, RE	3	SN: 5001-UP
11	DY06018-22615	• ABSORBER, SURGE	1	SN: 5001-UP
12	DY81710-20004	• WASHER, INSULATOR	1	SN: 5001-UP
13	DY81710-20504	• WASHER, INSULATOR	1	SN: 5001-UP
14	DY00101-10020	• BOLT	6	SN: 5001-UP
15	DY00400-10000	• WASHER, SPRING	6	SN: 5001-UP
16	DY06010-00209	• WEIGHT ASS'Y	1	SN: 5001-UP
17	DY00708-06312	• BEARING, 6312 DU	1	SN: 5001-UP
18	DY00800-00060	• RING, SNAP	1	SN: 5001-UP
19	DY81716-14003	• RING, COUPLING	1	SN: 5001-UP
20	DY00121-12035	• BOLT	8	SN: 5001-UP
21	DY00425-12000	• WASHER, SPRING	8	SN: 5001-UP
22	DY81913-40303	• STATOR ASS'Y	1	SN: 5001-UP
23	DY02261-00400	• SEAL, RUBBER	1	SN: 5001-UP
24	DY81713-23004	• BRACKET ASS'Y	1	SN: 5001-UP
25	DY02233-00130	• SEAL, RUBBER	1	SN: 5001-UP
26	DY81913-23003	• BRACKET ASS'Y	1	SN: 5001-UP
27	DY02212-00320	• SEAL, RUBBER	1	SN: 5001-UP
28	DY00101-10035	• BOLT	2	SN: 5001-UP
29	DY00412-10000	• WASHER	2	SN: 5001-UP
30	DY81713-24003	• COVER	1	SN: 5001-UP
31	DY02260-00270	• SEAL, RUBBER	2	SN: 5001-UP
32	DY02250-00480	• SEAL, RUBBER	1	SN: 5001-UP
33	DY00101-06016	• BOLT	6	SN: 5001-UP
34	DY00400-06000	• WASHER, SPRING	6	SN: 5001-UP
35	DY00412-06000	• WASHER	6	SN: 5001-UP
36	DY81713-15002	• BRACKET, END	1	SN: 5001-UP
37	DY81713-50003	• FIELD ASS'Y, EXCITER	1	SN: 5001-UP
38	DY00121-10060	• BOLT	6	SN: 5001-UP
39	DY00426-10000	• WASHER, SPRING	6	SN: 5001-UP
40	DY00412-10000	• WASHER	6	SN: 5001-UP
41	DY08450-44904	• GROMMET	1	SN: 5001-UP
42	DY00101-12040	• BOLT	8	SN: 5001-UP
43	DY00400-12000	• WASHER, SPRING	8	SN: 5001-UP
44	DY00412-12000	• WASHER	8	SN: 5001-UP
45	DY81713-10004	• COVER, BEARING	1	SN: 5001-UP
46	DY81713-12004	• GASKET, BEARING	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
47	DY81713-31003	• COVER,END BRACKET	1	SN: 5001-UP
48	DY00101-06016	• BOLT	12	SN: 5001-UP
49	DY00400-06000	• WASHER,SPRING	12	SN: 5001-UP
50	DY00412-06000	• WASHER	12	SN: 5001-UP
51	DY81713-33003	• COVER,END BRACKET	1	SN: 5001-UP
52	DY00101-06030	• BOLT	2	SN: 5001-UP
53	DY00400-06000	• WASHER,SPRING	2	SN: 5001-UP
54	DY00412-06000	• WASHER	2	SN: 5001-UP
55	DY00121-12035	• BOLT	12	SN: 5001-UP
56	DY00425-12000	• WASHER,SPRING	12	SN: 5001-UP
57	DY81713-32003	• COVER,FAN	1	SN: 5001-UP
58	DY06050-00012	RUBBER,SUSPENSION	2	SN: 5001-UP
59	DY00300-20000	NUT	4	SN: 5001-UP
60	DY00400-20000	WASHER,SPRING	4	SN: 5001-UP

Reference: 1201




Reference: 2201

030020 CONTROL BOX ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY82018-12512	BOX,CONTROL	1	SN: 5001-UP
2	DY06018-01168	TRANSFORMER,CURRENT, AMMETER	2	SN: 5001-UP
3	DY00271-06012	SCREW	4	SN: 5001-UP
4	DY06018-05951	CIRCUIT BREAKER	1	SN: 5001-UP
5	DY06018-02523	• HANDLE,CIRCUIT BREAKER	1	SN: 5001-UP
6	DY06018-20625	REGULATOR,AUTOMATIC VOLTAGE	1	SN: 5001-UP
7	DY00271-05012	SCREW	4	SN: 5001-UP
8	DY06018-23240	RECTIFIER	1	SN: 5001-UP
9	DY00271-05016	SCREW	1	SN: 5001-UP
10	DY06018-20193	CONDENSER	1	SN: 5001-UP
11	DY00271-03010	SCREW	2	SN: 5001-UP
12	DY06018-20851	RELAY,OVER CURRENT	1	SN: 5001-UP
13	DY00271-04016	SCREW	2	SN: 5001-UP
14	DY06018-23757	RELAY	2	SN: 5001-UP
15	DY06018-23143	SOCKET,RELAY	2	SN: 5001-UP
16	DY06018-24400	HOLDER	2	SN: 5001-UP
17	DY00271-04016	SCREW	4	SN: 5001-UP
18	DY08018-50004	UNIT,RESISTOR	1	SN: 5001-UP
19	DY00210-05020	SCREW	1	SN: 5001-UP
20	DY00400-05000	WASHER,SPRING	1	SN: 5001-UP
21	DY00412-05000	WASHER	1	SN: 5001-UP
22	DY00300-06000	NUT	1	SN: 5001-UP
23	DY06018-30715	SWITCH,VOLTAGE SELECTOR	1	SN: 5001-UP
24	600-815-1252	RELAY,EMERGENCY	1	SN: 5001-UP
25	DY00171-06016	BOLT	4	SN: 5001-UP
26	DY06022-01910	UNIT,BATTERY SENSOR	1	SN: 5001-UP
27	DY00271-06016	SCREW	1	SN: 5001-UP
28	DY82018-61103	BOARD,CHANGE TERMINAL	1	SN: 5001-UP
29	DY82018-52104	TERMINAL,CHANGE	10	SN: 5001-UP
30	DY00171-08030	BOLT	20	SN: 5001-UP
31	DY82018-53104	PLATE,CHANGE	6	SN: 5001-UP
32	DY82018-52504	BOLT	10	SN: 5001-UP
33	DY08018-30704	BOLT	16	SN: 5001-UP
34	DY00400-12000	WASHER,SPRING	26	SN: 5001-UP
35	DY00414-12000	WASHER	26	SN: 5001-UP
36	DY00171-10030	BOLT	4	SN: 5001-UP
37	DY82018-33003	PANEL,ELECTRIC PARTS	1	SN: 5001-UP
38	DY06018-23872	UNIT,AUTOMATIC IDLING	1	SN: 5001-UP
39	DY00171-06025	BOLT	2	SN: 5001-UP
40	DY00171-08020	BOLT	4	SN: 5001-UP
41	DY82018-22603	PANEL,CONTROL	1	SN: 5001-UP
42	DY82018-22503	PANEL,CONTROL	1	SN: 5001-UP
43	DY02251-00095	• SEAL,RUBBER	2	SN: 5001-UP
44	DY02251-00117	• SEAL,RUBBER	2	SN: 5001-UP
45	DY06050-11211	PIN	4	SN: 5001-UP
46	DY06018-00470	FREQUENCY METER	1	SN: 5001-UP
47	DY06018-05753	AMMETER,AC	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
48	DY06018-01040	SWITCH,CHANGE OVER, AMMETER	1	SN: 5001-UP
49	DY06018-00239	VOLTMETER,AC	1	SN: 5001-UP
50	DY06018-01041	SWITCH,CHANGE OVER, VOLTMETER	1	SN: 5001-UP
51	DY06018-10072	LAMP,PILOT	1	SN: 5001-UP
51	DY06018-10261	• BULB, 13W	1	SN: 5001-UP
52	DY06018-40073	REGULATOR,VOLTAGE REGULATOR	1	SN: 5001-UP
53	DY06018-40121	KNOB,25N	1	SN: 5001-UP
54	DY06018-22408	RELAY,EARTH LEAKAGE	1	SN: 5001-UP
55	DY06018-02810	• TRANSFORMER,ZERO PHASE SEQUENCE CURRENT	1	SN: 5001-UP
56	DY08403-03303	BRACKET,EARTH LEAKAGE RELAY	1	SN: 5001-UP
57	DY00210-04020	SCREW	2	SN: 5001-UP
58	DY00400-04000	WASHER,SPRING	2	SN: 5001-UP
59	DY00412-04000	WASHER	2	SN: 5001-UP
60	DY00271-04010	SCREW	2	SN: 5001-UP
61	DY00271-04010	SCREW	4	SN: 5001-UP
62	DY06018-10072	LAMP,SYNCHRONIZING	2	SN: 5001-UP
62	DY06018-10261	• BULB, 13W	1	SN: 5001-UP
63	DY06018-30682	SWITCH,SELECTOR	1	SN: 5001-UP
64	DY06018-10161	LAMP,PANEL	1	SN: 5001-UP
64	DY06018-10214	• BULB	1	SN: 5001-UP
65	DY02070-04000	NUT	2	SN: 5001-UP
66	DY06018-30710	SWITCH,PANEL LIGHT	1	SN: 5001-UP
67	DY74318-22104	COVER	1	SN: 5001-UP
68	DY00210-03016	SCREW	4	SN: 5001-UP
69	DY00300-03000	NUT	4	SN: 5001-UP
70	DY00400-03000	WASHER,SPRING	4	SN: 5001-UP
71	DY00412-03000	WASHER	4	SN: 5001-UP
72	DY08050-01304	SCREW	4	SN: 5001-UP
73	DY00412-08000	WASHER	4	SN: 5001-UP
74	DY00300-08000	NUT	4	SN: 5001-UP
75	DY38718-24004	STOPPER,CONTROL PANEL	2	SN: 5001-UP
76	DY00412-06000	WASHER	2	SN: 5001-UP
77	DY06050-10502	SNAP PIN,SNAP	2	SN: 5001-UP
78	DY82018-14504	COVER,CONTROL BOX	1	SN: 5001-UP
79	DY00171-06016	BOLT	12	SN: 5001-UP
80	DY81818-26504	PANEL,SIDE, CONTROL BOX	2	SN: 5001-UP
81	DY00171-06016	BOLT	16	SN: 5001-UP
82	DY82018-27504	PANEL,CONTROL BOX	1	SN: 5001-UP
83	DY00171-06016	BOLT	12	SN: 5001-UP
84	DY00100-10035	BOLT	4	SN: 5001-UP
85	DY00300-10000	NUT	4	SN: 5001-UP
86	DY00400-10000	WASHER,SPRING	4	SN: 5001-UP
87	DY00412-10000	WASHER	8	SN: 5001-UP

Reference: 2201




Reference: 3201

030030 RADIATOR ASS'Y

Item	Part No.	Part Name	Qty	Options
1	6151-61-9720	RADIATOR ASS'Y	1	SN: 5001-UP
2	6993-61-9170	SHEET,RUBBER	2	SN: 5001-UP
3	DY00101-12055	BOLT	4	SN: 5001-UP
4	DY00300-12000	NUT	4	SN: 5001-UP
5	DY00400-12000	WASHER,SPRING	4	SN: 5001-UP
6	DY00412-12000	WASHER	8	SN: 5001-UP
7	DY81951-23004	BRACKET,RADIATOR	2	SN: 5001-UP
8	DY00171-08020	BOLT	4	SN: 5001-UP
9	6996-61-1520	HOSE,RADIATOR	1	SN: 5001-UP
10	6996-61-1530	HOSE,RADIATOR	1	SN: 5001-UP
11	6128-61-9530	HOSE,RADIATOR	1	SN: 5001-UP
12	07281-00809	CLAMP,HOSE	4	SN: 5001-UP
13	07281-00909	CLAMP,HOSE	1	SN: 5001-UP
14	07281-00197	CLAMP,HOSE	2	SN: 5001-UP
15	600-181-4300	ELEMENT ASS'Y,AIR CLEANER	1	SN: 5001-UP
16	600-181-1510	CAP,AIR CLEANER	1	SN: 5001-UP
17	DY62033-06104	SOCKET	1	SN: 5001-UP
18	DY06033-01000	ELBOW	1	SN: 5001-UP
19	DY06033-02000	SLEEVE	1	SN: 5001-UP
20	DY06033-03000	NUT	1	SN: 5001-UP
21	600-211-1230	CARTRIDGE,OIL FILTER	1	SN: 5001-UP
22	600-311-8291	CARTRIDGE,FUEL FILTER	2	SN: 5001-UP
23	600-411-1020	CARTRIDGE,CORROSION RESISTOR	1	SN: 5001-UP
24	DY81851-12004	FOOT,ENGINE	1	SN: 5001-UP
25	DY00101-18060	BOLT	2	SN: 5001-UP
26	DY00300-18000	NUT	2	SN: 5001-UP
27	DY00400-18000	WASHER,SPRING	2	SN: 5001-UP
28	DY00412-18000	WASHER	4	SN: 5001-UP
29	DY06050-00011	RUBBER,SUSPENSION	2	SN: 5001-UP
30	DY00300-16000	NUT	4	SN: 5001-UP
31	DY00400-16000	WASHER,SPRING	4	SN: 5001-UP
32	DY74920-25104	JOINT,DRAIN	1	SN: 5001-UP
33	DY00192-08020	BOLT	2	SN: 5001-UP
34	DY01319-04000	CAP	1	SN: 5001-UP
35	DY62820-25204	HOSE,DRAIN	1	SN: 5001-UP
36	DY06055-15091	BAND,HOSE	2	SN: 5001-UP
37	DY08020-81003	TANK,RESERVE	1	SN: 5001-UP
38	DY06020-10900	CAP,RESERVE TANK	1	SN: 5001-UP
39	DY82120-82103	BRACKET,RESERVE TANK	1	SN: 5001-UP
40	DY02250-00600	SEAL,RUBBER	1	SN: 5001-UP
41	DY00171-06025	BOLT	1	SN: 5001-UP
42	DY00171-08020	BOLT	2	SN: 5001-UP
43	DY01996-01800	HOSE	1	SN: 5001-UP
44	DY01936-01300	HOSE	1	SN: 5001-UP
45	DY01936-00500	HOSE	1	SN: 5001-UP
46	DY06055-15024	BAND,HOSE	4	SN: 5001-UP
47	DY01941-00800	HOSE	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
48	DY06055-15024	BAND,HOSE	1	SN: 5001-UP
49	DY75022-56304	ROD,SUPPORT	1	SN: 5001-UP
50	DY00171-10020	BOLT	2	SN: 5001-UP
51	DY81822-56104	ROD,SUPPORT	1	SN: 5001-UP
52	DY00171-10020	BOLT	2	SN: 5001-UP

Reference: 3201




Reference: 4201

030040 ENGINE OPERATING PANEL ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY81921-11013	PANEL, OPERATING	1	SN: 5001-UP
2	DY00191-06016	BOLT	12	SN: 5001-UP
3	DY00423-06000	WASHER, SPRING	12	SN: 5001-UP
4	DY00424-06000	WASHER	12	SN: 5001-UP
5	DY06021-01000	SWITCH, BATTERY	1	SN: 5001-UP
6	DY00210-08080	SCREW	2	SN: 5001-UP
7	DY00300-08000	NUT	2	SN: 5001-UP
8	DY00400-08000	WASHER, SPRING	2	SN: 5001-UP
9	DY00412-08000	WASHER	4	SN: 5001-UP
10	DY08402-01200	HANDLE, THROTTLE	1	SN: 5001-UP
11	600-815-5390	SWITCH, STARTER	1	SN: 5001-UP
12	08064-10000	SWITCH, EMERGENCY STOP	1	SN: 5001-UP
13	600-815-3730	SIGNAL, HEATER	1	SN: 5001-UP
14	DY06021-20052	TACHOMETER	1	SN: 5001-UP
15	DY06021-20156	CABLE, TACHOMETER	1	SN: 5001-UP
16	DY06021-22053	GAUGE, OIL PRESSURE	1	SN: 5001-UP
17	DY06021-22200	UNIT, OIL PRESSURE	1	SN: 5001-UP
18	DY06021-23053	GAUGE, WATER TEMPERATURE	1	SN: 5001-UP
19	DY06021-23206	UNIT, WATER TEMPERATURE	1	SN: 5001-UP
20	DY06021-21052	AMMETER, CHARGE	1	SN: 5001-UP
21	DY06020-40690	INDICATOR, DUST	1	SN: 5001-UP
22	DY06033-00000	UNION, HALF	1	SN: 5001-UP
23	DY06033-02000	SLEEVE	1	SN: 5001-UP
24	DY06033-03000	NUT	1	SN: 5001-UP
25	DY01900-01100	PIPE, NYLON	1	SN: 5001-UP
26	DY06021-15008	MONITOR ASS'Y, OK	1	SN: 5001-UP
26	DY06018-10204	• BULB	6	SN: 5001-UP
27	DY06021-03090	CAUTION LAMP ASS'Y	1	SN: 5001-UP
27	DY06018-10244	• BULB	1	SN: 5001-UP
28	DY06018-30685	SWITCH, CHANGE OVER, SPEED	1	SN: 5001-UP
29	DY81953-12002	SUPPORT, LEG	1	SN: 5001-UP
30	DY00101-10030	BOLT	5	SN: 5001-UP
31	DY00400-10000	WASHER, SPRING	5	SN: 5001-UP
32	DY00412-10000	WASHER	5	SN: 5001-UP
33	DY81921-83004	LINK, GOVERNOR ROD	1	SN: 5001-UP
34	DY00100-10055	BOLT	1	SN: 5001-UP
35	DY00300-10000	NUT	1	SN: 5001-UP
36	DY00412-10000	WASHER	2	SN: 5001-UP
37	DY81921-52004	ROD, GOVERNOR	1	SN: 5001-UP
38	DY81921-52104	ROD, GOVERNOR	1	SN: 5001-UP
39	DY06021-80106	JOINT, BALL	2	SN: 5001-UP
40	DY02070-08000	NUT	2	SN: 5001-UP
41	DY02070-06000	NUT	2	SN: 5001-UP
42	DY08021-00704	BOLT	1	SN: 5001-UP
43	DY02070-06000	NUT	1	SN: 5001-UP
44	DY00412-08000	WASHER	3	SN: 5001-UP
45	DY00412-06000	WASHER	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
46	DY06050-10503	PIN,SNAP	1	SN: 5001-UP
47	DY06022-10805	CONTROLLER	1	SN: 5001-UP
48	DY06018-02133	FUSE, 5A	1	SN: 5001-UP
49	DY80521-59104	BRACKET	1	SN: 5001-UP
50	DY00271-06016	SCREW	3	SN: 5001-UP
51	DY00171-06020	BOLT	4	SN: 5001-UP
52	DY02070-06000	NUT	4	SN: 5001-UP
53	DY08021-00204	JOINT	1	SN: 5001-UP
54	DY08021-01204	SPRING	1	SN: 5001-UP
55	DY81921-59103	BRACKET	1	SN: 5001-UP
56	DY00171-08020	BOLT	2	SN: 5001-UP
57	DY02070-08000	NUT	2	SN: 5001-UP
58	DY00210-05020	SCREW	1	SN: 5001-UP
59	DY00400-05000	WASHER,SPRING	1	SN: 5001-UP
60	DY00412-05000	WASHER	1	SN: 5001-UP
61	DY82218-60103	BOARD,OUTPUT TERMINAL	1	SN: 5001-UP
62	DY08018-30404	TERMINAL,OUTPUT	7	SN: 5001-UP
63	DY08018-30904	BOLT	7	SN: 5001-UP
64	DY00393-20000	NUT	14	SN: 5001-UP
65	DY00400-20000	WASHER,SPRING	21	SN: 5001-UP
66	DY00414-20000	WASHER	28	SN: 5001-UP
67	DY35018-60614	PLATE,TERMINAL	3	SN: 5001-UP
68	DY08018-32304	SCREW,TERMINAL	1	SN: 5001-UP
69	DY00393-06000	NUT	5	SN: 5001-UP
70	DY00400-06000	WASHER,SPRING	2	SN: 5001-UP
71	DY00414-06000	WASHER	6	SN: 5001-UP
72	DY00191-10040	BOLT	5	SN: 5001-UP
73	DY00423-10000	WASHER,SPRING	5	SN: 5001-UP
74	DY00424-10000	WASHER	5	SN: 5001-UP
75	DY06018-11018	RECEPTACLE,AUXILIARY POWER	1	SN: 5001-UP
76	DY00250-04016	SCREW	2	SN: 5001-UP
77	DY00423-04000	WASHER,SPRING	2	SN: 5001-UP
78	DY00424-04000	WASHER	2	SN: 5001-UP
79	DY06018-02010	CIRCUIT BREAKER	1	SN: 5001-UP
80	DY08450-32304	BRACKET,CIRCUIT BREAKER	1	SN: 5001-UP
81	DY02233-00060	• SEAL,RUBBER	1	SN: 5001-UP
82	DY00191-06020	BOLT	4	SN: 5001-UP
83	DY00423-06000	WASHER,SPRING	4	SN: 5001-UP
84	DY00424-06000	WASHER	4	SN: 5001-UP
85	DY06018-11262	RECEPTACLE,REMOTE CONTROL	1	SN: 5001-UP
86	DY06018-11409	CAP,RECEPTACLE	1	SN: 5001-UP
87	DY08450-44604	BRACKET	1	SN: 5001-UP
88	DY00251-03010	SCREW	3	SN: 5001-UP
89	DY00250-03010	SCREW	4	SN: 5001-UP
90	DY00423-03000	WASHER,SPRING	4	SN: 5001-UP
91	DY00424-03000	WASHER	4	SN: 5001-UP
92	DY82251-82003	COVER,OUTPUT TERMINAL	1	SN: 5001-UP
93	DY00191-12045	BOLT	2	SN: 5001-UP
94	DY00424-12000	WASHER	4	SN: 5001-UP
95	DY08050-09804	WASHER,RUBBER	2	SN: 5001-UP
96	DY02050-12000	NUT	2	SN: 5001-UP
97	DY08450-43704	SPRING	2	SN: 5001-UP
98	DY00405-06000	WASHER,LOCK	1	SN: 5001-UP
99	DY00171-06020	BOLT	1	SN: 5001-UP

Reference: 4201




Reference: 5201

030050 BATTERY ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY01656-14551	BATTERY, 12V 150AH	2	SN: 5001-UP
2	DY08050-00804	SHEET,BATTERY	2	SN: 5001-UP
3	DY75022-50103	BAND,BATTERY	1	SN: 5001-UP
4	DY08050-00904	BAND,BATTERY	1	SN: 5001-UP
5	DY08050-02904	BOLT,BATTERY	4	SN: 5001-UP
6	DY00378-08000	NUT,WING	4	SN: 5001-UP
7	DY00400-08000	WASHER,SPRING	4	SN: 5001-UP
8	DY00412-08000	WASHER	4	SN: 5001-UP
9	DY81922-80304	CABLE,BATTERY	1	SN: 5001-UP
10	DY81922-80104	CABLE,BATTERY	1	SN: 5001-UP
11	DY81922-80504	CABLE,BATTERY	1	SN: 5001-UP
12	DY81922-80704	CABLE,BATTERY	1	SN: 5001-UP
13	DY81922-80904	CABLE,EARTH	1	SN: 5001-UP
14	DY00100-10030	BOLT	4	SN: 5001-UP
15	DY00300-10000	NUT	4	SN: 5001-UP
16	DY00101-16020	BOLT	1	SN: 5001-UP
17	DY00400-16000	WASHER,SPRING	1	SN: 5001-UP
18	DY00412-16000	WASHER	1	SN: 5001-UP
19	DY00405-16000	WASHER,LOCK	1	SN: 5001-UP
20	DY08450-40414	CAP,TERMINAL	2	SN: 5001-UP
21	DY08450-41304	CAP,TERMINAL	2	SN: 5001-UP
22	DY06022-20204	SENSOR,BATTERY	1	SN: 5001-UP

Reference: 5201



Reference: 6201

030060 MUFFLER ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY81923-11012	MUFFLER	1	SN: 5001-UP
2	DY00191-10030	BOLT	4	SN: 5001-UP
3	DY00423-10000	WASHER,SPRING	4	SN: 5001-UP
4	DY00424-10000	WASHER	4	SN: 5001-UP
5	DY81923-50003	PIPE,EXHAUST	1	SN: 5001-UP
6	6150-11-5750	GASKET	1	SN: 5001-UP
7	DY75023-56004	GASKET	2	SN: 5001-UP
8	DY00103-12040	BOLT	4	SN: 5001-UP
9	DY00303-12000	NUT	4	SN: 5001-UP
10	DY00400-12000	WASHER,SPRING	4	SN: 5001-UP
11	DY00412-12000	WASHER	8	SN: 5001-UP
12	DY00101-12055	BOLT	4	SN: 5001-UP
13	DY00300-12000	NUT	4	SN: 5001-UP
14	DY00400-12000	WASHER,SPRING	4	SN: 5001-UP
15	DY00412-12000	WASHER	8	SN: 5001-UP

Reference: 6201

Get the complete PDF catalogue

Komatsu EG275BS-2 S/N 5001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.