





Reference: 1201

030010 GENERATOR ASS'Y

Item	Part No.	Part Name	Qty	Options
	DY82013-00002	GENERATOR ASS'Y	1	SN: 5001-UP
1	DY82010-00002	• ROTOR ASS'Y	1	SN: 5001-UP
2	DY82010-70002	• FAN	1	SN: 5001-UP
3	DY00121-12040	• BOLT	12	SN: 5001-UP
4	DY00425-12000	• WASHER, SPRING	12	SN: 5001-UP
5	DY82016-11004	• DISK, COUPLING	12	SN: 5001-UP
6	DY82010-15003	• PLATE, BALANCE	1	SN: 5001-UP
7	DY00121-16040	• BOLT	10	SN: 5001-UP
8	DY00426-16000	• WASHER, SPRING	10	SN: 5001-UP
9	DY81710-26003	• PLATE, RECTIFIER	1	SN: 5001-UP
10	DY06018-21349	• RECTIFIER, PT 3610 ? RE	3	SN: 5001-UP
11	DY06018-22615	• ABSORBER, SURGE	1	SN: 5001-UP
12	DY81710-20004	• WASHER, INSULATOR	1	SN: 5001-UP
13	DY81710-20504	• WASHER, INSULATOR	1	SN: 5001-UP
14	DY00101-10020	• BOLT	6	SN: 5001-UP
15	DY00400-10000	• WASHER, SPRING	6	SN: 5001-UP
16	DY06010-00209	• WEIGHT ASS'Y	1	SN: 5001-UP
17	DY00708-06313	• BEARING, 6313 DU	1	SN: 5001-UP
18	DY00800-00065	• RING, SNAP	1	SN: 5001-UP
19	DY82016-14003	• RING, COUPLING	1	SN: 5001-UP
20	DY00121-16040	• BOLT	6	SN: 5001-UP
21	DY00425-16000	• WASHER, SPRING	6	SN: 5001-UP
22	DY82013-40003	• STATOR ASS'Y	1	SN: 5001-UP
23	DY02262-00430	• SEAL, RUBBER	1	SN: 5001-UP
24	DY82013-23004	• BRACKET ASS'Y	1	SN: 5001-UP
25	DY02233-00140	• SEAL, RUBBER	1	SN: 5001-UP
26	DY82013-23103	• BRACKET ASS'Y	1	SN: 5001-UP
27	DY02212-00350	• SEAL, RUBBER	1	SN: 5001-UP
28	DY00101-10035	• BOLT	2	SN: 5001-UP
29	DY00412-10000	• WASHER	2	SN: 5001-UP
30	DY82013-24003	• COVER ASS'Y	1	SN: 5001-UP
31	DY02260-00285	• SEAL, RUBBER	2	SN: 5001-UP
32	DY02250-00500	• SEAL, RUBBER	1	SN: 5001-UP
33	DY00101-06016	• BOLT	6	SN: 5001-UP
34	DY00400-06000	• WASHER, SPRING	6	SN: 5001-UP
35	DY00412-06000	• WASHER	6	SN: 5001-UP
36	DY82013-15002	• BRACKET, END	1	SN: 5001-UP
37	DY82013-50003	• FIELD ASS'Y, EXCITER	1	SN: 5001-UP
38	DY00121-10075	• BOLT	6	SN: 5001-UP
39	DY00426-10000	• WASHER, SPRING	6	SN: 5001-UP
40	DY00412-10000	• WASHER	6	SN: 5001-UP
41	DY08450-44904	• GROMMET	1	SN: 5001-UP
42	DY00101-12045	• BOLT	8	SN: 5001-UP
43	DY00400-12000	• WASHER, SPRING	8	SN: 5001-UP
44	DY00412-12000	• WASHER	8	SN: 5001-UP
45	DY82013-10004	• COVER, BEARING	1	SN: 5001-UP
46	DY82013-12004	• GASKET, BEARING	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
47	DY81713-31003	• COVER,END BRACKET	1	SN: 5001-UP
48	DY00101-06016	• BOLT	12	SN: 5001-UP
49	DY00400-06000	• WASHER,SPRING	12	SN: 5001-UP
50	DY00412-06000	• WASHER	12	SN: 5001-UP
51	DY81713-33003	• COVER,END BRACKET	1	SN: 5001-UP
52	DY00101-06030	• BOLT	2	SN: 5001-UP
53	DY00400-06000	• WASHER,SPRING	2	SN: 5001-UP
54	DY00412-06000	• WASHER	2	SN: 5001-UP
55	DY00121-12035	• BOLT	16	SN: 5001-UP
56	DY00425-12000	• WASHER,SPRING	16	SN: 5001-UP
57	DY82013-32003	• COVER,FAN	1	SN: 5001-UP
58	DY06050-00012	RUBBER,SUSPENSION	4	SN: 5001-UP
59	DY00300-20000	NUT	8	SN: 5001-UP
60	DY00400-20000	WASHER,SPRING	8	SN: 5001-UP

Reference: 1201




Reference: 2201

030020 CONTROL BOX ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY82018-12512	BOX,CONTROL	1	SN: 5001-UP
2	DY06018-01168	TRANSFORMER,CURRENT ? AMMETER	2	SN: 5001-UP
3	DY00271-06012	SCREW	4	SN: 5001-UP
4	DY06018-05951	CIRCUIT BREAKER	1	SN: 5001-UP
5	DY06018-02523	• HANDLE,CIRCUIT BREAKER	1	SN: 5001-UP
6	DY06018-20625	REGULATOR,AUTOMATIC VOLTAGE	1	SN: 5001-UP
7	DY00271-05012	SCREW	4	SN: 5001-UP
8	DY06018-23240	RECTIFIER	1	SN: 5001-UP
9	DY00271-05016	SCREW	1	SN: 5001-UP
10	DY06018-20193	CONDENSER	1	SN: 5001-UP
11	DY00271-03010	SCREW	2	SN: 5001-UP
12	DY06018-20851	RELAY,OVER CURRENT	1	SN: 5001-UP
13	DY00271-04016	SCREW	2	SN: 5001-UP
14	DY06018-23757	RELAY	2	SN: 5001-UP
15	DY06018-23143	SOCKET,RELAY	2	SN: 5001-UP
16	DY06018-24400	HOLDER	2	SN: 5001-UP
17	DY00271-04016	SCREW	4	SN: 5001-UP
18	DY08018-50004	UNIT,RESISTOR	1	SN: 5001-UP
19	DY00210-05020	SCREW	1	SN: 5001-UP
20	DY00400-05000	WASHER,SPRING	1	SN: 5001-UP
21	DY00412-05000	WASHER	1	SN: 5001-UP
22	DY00300-06000	NUT	1	SN: 5001-UP
23	DY06018-30715	SWITCH,VOLTAGE SELECTOR	1	SN: 5001-UP
24	600-815-1252	RELAY,EMERGENCY	1	SN: 5001-UP
25	DY00171-06016	BOLT	4	SN: 5001-UP
26	DY06022-01911	UNIT,BATTERY SENSOR	1	SN: 5001-UP
27	DY00271-06016	SCREW	1	SN: 5001-UP
28	DY82018-61103	BOARD,CHANGE TERMINAL	1	SN: 5001-UP
29	DY82018-52104	TERMINAL,CHANGE	10	SN: 5001-UP
30	DY00171-08030	BOLT	20	SN: 5001-UP
31	DY82018-53104	PLATE,CHANGE	6	SN: 5001-UP
32	DY82018-52504	BOLT	10	SN: 5001-UP
33	DY08018-30704	BOLT	16	SN: 5001-UP
34	DY00400-12000	WASHER,SPRING	26	SN: 5001-UP
35	DY00414-12000	WASHER	26	SN: 5001-UP
36	DY00171-10030	BOLT	4	SN: 5001-UP
37	DY82018-33003	PANEL,ELECTRIC PARTS	1	SN: 5001-UP
38	DY06018-23872	UNIT,AUTOMATIC IDLING	1	SN: 5001-UP
39	DY00171-06025	BOLT	2	SN: 5001-UP
40	DY00171-08020	BOLT	4	SN: 5001-UP
41	DY82018-22603	PANEL,CONTROL	1	SN: 5001-UP
42	DY82018-22503	PANEL,CONTROL	1	SN: 5001-UP
43	DY06050-11211	PIN	4	SN: 5001-UP
44	DY06018-00470	FREQUENCY METER	1	SN: 5001-UP
45	DY06018-05752	AMMETER,AC	1	SN: 5001-UP
46	DY06018-01040	SWITCH,CHANGE OVER ? AMMETER	1	SN: 5001-UP
47	DY06018-00239	VOLTMETER,AC	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
48	DY06018-01041	SWITCH,CHANGE OVER ? VOLTMETER	1	SN: 5001-UP
49	DY06018-10072	LAMP,PILOT	1	SN: 5001-UP
	DY06018-10261	• BULB ? 13W	1	SN: 5001-UP
50	DY06018-40073	REGULATOR,VOLTAGE REGULATOR	1	SN: 5001-UP
51	DY06018-40121	KNOB,25N	1	SN: 5001-UP
52	DY06018-22408	RELAY,EARTH LEAKAGE	1	SN: 5001-UP
53	DY06018-02810	• TRANSFORMER,ZERO PHASE SEQUENCE CURRENT	1	SN: 5001-UP
54	DY08403-03303	BRACKET,EARTH LEAKAGE RELAY	1	SN: 5001-UP
55	DY00210-04020	SCREW	2	SN: 5001-UP
56	DY00400-04000	WASHER,SPRING	2	SN: 5001-UP
57	DY00412-04000	WASHER	2	SN: 5001-UP
58	DY00271-04010	SCREW	2	SN: 5001-UP
59	DY00271-04010	SCREW	4	SN: 5001-UP
60	DY06018-10072	LAMP,SYNCHRONIZING	2	SN: 5001-UP
	DY06018-10261	• BULB ? 13W	1	SN: 5001-UP
61	DY06018-30682	SWITCH,SELECTOR	1	SN: 5001-UP
62	DY06018-10161	LAMP,PANEL	1	SN: 5001-UP
	DY06018-10214	• BULB	1	SN: 5001-UP
63	DY02070-04000	NUT	2	SN: 5001-UP
64	DY06018-30710	SWITCH,PANEL LIGHT	1	SN: 5001-UP
65	DY74318-22104	COVER	1	SN: 5001-UP
66	DY00210-03016	SCREW	4	SN: 5001-UP
67	DY00300-03000	NUT	4	SN: 5001-UP
68	DY00400-03000	WASHER,SPRING	4	SN: 5001-UP
69	DY00412-03000	WASHER	4	SN: 5001-UP
70	DY08050-01304	SCREW	4	SN: 5001-UP
71	DY00412-08000	WASHER	4	SN: 5001-UP
72	DY00300-08000	NUT	4	SN: 5001-UP
73	DY38718-24004	STOPPER,CONTROL PANEL	2	SN: 5001-UP
74	DY00412-06000	WASHER	2	SN: 5001-UP
75	DY06050-10502	SNAP PIN,SNAP	2	SN: 5001-UP
76	DY82018-14504	COVER,CONTROL BOX	1	SN: 5001-UP
77	DY00171-06016	BOLT	12	SN: 5001-UP
78	DY81818-26504	PANEL,SIDE ? CONTROL BOX	2	SN: 5001-UP
79	DY00171-06016	BOLT	16	SN: 5001-UP
80	DY82018-27504	PANEL,CONTROL BOX	1	SN: 5001-UP
81	DY00171-06016	BOLT	12	SN: 5001-UP
82	DY00100-10035	BOLT	4	SN: 5001-UP
83	DY00300-10000	NUT	4	SN: 5001-UP
84	DY00400-10000	WASHER,SPRING	4	SN: 5001-UP
85	DY00412-10000	WASHER	8	SN: 5001-UP

Reference: 2201




Reference: 3201

030030 RADIATOR ASS'Y

Item	Part No.	Part Name	Qty	Options
1	6212-61-9901	RADIATOR ASS'Y	1	SN: 5001-UP
2	DY82151-03504	SEAL,RUBBER	1	SN: 5001-UP
3	6995-61-9230	CUSHION,RUBBER	2	SN: 5001-UP
4	DY00101-20055	BOLT	4	SN: 5001-UP
5	DY00400-20000	WASHER,SPRING	4	SN: 5001-UP
6	DY00412-20000	WASHER	4	SN: 5001-UP
7	DY82051-23004	BRACKET,RADIATOR	2	SN: 5001-UP
8	DY00101-12025	BOLT	4	SN: 5001-UP
9	DY00400-12000	WASHER,SPRING	4	SN: 5001-UP
10	DY00412-12000	WASHER	4	SN: 5001-UP
11	6212-61-9610	HOSE,RADIATOR	1	SN: 5001-UP
12	6212-61-9630	HOSE,RADIATOR	1	SN: 5001-UP
13	07261-02612	HOSE,RADIATOR	1	SN: 5001-UP
14	6212-61-9650	HOSE,RADIATOR	1	SN: 5001-UP
15	07281-00909	CLAMP,HOSE	3	SN: 5001-UP
16	07281-01029	CLAMP,HOSE	1	SN: 5001-UP
17	07281-00489	CLAMP,HOSE	2	SN: 5001-UP
18	07281-00167	CLAMP,HOSE	2	SN: 5001-UP
19	6128-81-7051	ELEMENT ASS'Y,AIR CLEANER	1	SN: 5001-UP
20	600-211-1230	CARTRIDGE,OIL FILTER	1	SN: 5001-UP
21	600-311-7130	CARTRIDGE,FUEL FILTER	1	SN: 5001-UP
22	600-411-1150	CARTRIDGE,CORROSION RESISTOR	1	SN: 5001-UP
23	DY82151-12003	FOOT,ENGINE	1	SN: 5001-UP
24	DY00101-18060	BOLT	2	SN: 5001-UP
25	DY00300-18000	NUT	2	SN: 5001-UP
26	DY00400-18000	WASHER,SPRING	2	SN: 5001-UP
27	DY00412-18000	WASHER	4	SN: 5001-UP
28	DY82151-12103	FOOT,ENGINE	2	SN: 5001-UP
29	DY00101-20060	BOLT	4	SN: 5001-UP
30	DY00300-20000	NUT	4	SN: 5001-UP
31	DY00400-20000	WASHER,SPRING	4	SN: 5001-UP
32	DY00412-20000	WASHER	8	SN: 5001-UP
33	DY06050-00013	RUBBER,SUSPENSION	4	SN: 5001-UP
34	DY00300-16000	NUT	8	SN: 5001-UP
35	DY00400-16000	WASHER,SPRING	8	SN: 5001-UP
36	DY08020-81003	TANK,RESERVE	1	SN: 5001-UP
37	DY06020-10900	CAP,RESERVE TANK	1	SN: 5001-UP
38	DY82120-82103	BRACKET,RESERVE TANK	1	SN: 5001-UP
39	DY02250-00600	SEAL,RUBBER	1	SN: 5001-UP
40	DY00171-06025	BOLT	1	SN: 5001-UP
41	DY00171-08020	BOLT	2	SN: 5001-UP
42	DY01996-01150	HOSE	1	SN: 5001-UP
43	DY01937-01300	HOSE	1	SN: 5001-UP
44	DY06055-15024	BAND,HOSE	2	SN: 5001-UP
45	DY01947-00400	HOSE	1	SN: 5001-UP
46	DY01947-00450	HOSE	1	SN: 5001-UP
47	DY01985-01050	HOSE	1	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
48	DY39722-20103	ROD,SUPPORT	1	SN: 5001-UP
49	DY00171-10025	BOLT	2	SN: 5001-UP
50	DY82120-44103	PANEL,OIL	1	SN: 5001-UP
51	DY00171-10025	BOLT	2	SN: 5001-UP

Reference: 3201




Reference: 3501

030040 OIL PUMP ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY06020-23001	PUMP	1	SN: 5001-UP
2	DY82051-91004	BRACKET,PUMP	1	SN: 5001-UP
3	DY00171-06025	BOLT	4	SN: 5001-UP
4	DY00171-08025	BOLT	2	SN: 5001-UP
5	DY01316-08060	NIPPLE	1	SN: 5001-UP
6	DY01200-06005	VALVE	1	SN: 5001-UP
7	DY39720-27104	JOINT,HOSE	1	SN: 5001-UP
8	DY39720-54104	JOINT,HOSE	1	SN: 5001-UP
9	DY39720-54304	PACKING	1	SN: 5001-UP
10	DY01916-01650	HOSE	1	SN: 5001-UP
11	DY06055-15003	BAND,HOSE	2	SN: 5001-UP
12	DY08055-72304	HOSE	1	SN: 5001-UP
13	DY06055-15003	BAND,HOSE	1	SN: 5001-UP

Reference: 3501




Reference: 4201

030050 ENGINE OPERATING PANEL ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY82121-11013	PANEL, OPERATING	1	SN: 5001-UP
2	DY00171-06020	BOLT	12	SN: 5001-UP
3	DY06021-01000	SWITCH, BATTERY	1	SN: 5001-UP
4	DY00210-08080	SCREW	2	SN: 5001-UP
5	DY00300-08000	NUT	2	SN: 5001-UP
6	DY00400-08000	WASHER, SPRING	2	SN: 5001-UP
7	DY00412-08000	WASHER	2	SN: 5001-UP
8	DY08402-01200	HANDLE, THROTTLE	1	SN: 5001-UP
9	DY82121-83004	LINK, GOVERNOR ROD	1	SN: 5001-UP
10	DY08450-45604	BOLT	1	SN: 5001-UP
11	DY00424-12000	WASHER	2	SN: 5001-UP
12	DY02050-08000	NUT	1	SN: 5001-UP
13	DY00423-08000	WASHER, SPRING	1	SN: 5001-UP
14	DY00424-08000	WASHER	2	SN: 5001-UP
15	DY82121-52004	ROD, GOVERNOR	1	SN: 5001-UP
16	DY82121-52104	ROD, GOVERNOR	1	SN: 5001-UP
17	DY06021-80106	JOINT, BALL	4	SN: 5001-UP
18	DY00300-08000	NUT	4	SN: 5001-UP
19	DY02070-06000	NUT	4	SN: 5001-UP
20	600-815-5390	SWITCH, STARTING	1	SN: 5001-UP
21	08064-10000	SWITCH, EMERGENCY STOP	1	SN: 5001-UP
22	600-815-3730	SIGNAL, HEATER	1	SN: 5001-UP
23	DY06021-20052	TACHOMETER	1	SN: 5001-UP
24	DY06021-20156	CABLE, TACHOMETER	1	SN: 5001-UP
25	DY06021-22053	GAUGE, OIL PRESSURE	1	SN: 5001-UP
26	DY06021-22200	UNIT, OIL PRESSURE	1	SN: 5001-UP
27	DY06021-23053	GAUGE, WATER TEMPERATURE	1	SN: 5001-UP
28	DY06021-23206	UNIT, WATER TEMPERATURE	1	SN: 5001-UP
29	DY06021-21052	AMMETER, CHARGE	1	SN: 5001-UP
30	DY06021-24053	GAUGE, OIL TEMPERATURE	1	SN: 5001-UP
31	DY06021-23206	UNIT, OIL TEMPERATURE	1	SN: 5001-UP
32	DY06020-40690	INDICATOR, AIR CLEANER	1	SN: 5001-UP
33	DY62033-06104	SOCKET	1	SN: 5001-UP
34	DY06033-00000	UNION, HALF	1	SN: 5001-UP
35	DY06033-01000	ELBOW	1	SN: 5001-UP
36	DY06033-02000	SLEEVE	2	SN: 5001-UP
37	DY06033-03000	NUT	2	SN: 5001-UP
38	DY01900-01700	PIPE, NYLON	1	SN: 5001-UP
39	DY06021-15008	MONITOR ASS'Y	1	SN: 5001-UP
	DY06018-10204	• BULB	6	SN: 5001-UP
40	DY06021-03090	CAUTION LAMP ASS'Y	1	SN: 5001-UP
	DY06018-10244	• BULB	1	SN: 5001-UP
41	DY06018-30685	SWITCH, CHANGE OVER ? SPEED	1	SN: 5001-UP
42	DY06022-10805	CONTROLLER	1	SN: 5001-UP
43	DY82121-59304	BRACKET	1	SN: 5001-UP
44	DY00271-06012	SCREW	3	SN: 5001-UP
45	DY00171-08020	BOLT	2	SN: 5001-UP

Item	Part No.	Part Name	Qty	Options
46	DY06018-02133	FUSE ? 5A	1	SN: 5001-UP
47	DY82021-67104	LEVER, LINK	1	SN: 5001-UP
48	DY00171-06016	BOLT	2	SN: 5001-UP
49	DY82121-66104	LEVER, SLIDE	1	SN: 5001-UP
50	DY08450-45704	BOLT	1	SN: 5001-UP
51	DY00412-08000	WASHER	2	SN: 5001-UP
52	DY00300-06000	NUT	1	SN: 5001-UP
53	DY82121-59103	BRACKET	1	SN: 5001-UP
54	DY00171-10025	BOLT	2	SN: 5001-UP
55	DY82218-60103	BOARD, OUTPUT TERMINAL	1	SN: 5001-UP
56	DY08018-30404	TERMINAL, OUTPUT	7	SN: 5001-UP
57	DY08018-30904	BOLT	7	SN: 5001-UP
58	DY00393-20000	NUT	14	SN: 5001-UP
59	DY00400-20000	WASHER, SPRING	21	SN: 5001-UP
60	DY00414-20000	WASHER	28	SN: 5001-UP
61	DY35018-60604	PLATE, TERMINAL	3	SN: 5001-UP
62	DY08018-32304	SCREW, TERMINAL	1	SN: 5001-UP
63	DY00393-06000	NUT	5	SN: 5001-UP
64	DY00400-06000	WASHER, SPRING	2	SN: 5001-UP
65	DY00414-06000	WASHER	6	SN: 5001-UP
66	DY00191-10040	BOLT	5	SN: 5001-UP
67	DY00423-10000	WASHER, SPRING	5	SN: 5001-UP
68	DY00424-10000	WASHER	5	SN: 5001-UP
69	DY06018-11018	RECEPTACLE, AUXILIARY POWER	1	SN: 5001-UP
70	DY00250-04016	SCREW	2	SN: 5001-UP
71	DY00423-04000	WASHER, SPRING	2	SN: 5001-UP
72	DY00424-04000	WASHER	2	SN: 5001-UP
73	DY06018-02010	CIRCUIT BREAKER	1	SN: 5001-UP
74	DY08450-32304	BRACKET, CIRCUIT BREAKER	1	SN: 5001-UP
75	DY02233-00060	• SEAL, RUBBER	1	SN: 5001-UP
76	DY00191-06020	BOLT	4	SN: 5001-UP
77	DY00423-06000	WASHER, SPRING	4	SN: 5001-UP
78	DY00424-06000	WASHER	4	SN: 5001-UP
79	DY06018-11262	RECEPTACLE, REMOTE CONTROL	1	SN: 5001-UP
80	DY06018-11409	CAP, RECEPTACLE	1	SN: 5001-UP
81	DY08450-44604	BRACKET	1	SN: 5001-UP
82	DY00251-03010	SCREW	3	SN: 5001-UP
83	DY00250-03010	SCREW	4	SN: 5001-UP
84	DY00423-03000	WASHER, SPRING	4	SN: 5001-UP
85	DY00424-03000	WASHER	4	SN: 5001-UP
86	DY82151-82003	COVER, OUTPUT TERMINAL	1	SN: 5001-UP
87	DY00191-12045	BOLT	2	SN: 5001-UP
88	DY00424-12000	WASHER	4	SN: 5001-UP
89	DY08050-09804	WASHER, RUBBER	2	SN: 5001-UP
90	DY02050-12000	NUT	2	SN: 5001-UP
91	DY08450-43704	SPRING	2	SN: 5001-UP
92	DY00405-06000	WASHER, LOCK	1	SN: 5001-UP
93	DY00171-06020	BOLT	1	SN: 5001-UP

Reference: 4201



Reference: 5201

030060 BATTERY ASS'Y

Item	Part No.	Part Name	Qty	Options
1	DY01657-19052	BATTERY ? 12V 200AH	2	SN: 5001-UP
2	DY39722-51004	SHEET,BATTERY	2	SN: 5001-UP
3	DY39722-50103	BAND,BATTERY	1	SN: 5001-UP
4	DY08050-06504	BOLT,BATTERY	2	SN: 5001-UP
5	DY00378-08000	NUT,WING	2	SN: 5001-UP
6	DY00400-08000	WASHER,SPRING	2	SN: 5001-UP
7	DY00412-08000	WASHER	2	SN: 5001-UP
8	DY82122-65304	CABLE,BATTERY	1	SN: 5001-UP
9	DY82022-65104	CABLE,BATTERY	1	SN: 5001-UP
10	DY82122-65504	CABLE,BATTERY	1	SN: 5001-UP
11	DY82122-65704	CABLE,BATTERY	1	SN: 5001-UP
12	DY82122-65904	CABLE,EARTH	1	SN: 5001-UP
13	DY00100-10030	BOLT	4	SN: 5001-UP
14	DY00300-10000	NUT	4	SN: 5001-UP
15	DY08450-40114	CAP,TERMINAL	1	SN: 5001-UP
16	DY08450-41004	CAP,TERMINAL	1	SN: 5001-UP
17	DY08450-40214	CAP,TERMINAL	1	SN: 5001-UP
18	DY08450-41104	CAP,TERMINAL	1	SN: 5001-UP
19	DY06022-20205	SENSOR,BATTERY	1	SN: 5001-UP

Reference: 5201

Get the complete PDF catalogue

Komatsu EG300BS-5 S/N 5001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.