

The diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor. The main components are labeled with numbers and letters:

- Motor/Actuator:** A central cylindrical component labeled 1, with a shaft labeled 1A and a mounting bracket labeled 1B.
- Flange Assembly (DETAIL - X):** A detailed inset showing a circular flange with various mounting points labeled 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100.
- Internal Components:** A large cylindrical component labeled 10, with a central shaft labeled 11 and a mounting bracket labeled 12.
- Mounting and Support:** Various mounting brackets and supports labeled 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100.


030010 GENERATOR

Item	Part No.	Part Name	Qty	Options
1	DY39702-15101	GENERATOR ASSEMBLY	1	SN: 4501-UP
	DY39710-40010	• FIELD ASSEMBLY	1	SN: 4501-UP
	1A DY39710-10022	•• SHAFT	1	SN: 4501-UP
	1B DY35110-42002	•• CORE, FIELD	1	SN: 4501-UP
	1C DY35110-80013	•• COIL, FIELD	1	SN: 4501-UP
	1D DY35110-32003	•• CORE, ARMATURE, EXCITER	1	SN: 4501-UP
	1E DY35110-85103	•• COIL, ARMATURE, EXCITER	1	SN: 4501-UP
	1F DY35016-10203	•• HUB, COUPLING	1	SN: 4501-UP
	2 DY39710-39004	• HUB, RECTIFIER	1	SN: 4501-UP
	3 DY34310-25102	• RECTIFIER ASSEMBLY	1	SN: 4501-UP
	3A DY34010-26103	•• DISC, RECTIFIER	1	SN: 4501-UP
	3B DY34710-27004	•• FIN, RECTIFIER	6	SN: 4501-UP
	3C DY06018-20052	•• RECTIFIER	6	SN: 4501-UP
	3D DY06018-22601	•• ABSORBER, SURGE	1	SN: 4501-UP
3E DY35010-28014	•• SCREW, TERMINAL	2	SN: 4501-UP	
3F DY00414-06000	•• WASHER	8	SN: 4501-UP	
3G DY00400-06000	•• WASHER, SPRING	8	SN: 4501-UP	
3H DY00395-06000	•• NAT	12	SN: 4501-UP	
3I DY00190-05012	•• BOLT	1	SN: 4501-UP	
3J DY00414-05000	•• WASHER	1	SN: 4501-UP	
3K DY00400-05000	•• WASHER, SPRING	1	SN: 4501-UP	
3L DY00393-05000	•• NAT	1	SN: 4501-UP	
3M DY00190-06020	•• BOLT	12	SN: 4501-UP	
3N DY00414-06000	•• WASHER	12	SN: 4501-UP	
3O DY00400-06000	•• WASHER, SPRING	12	SN: 4501-UP	
3P DY00393-06000	•• NAT	12	SN: 4501-UP	
3Q DY00100-06025	•• BOLT	6	SN: 4501-UP	
3R DY00400-06000	•• WASHER, SPRING	6	SN: 4501-UP	
3S DY00416-06000	•• WASHER	6	SN: 4501-UP	
3T DY00190-03005	•• BOLT	6	SN: 4501-UP	
3U DY00400-03000	•• WASHER, SPRING	6	SN: 4501-UP	
3V DY00414-03000	•• WASHER	6	SN: 4501-UP	
3W DY00393-03000	•• NAT	6	SN: 4501-UP	
3X DY00320-06000	•• NAT	6	SN: 4501-UP	
3Y DY00412-06000	•• WASHER	6	SN: 4501-UP	
3Z DY00404-06000	•• WASHER, LOCK	6	SN: 4501-UP	
4 DY39710-14004	•• FLANGE, BEARING	1	SN: 4501-UP	
5 DY00702-06314	•• BEARING	1	SN: 4501-UP	
6 DY00800-00070	•• RING, SNAP	1	SN: 4501-UP	
7 DY85010-70202	•• FAN	1	SN: 4501-UP	
8 DY35016-11203	•• DISC, COUPLING	1	SN: 4501-UP	
9 DY35016-12104	•• WASHER, COUPLING HUB	1	SN: 4501-UP	
10 DY35016-13104	•• PLATE, LOCK	5	SN: 4501-UP	
11 DY00103-12040	• BOLT	10	SN: 4501-UP	
12 DY35116-14003	• RING, COUPLING	1	SN: 4501-UP	
13 DY00400-12000	• WASHER, SPRING	8	SN: 4501-UP	
14 DY00103-12035	• BOLT	8	SN: 4501-UP	

Item	Part No.	Part Name	Qty	Options
15	DY00400-12000	• WASHER, SPRING	8	SN: 4501-UP
16	DY00103-12040	• BOLT	8	SN: 4501-UP
17	DY35113-40010	• STATOR ASSEMBLY	1	SN: 4501-UP
17A	DY35113-20042	• • FRAME, GENERATOR	1	SN: 4501-UP
17B	DY35113-42103	• • CORE, ARMATURE	1	SN: 4501-UP
17C	DY35113-60003	• • COIL, ARMATURE	1	SN: 4501-UP
18	DY08013-54104	• GROMMET	3	SN: 4501-UP
19	DY39713-21012	• BRACKET, END	1	SN: 4501-UP
20	DY35113-50020	• FIELD ASSEMBLY, EXCITER	1	SN: 4501-UP
20A	DY35113-52013	• • CORE, FIELD, EXCITER	1	SN: 4501-UP
20B	DY35113-62103	• • COIL, FIELD, EXCITER	1	SN: 4501-UP
21	DY00416-08000	• WASHER	4	SN: 4501-UP
22	DY00400-08000	• WASHER, SPRING	4	SN: 4501-UP
23	DY00100-08015	• BOLT	4	SN: 4501-UP
24	DY34713-12004	• GASKET	1	SN: 4501-UP
25	DY34613-10004	• COVER, BEARING	1	SN: 4501-UP
26	DY34713-31103	• COVER, BRACKET	1	SN: 4501-UP
27	DY00400-12000	• WASHER, SPRING	16	SN: 4501-UP
28	DY00103-12035	• BOLT	16	SN: 4501-UP
29	DY35013-32203	• COVER, FAN	1	SN: 4501-UP
31	DY00100-06040	• BOLT	2	SN: 4501-UP
32	DY00400-06000	• WASHER, SPRING	2	SN: 4501-UP
33	DY00416-06000	• WASHER	2	SN: 4501-UP
34	DY00100-12040	• BOLT	8	SN: 4501-UP
35	DY00400-12000	• WASHER, SPRING	8	SN: 4501-UP
36	DY00416-12000	• WASHER	8	SN: 4501-UP
37	DY00100-06015	• BOLT	4	SN: 4501-UP
38	DY00400-06000	• WASHER, SPRING	4	SN: 4501-UP
39	DY00416-06000	• WASHER	4	SN: 4501-UP
40	DY00100-06065	• BOLT	4	SN: 4501-UP
41	DY00400-06000	• WASHER, SPRING	4	SN: 4501-UP
42	DY00416-06000	• WASHER	4	SN: 4501-UP
43	DY00300-20000	NAT	4	SN: 4501-UP
44	DY00400-20000	WASHER, SPRING	4	SN: 4501-UP
45	DY06050-00012	RUBBER, SUSPENSION	4	SN: 4501-UP

Reference: 1201

Fig. 2201 CONTROL BOX ASS'Y (EG380BS)



Reference: 2201


030020 CONTROL BOX

Item	Part No.	Part Name	Qty	Options
1	DY39718-12502	BOX, CONTROL	1	SN: 4501-UP
2	DY35118-70103	TRANSFORMER, CURRENT	3	SN: 4501-UP
3	DY00171-06016	BOLT	6	SN: 4501-UP
4	DY06018-01169	TRANSFORMER, CURRENT, AMMETER	3	SN: 4501-UP
5	DY00171-06010	BOLT	6	SN: 4501-UP
6	DY39718-33403	PANEL, SET	1	SN: 4501-UP
7	DY35118-80103	REACTOR	4	SN: 4501-UP
8	DY00171-06016	BOLT	4	SN: 4501-UP
9	DY06018-20623	REGULATOR, AUTOMATIC VOLTAGE	1	SN: 4501-UP
10	DY00271-05016	SCREW	4	SN: 4501-UP
11	DY06018-20042	RECTIFIER	1	SN: 4501-UP
12	DY00271-03010	SCREW	4	SN: 4501-UP
13	DY06018-01500	TRANSFORMER, DIFFERENTIAL CURRENT	1	SN: 4501-UP
14	DY00200-05065	SCREW	2	SN: 4501-UP
15	DY00400-05000	WASHER, SPRING	2	SN: 4501-UP
16	DY00416-05000	WASHER	2	SN: 4501-UP
17	DY06018-20851	RELAY, OVER CURRENT	1	SN: 4501-UP
18	DY00271-04016	SCREW	2	SN: 4501-UP
19	DY06018-20925	RELAY	2	SN: 4501-UP
20	DY06018-23144	SOCKET, RELAY	2	SN: 4501-UP
21	DY00271-04010	SCREW	4	SN: 4501-UP
22	DY06018-15076	BOARD, TERMINAL	1	SN: 4501-UP
23	DY00271-04020	SCREW	2	SN: 4501-UP
24	DY00171-08020	BOLT	4	SN: 4501-UP
25	DY06018-42040	REGISTER	1	SN: 4501-UP
26	DY00271-05010	SCREW	2	SN: 4501-UP
27	DY06018-04980	CIRCUIT BREAKER	1	SN: 4501-UP
28	DY00210-05050	SCREW	4	SN: 4501-UP
29	DY00400-05000	WASHER, SPRING	4	SN: 4501-UP
30	DY00416-05000	WASHER	4	SN: 4501-UP
31	DY39718-61303	BOARD, CHANGE TERMINAL	1	SN: 4501-UP
32	DY35018-52204	TERMINAL, CHANGE	10	SN: 4501-UP
33	DY35018-53204	PLATE	6	SN: 4501-UP
34	DY00414-20000	WASHER, CHANGE	20	SN: 4501-UP
35	DY00400-20000	WASHER, SPRING	20	SN: 4501-UP
36	DY08018-31904	BOLT	10	SN: 4501-UP
37	DY08018-30904	BOLT	10	SN: 4501-UP
38	DY00100-08030	BOLT	20	SN: 4501-UP
39	DY00400-08000	WASHER, SPRING	20	SN: 4501-UP
40	DY00416-08000	WASHER	20	SN: 4501-UP
41	DY00100-10030	BOLT	4	SN: 4501-UP
42	DY00400-10000	WASHER, SPRING	4	SN: 4501-UP
43	DY00416-10000	WASHER	4	SN: 4501-UP
44	DY06018-30715	SWITCH, VOLTAGE SELECTOR	1	SN: 4501-UP
45	DY06018-50004	UNIT	1	SN: 4501-UP
46	DY00271-05020	SCREW	1	SN: 4501-UP
47	DY00300-06000	NAT	1	SN: 4501-UP

Item	Part No.	Part Name	Qty	Options
48A	DY39718-22803	PANEL, CONTROL	1	SN: 4501-UP
48B	DY39718-22603	PANEL, CONTROL	1	SN: 4501-UP
49	DY06018-00480	HOUR METER	1	SN: 4501-UP
50	DY06018-00059	AMMETER	1	SN: 4501-UP
51	DY06018-01040	SWITCH, CHANGE OVER, AMMETER	1	SN: 4501-UP
52	DY06018-00252	BOLT METER	1	SN: 4501-UP
53	DY06018-01041	SWITCH, CHANGE OVER, VOLTMETER	1	SN: 4501-UP
54	DY06018-10072	LAMP, PILOT, POWER	1	SN: 4501-UP
54	DY06018-10261	• LAMP, 13W	1	SN: 4501-UP
55	DY06018-40032	REGULATOR, VOLTAGE	1	SN: 4501-UP
56	DY06018-40120	NOBU	1	SN: 4501-UP
57	DY06018-10072	LAMP, SYNCHRONIZING	2	SN: 4501-UP
57	DY06018-10261	• LAMP, 13W	1	SN: 4501-UP
58	DY06018-30707	SWITCH, SYNCHRONIZING	1	SN: 4501-UP
59	DY06018-10120	LAMP, PANEL	1	SN: 4501-UP
60	DY06018-30710	SWITCH, PANEL LIGHT	1	SN: 4501-UP
61	DY38718-22004	COVER	2	SN: 4501-UP
62	DY38718-33704	COVER	1	SN: 4501-UP
63	DY06021-29015	COVER	1	SN: 4501-UP
64	DY00271-04016	SCREW	14	SN: 4501-UP
65	DY00300-04000	NAT	14	SN: 4501-UP
66	DY38718-24004	STOPPER, CONTROL PANEL	1	SN: 4501-UP
67	DY00416-08000	WASHER	2	SN: 4501-UP
68	DY00500-02016	PIN	2	SN: 4501-UP
69	DY08050-01304	SCREW, CONTROL PANEL	4	SN: 4501-UP
70	DY08050-02304	COLLAR	4	SN: 4501-UP
71	DY39718-14503	COVER, CONTROL BOX	1	SN: 4501-UP
72	DY35118-12104	PANEL, SIDE	2	SN: 4501-UP
73	DY35118-19504	PAD, RUBBER	8	SN: 4501-UP
74	DY00171-06016	BOLT	12	SN: 4501-UP
75	DY00171-08020	BOLT	4	SN: 4501-UP
76	DY00171-06020	BOLT	6	SN: 4501-UP

Reference: 2201

Fig. 3201 RADIATOR ASS'Y (EG380BS)



Reference: 3201


030030 RADIATOR

Item	Part No.	Part Name	Qty	Options
2	6212-61-9100	RADIATOR ASSEMBLY	1	SN: 4501-UP
3	DY39751-23034	BRACKET, RADIATOR	1	SN: 4501-UP
4	DY39751-23124	BRACKET, RADIATOR	1	SN: 4501-UP
5	6212-61-9520	PIPE	1	SN: 4501-UP
6	6212-61-9540	PIPE	1	SN: 4501-UP
7	6610-61-8411	VALVE, DRAIN	1	SN: 4501-UP
8	6212-61-9511	HOSE, INLET	1	SN: 4501-UP
9	6212-61-9530	HOSE, OUTLET	1	SN: 4501-UP
10	6128-61-9650	HOSE	1	SN: 4501-UP
11	6212-61-9550	HOSE	1	SN: 4501-UP
12	07281-00909	CLAMP	4	SN: 4501-UP
13	07281-01029	CLAMP	4	SN: 4501-UP
14	07281-00489	CLAMP	2	SN: 4501-UP
15	07281-00167	CLAMP	2	SN: 4501-UP
16	6128-81-7401	AIR CLEANER ASSEMBLY	1	SN: 4501-UP
16	6128-81-7051	• ELEMENT ASSEMBLY, AIR CLEANER	1	SN: 4501-UP
17	600-211-1230	CARTRIDGE, OIL FILTER	1	SN: 4501-UP
18	600-311-7110	CARTRIDGE, FUEL FILTER	1	SN: 4501-UP
19	DY39751-12014	FOOT, ENGINE	1	SN: 4501-UP
20	DY39751-12114	FOOT, ENGINE	2	SN: 4501-UP
21	DY06050-00012	RUBBER, SUSPENSION	4	SN: 4501-UP
22	DY08020-81003	TANK, RESERVE	1	SN: 4501-UP
23	DY33820-82013	BRACKET, RESERVE TANK	1	SN: 4501-UP
24	DY39722-20103	ROD, SUPPORT	1	SN: 4501-UP
25	DY00171-10025	BOLT	2	SN: 4501-UP
26	DY00100-18060	BOLT	2	SN: 4501-UP
27	DY00400-18000	WASHER, SPRING	2	SN: 4501-UP
28	DY00416-18000	WASHER	2	SN: 4501-UP
29	DY00300-18000	NAT	2	SN: 4501-UP
30	DY00100-20060	BOLT	4	SN: 4501-UP
31	DY00400-20000	WASHER, SPRING	4	SN: 4501-UP
32	DY00416-20000	WASHER	4	SN: 4501-UP
33	DY00300-20000	NAT	4	SN: 4501-UP
34	DY00171-12030	BOLT	8	SN: 4501-UP
35	DY00300-16000	NAT	8	SN: 4501-UP
36	DY00400-16000	WASHER, SPRING	8	SN: 4501-UP
37	6996-61-9350	CUSHION	2	SN: 4501-UP
38	DY00100-20080	BOLT	4	SN: 4501-UP
39	DY00416-20000	WASHER	4	SN: 4501-UP
40	DY00400-20000	WASHER, SPRING	4	SN: 4501-UP
41	DY00300-20000	NAT	8	SN: 4501-UP
42	DY00171-08025	BOLT	2	SN: 4501-UP
43	DY00171-06025	BOLT	1	SN: 4501-UP
44	DY01944-01450	HOSE	1	SN: 4501-UP
45	DY06055-15003	BAND	1	SN: 4501-UP
46	DY01942-00400	HOSE	1	SN: 4501-UP
47	DY06055-15014	BAND	1	SN: 4501-UP

Item	Part No.	Part Name	Qty	Options
48	DY01936-02000	HOSE	1	SN: 4501-UP
49	DY06055-15024	BAND	1	SN: 4501-UP
50	DY01942-00550	HOSE	1	SN: 4501-UP
51	DY06055-15014	BAND	1	SN: 4501-UP
52	DY01991-03000	HOSE	1	SN: 4501-UP

Reference: 3201

オイル ポンプ 組立
Fig. 3501 OIL PUMP ASS'Y (EG380BS)




Reference: 3501

030040 OIL PUMP

Item	Part No.	Part Name	Qty	Options
1	DY06020-23001	PUMP	1	SN: 4501-UP
2	DY39751-91203	BRACKET, PUMP	1	SN: 4501-UP
3	DY01316-08060	NIPPLE	1	SN: 4501-UP
4	DY01200-06005	VALVE	1	SN: 4501-UP
5	DY39720-27104	JOINT	1	SN: 4501-UP
6	DY39720-54304	PACKING	1	SN: 4501-UP
7	DY39720-54104	JOINT	1	SN: 4501-UP
8	DY01916-01300	HOSE	1	SN: 4501-UP
9	DY06055-15022	BAND	2	SN: 4501-UP
10	DY08055-72304	HOSE	1	SN: 4501-UP
11	DY06055-15003	BAND	1	SN: 4501-UP
12	DY00171-10030	BOLT	4	SN: 4501-UP
13	DY00171-06020	BOLT	4	SN: 4501-UP

Reference: 3501

エンジン 操作盤 組立
Fig. 4201 ENGINE OPERATING PANEL ASS'Y (EG380BS)



Reference: 4201


030050 ENGINE OPERATING PANEL

Item	Part No.	Part Name	Qty	Options
1	DY39721-11303	PANEL, OPERATING	1	SN: 4501-UP
2	DY06071-06015	BOLT	8	SN: 4501-UP
3	DY06021-01000	SWITCH, BATTERY	1	SN: 4501-UP
4	DY08050-00504	STAY, BATTERY SWITCH	2	SN: 4501-UP
5	DY00200-08060	SCREW	2	SN: 4501-UP
6	DY00416-08000	WASHER	2	SN: 4501-UP
7	DY00400-08000	WASHER, SPRING	2	SN: 4501-UP
8	DY00300-08000	NAT	2	SN: 4501-UP
9	DY08402-01200	HANDLE, THROTTLE	1	SN: 4501-UP
10	600-815-5390	SWITCH, STARTING	1	SN: 4501-UP
11	08064-10000	SWITCH, EMERGENCY STOP	1	SN: 4501-UP
12	600-815-3730	SIGNAL, PREHEAT	1	SN: 4501-UP
13	DY06021-20052	TACHOMETER	1	SN: 4501-UP
14	DY06021-20165	CABLE, TACHOMETER	1	SN: 4501-UP
15	DY06021-22053	GAUGE, FUEL	1	SN: 4501-UP
16	DY06021-22200	UNIT, VACUUM	1	SN: 4501-UP
17	DY06021-23053	GAUGE, WATER	1	SN: 4501-UP
18	DY06021-23204	UNIT, SWING	1	SN: 4501-UP
19	DY06021-21052	AMMETER, CHARGE	1	SN: 4501-UP
20	DY06021-24053	GAUGE, UNION	1	SN: 4501-UP
21	DY06021-23204	UNIT, UNION	1	SN: 4501-UP
22	DY06018-50261	GROMMET	1	SN: 4501-UP
23	DY06018-50275	GROMMET	1	SN: 4501-UP
24	DY06021-29015	COVER	1	SN: 4501-UP
25	DY39753-12303	LEG, SUPPORT	1	SN: 4501-UP
26	DY00171-10025	BOLT	4	SN: 4501-UP
27	DY00171-12035	BOLT	2	SN: 4501-UP
28	DY35121-83014	LINK, GOVERNOR ROD	1	SN: 4501-UP
29	DY12726-13104	PIN, LINK	1	SN: 4501-UP
30	DY00416-10000	WASHER	1	SN: 4501-UP
31	DY39721-52014	ROD, GOVERNOR	1	SN: 4501-UP
32	DY39721-52604	ROD, GOVERNOR	1	SN: 4501-UP
33	DY06021-80101	JOINT, BALL	2	SN: 4501-UP
34	DY00300-08000	NAT	2	SN: 4501-UP
35	DY00416-08000	WASHER	2	SN: 4501-UP
36	DY00500-02015	PIN, COTTER	2	SN: 4501-UP
37	DY39722-10114	PANEL, SET	1	SN: 4501-UP
38	DY00171-06020	BOLT	2	SN: 4501-UP
39	600-815-1252	RELAY, EMERGENCY	1	SN: 4501-UP
40	DY00271-06016	SCREW	4	SN: 4501-UP
41	DY34818-60103	BOARD, OUTPUT TERMINAL	1	SN: 4501-UP
42	DY08018-30404	TERMINAL, OUTPUT	7	SN: 4501-UP
43	DY08018-30904	BOLT	7	SN: 4501-UP
44	DY00414-20000	WASHER	28	SN: 4501-UP
45	DY00400-20000	WASHER, SPRING	21	SN: 4501-UP
46	DY00393-20000	NAT	14	SN: 4501-UP
47	DY35018-60604	PLATE, TERMINAL	3	SN: 4501-UP

Item	Part No.	Part Name	Qty	Options
48	DY08018-32304	SCREW, TERMINAL	3	SN: 4501-UP
49	DY00414-06000	WASHER	18	SN: 4501-UP
50	DY00400-06000	WASHER, SPRING	6	SN: 4501-UP
51	DY00393-06000	NAT	15	SN: 4501-UP
52	DY00100-10030	BOLT	4	SN: 4501-UP
53	DY00400-10000	WASHER, SPRING	4	SN: 4501-UP
54	DY00416-10000	WASHER	4	SN: 4501-UP
55	DY35118-65503	COVER, OUTPUT TERMINAL	1	SN: 4501-UP
56	DY00100-12040	BOLT	2	SN: 4501-UP
57	DY00416-12000	WASHER	4	SN: 4501-UP
58	DY08050-09804	WASHER, RUBBER	2	SN: 4501-UP
59	DY00300-12000	NAT	4	SN: 4501-UP

Reference: 4201

Fig. 5201 BATTERY ASS'Y (EG380BS)



Reference: 5201

030060 Battery

Item	Part No.	Part Name	Qty	Options
1	DY01600-12200	BATTERY, 12V 200AH	2	SN: 4501-UP
2	DY39722-51004	SEAT, BATTERY	2	SN: 4501-UP
3	DY39722-50103	BAND, BATTERY	1	SN: 4501-UP
4	DY08050-06504	BOLT, BATTERY	2	SN: 4501-UP
5	DY00416-08000	WASHER	2	SN: 4501-UP
6	DY00400-08000	WASHER, SPRING	2	SN: 4501-UP
7	DY00378-08000	NUT,WING	2	SN: 4501-UP
8	DY39722-65504	CABLE, BATTERY	1	SN: 4501-UP
9	DY39722-65704	CABLE, BATTERY	1	SN: 4501-UP
10	DY39722-65104	CABLE, BATTERY	1	SN: 4501-UP
11	DY39722-65304	CABLE, BATTERY	1	SN: 4501-UP
12	DY39722-65904	CABLE, EARTH	1	SN: 4501-UP
13	DY00171-10020	BOLT	1	SN: 4501-UP
14	DY00405-08000	WASHER, LOCK	1	SN: 4501-UP
15	DY00405-10000	WASHER, LOCK	1	SN: 4501-UP
16	DY08450-40214	CAP	1	SN: 4501-UP
17	DY08450-41104	CAP	1	SN: 4501-UP
18	DY08450-40114	CAP	1	SN: 4501-UP
19	DY08450-41004	CAP	1	SN: 4501-UP
20	6004000-9-80	CAP	2	SN: 4501-UP

Reference: 5201

Get the complete PDF catalogue

Komatsu EG380BS-1 (JPN) S/N 4501-UP (Japanese)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.