





FH20-V

Reference: A0000-01A0

030010 ENGINE UNIT

Item	Part No.	Part Name	Qty	Options
1	37C-1DB-6013	ENGINE ASS'Y	1	SN: 139297-UP
	37C-1DB-6012	ENGINE ASS'Y	1	SN: 138176-139296
	37C-1DB-6011	ENGINE ASS'Y	1	SN: 138001-138175

Reference: A0000-01A0




JY038782

Reference: B0100-01A0

060010 ENGINE MOUNTING PARTS

Item	Part No.	Part Name	Qty	Options
1	3EC-02-62111	BRACKET	1	SN: 138001-UP
2	3EC-02-62311	BRACKET	1	SN: 138001-UP
3	3EC-02-62321	BRACKET	1	SN: 138001-UP
4	3EC-02-62331	BRACKET	1	SN: 138001-UP
5	3EC-02-52370	MOUNT	2	SN: 138001-UP
6	3EC-02-52380	MOUNT	2	SN: 138001-UP
7	01643-31232	WASHER	8	SN: 138001-UP
8	3EB-01-51190	WASHER	4	SN: 138001-UP
9	01010-81095	BOLT	3	SN: 138001-UP
10	01643-31032	WASHER	3	SN: 138001-UP
11	01010-81030	BOLT	4	SN: 138001-UP
12	01010-81030	BOLT	12	SN: 138001-UP
13	01643-31032	WASHER	12	SN: 138001-UP
14	01010-81035	BOLT	4	SN: 139294-UP
	01010-81035	BOLT	5	SN: 138001-139293
15	01643-31032	WASHER	4	SN: 139294-UP
	01643-31032	WASHER	5	SN: 138001-139293
16	01010-81070	BOLT	1	SN: 139294-UP
17	01643-31032	WASHER	1	SN: 139294-UP
18	01596-01211	NUT	4	SN: 138001-UP
19	01580-11210	NUT	4	SN: 138001-UP
20	04020-01228	PIN,DOWEL	2	SN: 138001-UP
21	01643-51032	WASHER	4	SN: 138001-UP
22	3EB-11-31340	GASKET	1	SN: 138001-UP

Reference: B0100-01A0




Reference: B0100-01A1

060020 ENGINE MOUNTING PARTS (FOR STEEL CABIN)

Item	Part No.	Part Name	Qty	Options
1	3EC-02-62111	BRACKET	1	SN: 138001-UP
2	3EC-02-62311	BRACKET	1	SN: 138001-UP
3	3EC-02-62420	BRACKET	1	SN: 138001-UP
4	3EC-02-62331	BRACKET	1	SN: 138001-UP
5	3EC-02-52370	MOUNT	2	SN: 138001-UP
6	3EC-02-52380	MOUNT	2	SN: 138001-UP
7	01643-31232	WASHER	8	SN: 138001-UP
8	3EB-01-51190	WASHER	4	SN: 138001-UP
9	01010-81095	BOLT	3	SN: 138001-UP
10	01643-31032	WASHER	3	SN: 138001-UP
11	01010-81030	BOLT	4	SN: 138001-UP
12	01010-81030	BOLT	12	SN: 138001-UP
13	01643-31032	WASHER	12	SN: 138001-UP
14	01010-81035	BOLT	4	SN: 139294-UP
	01010-81035	BOLT	5	SN: 138001-139293
15	01643-31032	WASHER	4	SN: 139294-UP
	01643-31032	WASHER	5	SN: 138001-139293
16	01010-81070	BOLT	1	SN: 139294-UP
17	01643-31032	WASHER	1	SN: 139294-UP
18	01596-01211	NUT	4	SN: 138001-UP
19	01580-11210	NUT	4	SN: 138001-UP
20	04020-01228	PIN,DOWEL	2	SN: 138001-UP
21	01643-51032	WASHER	4	SN: 138001-UP
22	3EB-11-31340	GASKET	1	SN: 138001-UP

Reference: B0100-01A1




Reference: B0100-02A0

060030 AIR CLEANER PIPING

Item	Part No.	Part Name	Qty	Options
1	3EC-02-52940	PIPE	1	SN: 138001-UP
2	3EC-02-52990	HOSE	1	SN: 138001-UP
3	3EC-02-62921	PIPE	1	SN: 138001-UP
4	3EC-02-52980	HOSE	1	SN: 138001-UP
5	3EC-02-52870	PIPE	1	SN: 138001-UP
6	07289-00055	CLAMP	6	SN: 138001-UP

Reference: B0100-02A0




Reference: B0100-02A1

060040 AIR CLEANER PIPING (FOR STEEL CABIN)

Item	Part No.	Part Name	Qty	Options
1	3EC-02-52940	PIPE	1	SN: 138001-UP
2	3EC-02-52990	HOSE	1	SN: 138001-UP
3	3EC-02-62921	PIPE	1	SN: 138001-UP
4	3EC-02-52980	HOSE	1	SN: 138001-UP
5	3EC-02-52870	PIPE	1	SN: 138001-UP
6	07289-00055	CLAMP	6	SN: 138001-UP

Reference: B0100-02A1




Reference: B0100-02A2

060050 AIR CLEANER PIPING (FOR STEEL CABIN) (CYCLONE CLEANER OUTER TYPE WITH PRE-CLEANER)

Item	Part No.	Part Name	Qty	Options
1	3EC-02-62940	PIPE	1	SN: 138001-UP
2	3EC-02-52990	HOSE	1	SN: 138001-UP
3	3EC-02-62921	PIPE	1	SN: 138001-UP
4	3EC-02-52980	HOSE	1	SN: 138001-UP
5	3EC-02-52870	PIPE	1	SN: 138001-UP
6	07289-00055	CLAMP	6	SN: 138001-UP

Reference: B0100-02A2




JY018651

Reference: B0100-03A0

060060 AIR DUCT

Item	Part No.	Part Name	Qty	Options
1	3EC-60-62110	BRACKET	1	SN: 138001-UP
2	01010-81220	BOLT	2	SN: 138001-UP
3	01643-31232	WASHER	2	SN: 138001-UP
4	3EC-02-63660	HOSE	1	SN: 138001-UP
5	3EC-02-63650	TUBE	1	SN: 138001-UP
6	07281-01029	CLAMP	1	SN: 138001-UP
7	01010-81020	BOLT	1	SN: 138001-UP
8	01643-31032	WASHER	1	SN: 138001-UP
9	07281-00809	CLAMP	1	SN: 138001-UP

Reference: B0100-03A0




Reference: B0200-01A0

060070 AIR CLEANER

Item	Part No.	Part Name	Qty	Options
1	3EC-02-63640	AIR CLEANER ASS'Y	1	SN: 138001-UP
2	3EC-02-63630	PLATE	1	SN: 138133-UP
	3EC-51-69170	PLATE	1	SN: 138001-138132
3	01435-00816	BOLT	4	SN: 138001-UP
4	3EC-02-63610	HOSE	1	SN: 138001-UP
5	07281-01159	CLAMP	1	SN: 138001-UP
6	01010-81025	BOLT	2	SN: 138001-UP
7	01643-31032	WASHER	2	SN: 138001-UP
8	07281-00809	CLAMP	1	SN: 138001-UP
9	3EC-02-52570	COVER	1	SN: 138001-UP

Reference: B0200-01A0



JY020398

Reference: B0200-01A1

060080 AIR CLEANER (WITH PRE-CLEANER)

Item	Part No.	Part Name	Qty	Options
1	01016-50880	BOLT	1	SN: 138001-UP
2	01010-81020	BOLT	2	SN: 138001-UP
3	01643-31032	WASHER	2	SN: 138001-UP
4	01010-81025	BOLT	2	SN: 138001-UP
5	01643-31032	WASHER	2	SN: 138001-UP
6	01010-81025	BOLT	2	SN: 138001-UP
7	01643-31032	WASHER	2	SN: 138001-UP
8	01580-10806	NUT	1	SN: 138001-UP
9	01580-12016	NUT	4	SN: 138001-UP
10	01643-32060	WASHER	2	SN: 138001-UP
11	3EC-02-61520	HOSE	1	SN: 138001-UP
12	07281-01029	CLAMP	2	SN: 138001-UP
13	07281-01159	CLAMP	2	SN: 138001-UP
14	3EC-05-13250	WASHER	2	SN: 138001-UP
15	3EC-02-61550	BOLT	2	SN: 138001-UP
16	3EC-02-61540	BRACKET	1	SN: 138001-UP
17	3EC-02-43470	BRACKET	1	SN: 138001-UP
18	3EC-02-43480	BRACKET	1	SN: 138001-UP
19	3EC-02-61530	BRACKET	1	SN: 138001-UP
20	3EF-02-46820	ADAPTER	1	SN: 138001-UP
21	3FD-02-13560	BAND	1	SN: 138001-UP
22	3EC-02-61560	AIR CLEANER ASS'Y	1	SN: 138001-UP
23	3SB-02-14130	BAR	2	SN: 138001-UP
24	45E-02-11310	PRE-CLEANER	1	SN: 138001-UP
25	3EC-02-61570	SHEET	1	SN: 138001-UP
26	07281-02309	CLAMP	1	SN: 138001-UP
27	3EC-02-61510	PIPE	1	SN: 138001-UP
28	01010-80830	BOLT	2	SN: 138001-UP
29	01643-30823	WASHER	2	SN: 138001-UP
30	3EC-02-33420	HOSE	1	SN: 138001-UP
31	07281-00909	CLAMP	1	SN: 138001-UP
32	07281-00809	CLAMP	1	SN: 138001-UP
33	3EC-02-52570	COVER	1	SN: 138001-UP

Get the complete PDF catalogue

Komatsu FH40-1 S/N 138001-UP

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.