





Reference: 023-1225c

## 023-1225c Engine Mounting

| Item | Part No.   | Part Name             | Qty | Options |
|------|------------|-----------------------|-----|---------|
| 01   | 901 854 40 | Engine mounting assy. | 1   |         |
| 02   | 487 631 40 | Stand of the bearing  | 1   |         |
| 03   | 487 633 40 | Bearing cover         | 1   |         |
| 04   | 896 672 40 | Rubber metal bar      | 2   |         |
| 05   | 307 780 99 | Bolt                  | 4   |         |
| 06   | 507 037 98 | Nut                   | 8   |         |
| 07   | 307 779 99 | Bolt                  | 4   |         |

Reference: 023-1225c




Reference: 023-1227c

## 023-1227c Engine Mounting

| Item | Part No.   | Part Name             | Qty | Options |
|------|------------|-----------------------|-----|---------|
| 01   | 901 853 40 | Engine mounting assy. | 1   |         |
| 02   | 462 994 40 | Stand of the bearing  | 1   |         |
| 03   | 462 995 40 | Bearing cover         | 1   |         |
| 04   | 896 672 40 | Rubber metal bar      | 2   |         |
| 05   | 307 780 99 | Bolt                  | 4   |         |
| 06   | 507 037 98 | Nut                   | 8   |         |
| 07   | 307 779 99 | Bolt                  | 4   |         |

Reference: 023-1227c




Reference: 090-0359a

## 090-0359a Bleed-Off Valve, Pre-controlled

| Item | Part No.   | Part Name                                                                                                   | Qty | Options |
|------|------------|-------------------------------------------------------------------------------------------------------------|-----|---------|
| 01   | 906 861 40 | Bleed-off valve, pre-controlled assy. without pressure adjustment<br>Fial resetting after mounting required | -2  |         |
|      | 356 197 40 | Valve, pre-controlled assy. 150bar                                                                          | -2  |         |
|      | 356 198 40 | Valve, pre-controlled assy. 350bar                                                                          | -2  |         |
|      | 324 559 40 | Valve, pre-controlled assy. 125bar                                                                          | -2  |         |
|      | 414 238 40 | Valve, pre-controlled assy. 180bar                                                                          | -2  |         |
|      | 414 239 40 | Valve, pre-controlled assy. 190bar                                                                          | -2  |         |
|      | 655 571 40 | Valve, pre-controlled assy. 310bar                                                                          | -2  |         |
|      | 906 711 40 | Valve, pre-controlled assy. 280bar                                                                          | -2  |         |
|      | 414 967 40 | Valve, pre-controlled assy. 330bar                                                                          | -2  |         |
|      | 621 732 40 | Valve, pre-controlled assy. 320bar                                                                          | -2  |         |
| 02   |            | Pressure relief valve                                                                                       | 1   |         |
| 03   | 368 097 40 | Support ring                                                                                                | 2   |         |
| 04   | 519 254 98 | O-ring                                                                                                      | 2   |         |
| 05   | 799 756 73 | Seal kit to fig-no: 02                                                                                      | 1   |         |

Reference: 090-0359a




Reference: 090-0392a

## 090-0392a Travelling Gear Brake Valve

| Item | Part No.   | Part Name                                  | Qty | Options |
|------|------------|--------------------------------------------|-----|---------|
| 01   | 358 617 40 | Brake valve assy. 310 bar                  | 1   |         |
| 02   | 754 587 00 | Safety plug                                | 6   |         |
| 03   | 519 252 98 | Plug                                       | 2   |         |
| 04   | 501 275 98 | O-ring                                     | 2   |         |
| 05   | 255 011 40 | Valve Disc                                 | 2   |         |
| 06   | 754 591 00 | Plug                                       | 2   |         |
| 07   | 519 255 98 | O-ring                                     | 2   |         |
| 08   |            | Pressure relief valve                      | 2   |         |
| 09   |            | Piston                                     | 2   |         |
| 10   |            | Bush                                       | 2   |         |
| 11   | 754 588 00 | Distance piece                             | 2   |         |
| 12   | 912 829 00 | O-ring                                     | 2   |         |
| 13   | 997 791 00 | Support ring                               | 4   |         |
| 14   | 994 838 00 | Spring                                     | 2   |         |
| 15   | 994 837 00 | Spring                                     | 2   |         |
| 16   | 101 537 64 | O-ring                                     | 2   |         |
| 17   | 997 792 00 | Support ring                               | 2   |         |
| 18   | 694 134 00 | Cover                                      | 2   |         |
| 19   | 509 814 98 | Bolt                                       | 12  |         |
| 20   | 255 012 40 | Spring                                     | 2   |         |
| 30   |            | Housing                                    | 1   |         |
|      | 797 697 73 | Set out of pos. 09+10, piston and bush     | -2  |         |
|      | 994 836 00 | Seal kit, assy. fig-nos: 04,07,12,13,16,17 | -2  |         |

Reference: 090-0392a




Reference: 090-0441

## 090-0441 Pilot Oil Unit

| Item | Part No.   | Part Name                             | Qty | Options |
|------|------------|---------------------------------------|-----|---------|
| 01   | 346 567 40 | Pilot oil unit assy.                  | 1   |         |
| 02   | 756 321 73 | Control insert assy.                  | 1   |         |
| 03   | 756 257 73 | Base assy. consist. of fig-nos: 04-12 | 1   |         |
| 04   | 962 875    | Lock pad                              | 1   |         |
| 05   | 962 876    | Spring plate                          | 1   |         |
| 06   | 999 630    | Spring                                | 1   |         |
| 07   | 994 954    | Shim ring 0,1                         | -2  |         |
| 08   | 994 955    | Shim ring 0,2                         | -2  |         |
| 09   | 989 568    | Shim ring 0,5                         | -2  |         |
| 10   | 690 822    | Return spring                         | 1   |         |
| 11   |            | Piston                                | 1   |         |
| 12   |            | Housing                               | 1   |         |
| 13   | 999 605    | Upper assy.                           | 1   |         |

Reference: 090-0441




Reference: 090-0695b

## 090-0695b Throttle Check Valve

| Item | Part No.   | Part Name                  | Qty | Options |
|------|------------|----------------------------|-----|---------|
| 01   | 461 640 40 | Throttle check valve assy. | 1   |         |
| 03   |            | Housing                    | 1   |         |
| 04   |            | Flange                     | 1   |         |
| 05   |            | Spindle                    | 1   |         |
| 06   |            | Taper                      | 1   |         |
| 07   |            | Spring plate               | 1   |         |
| 08   |            | O-ring                     | 1   |         |
| 09   |            | Support ring               | 1   |         |
| 10   |            | O-ring                     | 1   |         |
| 11   |            | Support ring               | 1   |         |
| 12   |            | Nut                        | 1   |         |
| 13   |            | Snap ring                  | 1   |         |
| 14   | 006 729 98 | O-ring                     | 1   |         |
| 15   |            | Spring                     | 1   |         |
| 16   | 319 484 99 | Bolt                       | 4   |         |
| 17   | 757 181 73 | Plug                       | 2   |         |
| 18   |            | Pressure relief valve      | 1   |         |
|      | 790 378 73 | Seal kit                   | -2  |         |
| 20   | 790 376 73 | Mounting kit               | 1   |         |

Reference: 090-0695b




Reference: 090-2863a

## 090-2863a Pilot Oil Unit

| Item | Part No.   | Part Name                | Qty | Options |
|------|------------|--------------------------|-----|---------|
| 01   | 604 750 40 | Pilot oil unit           | 1   |         |
| 01   | 627 291 40 | Pilot oil unit           | 1   |         |
| 02   | 762 586 73 | Pedal                    | 1   |         |
| 03   |            | Mounting group for pedal | 1   |         |
| 05   | 319 154 99 | Bolt                     | 1   |         |
| 06   | 793 714 73 | Plate                    | 1   |         |
| 07   | 793 713 73 | Bellow                   | 2   |         |
| 08   | 790 932 73 | Tappet kit               | 2   |         |
| 09   | 793 715 73 | Controller               | 2   |         |
| 11   | 793 716 73 | Spring set               | 1   |         |
| 12   |            | Housing                  | 1   |         |

Reference: 090-2863a




Reference: 090-5581a

## 090-5581a Air Cleaner

| Item | Part No.   | Part Name                           | Qty | Options |
|------|------------|-------------------------------------|-----|---------|
| 01   | 414 984 40 | Air cleaner assy.                   | 1   |         |
| 02   | 694 488 00 | Main element                        | 2   |         |
| 03   | 988 636 00 | Safety element                      | 2   |         |
| 04   | 988 759 00 | Wing nut                            | 2   |         |
| 05   | 988 750 00 | Gasket                              | 2   |         |
| 06   | 988 748 00 | Maintenance indicator               | 2   |         |
| 07   | 761 418 73 | Cap                                 | 2   |         |
| 08   | 307 775 99 | Bolt                                | 22  |         |
| 09   | 343 110 99 | Lock washer                         | 22  |         |
| 10   | 332 333 99 | Nut                                 | 22  |         |
| 11   | 307 730 99 | Bolt                                | 20  |         |
| 12   | 346 499 99 | Lock washer                         | 20  |         |
| 13   | 765 198 73 | Gasket                              | -2  |         |
| 14   | 697 709 73 | Cover                               | 3   |         |
| 15   | 765 199 73 | Latch                               | 3   |         |
| 16   | 765 165 73 | Hinge                               | 3   |         |
| 17   | 765 200 73 | Dust cup assy. incl. fig-nos. 13-16 | 1   |         |
| 18   | 988 758 00 | Safety clip                         | 2   |         |
| 19   | 988 749 00 | Pin                                 | 2   |         |
| 20   | 794 462 73 | Seal                                | -2  |         |
| 25   | 951 527 40 | Air Filter Cover assy.              | 3   |         |

Reference: 090-5581a




Reference: 090-5586

## 090-5586 Aeration Filter

| Item | Part No.   | Part Name                   | Qty | Options |
|------|------------|-----------------------------|-----|---------|
| 01   | 440 479 40 | Aeration filter, assy.      | 1   |         |
| 02   | 334 627 99 | Nut                         | 1   |         |
| 03   | 694 490    | Cover                       | 1   |         |
| 04   | 696 257 73 | Element with nut fig-no: 02 | 1   |         |
| 05   | 694 489    | Socket housing              | 1   |         |

Reference: 090-5586



Reference: 113-2150

## 113-2150 Horn, Illumination

| Item | Part No.   | Part Name                                                      | Qty | Options |
|------|------------|----------------------------------------------------------------|-----|---------|
| 01   | 256 886 40 | Compressor-single ton-horn consist. of fig.-no: 03-05 440Hz    | 1   |         |
| 02   | 270 960 40 | Compressor-two ton-horn consist. of fig.-no: 05-08 466/587Hz   | 1   |         |
| 03   | 966 953    | Acoustic funnel 440Hz                                          | 1   |         |
| 04   | 966 954    | Hose 1000 lg.                                                  | 1   |         |
| 05   | 966 955    | Compressor                                                     | 1   |         |
| 06   | 966 956    | Acoustic funnel 466Hz                                          | 1   |         |
| 07   | 966 957    | Acoustic funnel 587Hz                                          | 1   |         |
| 08   | 966 958    | Hose 1000 lg.                                                  | 1   |         |
| 09   | 604 289 40 | Compressor-single ton-horn consist. of fig.-no: 04,05,12 880Hz | 1   |         |
| 10   | 307 752 99 | Screw                                                          | 4   |         |
| 11   | 340 507 99 | Washer                                                         | 4   |         |
| 12   | 766 970 73 | Acoustic funnel 880Hz                                          | 1   |         |

Reference: 113-2150

# Get the complete PDF catalogue

Komatsu PC3000-6 S/N 06366

**\$89**

with PayPal | Store cart: \$99

**Buy this PDF on Manuals Komatsu**

Check the model, serial range and language before payment.  
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.