





Reference: 023-1225c

023-1225c Engine Mounting

Item	Part No.	Part Name	Qty	Options
01	901 854 40	Engine mounting assy.	1	
02	487 631 40	Stand of the bearing	1	
03	487 633 40	Bearing cover	1	
04	896 672 40	Rubber metal bar	2	
05	307 780 99	Bolt	4	
06	507 037 98	Nut	8	
07	307 779 99	Bolt	4	

Reference: 023-1225c




Reference: 023-1227c

023-1227c Engine Mounting

Item	Part No.	Part Name	Qty	Options
01	901 853 40	Engine mounting assy.	1	
02	462 994 40	Stand of the bearing	1	
03	462 995 40	Bearing cover	1	
04	896 672 40	Rubber metal bar	2	
05	307 780 99	Bolt	4	
06	507 037 98	Nut	8	
07	307 779 99	Bolt	4	

Reference: 023-1227c




Reference: 090-0270b

090-0270b Pressure Accumulator

Item	Part No.	Part Name	Qty	Options
01	959 329 40	Accumulator	-2	
01	239 441 40	Accumulator	-2	
01	979 485 40	Accumulator	-2	
01	959 328 40	Accumulator	-2	
01	979 486 40	Accumulator	-2	
01	979 487 40	Accumulator	-2	
01	979 488 40	Accumulator	-2	
01	940 922 40	Accumulator	-2	
10	799 944 73	Bladder assy. (fig.11-16)	1	
11		Bladder	1	
12		Gas valve insert	1	
13		Lock nut	1	
14		Seal cap	1	
15		Valve protection cap	1	
16		O-ring	1	
20	799 945 73	Oil valve assy. (fig.21-28)	1	
21		Valve	1	
22		Anti-extrusionsring	1	
23		Washer	1	
24		O-ring	1	
25		Spacer	1	
26		Lock nut	1	
27		Vent screw	1	
28		Support ring	1	
29		O-ring	1	
30	999 544	Adapter	1	
35	799 946 73	Seal kit (fig.16; 23; 24 a. 27-29)	-2	
36	799 947 73	Repair kit (Pos.10 a. seal kit)	-2	

Reference: 090-0270b




Reference: 090-0415b

090-0415b Travelling Gear Brake Valve

Item	Part No.	Part Name	Qty	Options
01	358 611 40	Brake valve, assy. 310 bar	1	
02		Housing	1	
03		Pressure relief valve	2	
04	799 941 73	Plug assy.	2	
05	319 311 99	Screw	12	
06		Cover	2	
07		Support ring	2	
08		O-ring	2	
09		Spring	2	
10		Spring	2	
11		Spring plate	2	
12	799 940 73	Piston	2	
13	799 942 73	Seal kit fig-nos:07-08	1	

Reference: 090-0415b




Reference: 090-2882b

090-2882b Throttle Check Valve

Item	Part No.	Part Name	Qty	Options
01	621 230 40	Throttle check valve assy. (350 bar)	1	
02		Housing	1	
03		O-ring	1	
04	515 383 98	Screw	2	
05		Flange	1	
06		Pressure relief valve	1	
07		Seal kit to fig-no. 06	1	
08		Valve	1	
09	813 976 73	Mounting kit	1	

Reference: 090-2882b




Reference: 090-2886c

090-2886c Throttle Check Valve

Item	Part No.	Part Name	Qty	Options
01	621 231 40	Throttle check valve assy. (350 bar)	1	
02		Housing	1	
03	813 360 73	Mounting kit to fig.01	1	
04		O-ring	1	
05		Pressure relief valve	1	
06	319 296 99	Bolt	4	

Reference: 090-2886c




Reference: 090-3093

090-3093 Hydr.-Motor

Item	Part No.	Part Name	Qty	Options
01	634 235 40	Hydr.-motor, assy.	1	
02	753 755	Housing	1	
03	319 442 99	Screw	6	
04	343 857 99	Lock washer	6	
05	757 224 73	Connection plate	1	
06	509 909 98	O-ring	1	
07	344 820 99	Parallel pin	1	
08	757 567 73	Power unit, assy. consist. of fig-nos: 09,16-24,26 (not available)	1	
09	757 763 73	Power unit, hydr. part, assy. consist. of fig-nos: 10-15 (not available)	1	
10	763 750 73	Control plate	1	
11	757 226 73	Cylinder	1	
12	757 764 73	Spring plate	1	
13	753 765	Cup spring	4	
14	753 766	Trunnion	1	
15	804 812 73	Piston with ring	7	
16	763 751 73	Screw	7	
17	763 752 73	Retaining plate	1	
18	753 770	Disc	1	
19	757 568 73	Drive shaft with bearing set	1	
20	998 515	Shim washer 110x140x0,3	1	
21	804 815 73	Shim washer 110x140x0,2	2	
22	509 910 98	O-ring	1	
23	758 082 73	Shaft seal	1	
24	757 563 73	Cover	1	
25	757 133 73	Cover assy. consist. of fig-nos: 23 + 24	1	
26	342 678 99	Circlip	1	
	973 125	Fluid sealing 50 ml	-2	
	763 498 73	Seal kit	1	

Reference: 090-3093




Reference: 090-5581a

090-5581a Air Cleaner

Item	Part No.	Part Name	Qty	Options
01	414 984 40	Air cleaner assy.	1	
02	694 488 00	Main element	2	
03	988 636 00	Safety element	2	
04	988 759 00	Wing nut	2	
05	988 750 00	Gasket	2	
06	988 748 00	Maintenance indicator	2	
07	761 418 73	Cap	2	
08	307 775 99	Bolt	22	
09	343 110 99	Lock washer	22	
10	332 333 99	Nut	22	
11	307 730 99	Bolt	20	
12	346 499 99	Lock washer	20	
13	765 198 73	Gasket	-2	
14	697 709 73	Cover	3	
15	765 199 73	Latch	3	
16	765 165 73	Hinge	3	
17	765 200 73	Dust cup assy. incl. fig-nos. 13-16	1	
18	988 758 00	Safety clip	2	
19	988 749 00	Pin	2	
20	794 462 73	Seal	-2	
25	951 527 40	Air Filter Cover assy.	3	

Reference: 090-5581a




Reference: 090-5586

090-5586 Aeration Filter

Item	Part No.	Part Name	Qty	Options
01	440 479 40	Aeration filter, assy.	1	
02	334 627 99	Nut	1	
03	694 490	Cover	1	
04	696 257 73	Element with nut fig-no: 02	1	
05	694 489	Socket housing	1	

Reference: 090-5586



Reference: 090-7003

090-7003 Joint Shaft

Item	Part No.	Part Name	Qty	Options
01	324 481 40	Joint shaft, assy. fig-nos: 02-09	1	
02		Hub joint These parts are not sold separately	1	
03		Shaft joint These parts are not sold separately	1	
04	692 893	Flange driver	2	
05	957 734	Bolt	16	
06	957 730	Spider, assy.	2	
07	350 562 99	Grease nipple	2	
08	692 894	Grease- and aeration valve	1	
09	505 050 98	Plug	1	
10	232 481 40	Screwdriver-special insert	-2	
11	997 645 73	Seal ring	1	

Reference: 090-7003

Get the complete PDF catalogue

Komatsu PC8000-6 S/N 12120

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.