





Reference: 023-1225c

023-1225c Engine Mounting

Item	Part No.	Part Name	Qty	Options
01	901 854 40	Engine mounting assy.	1	
02	487 631 40	Stand of the bearing	1	
03	487 633 40	Bearing cover	1	
04	896 672 40	Rubber metal bar	2	
05	307 780 99	Bolt	4	
06	507 037 98	Nut	8	
07	307 779 99	Bolt	4	

Reference: 023-1225c




Reference: 023-1227c

023-1227c Engine Mounting

Item	Part No.	Part Name	Qty	Options
01	901 853 40	Engine mounting assy.	1	
02	462 994 40	Stand of the bearing	1	
03	462 995 40	Bearing cover	1	
04	896 672 40	Rubber metal bar	2	
05	307 780 99	Bolt	4	
06	507 037 98	Nut	8	
07	307 779 99	Bolt	4	

Reference: 023-1227c




Reference: 090-0270b

090-0270b Pressure Accumulator

Item	Part No.	Part Name	Qty	Options
01	959 329 40	Accumulator	-2	
01	239 441 40	Accumulator	-2	
01	979 485 40	Accumulator	-2	
01	959 328 40	Accumulator	-2	
01	979 486 40	Accumulator	-2	
01	979 487 40	Accumulator	-2	
01	979 488 40	Accumulator	-2	
01	940 922 40	Accumulator	-2	
10	799 944 73	Bladder assy. (fig.11-16)	1	
11		Bladder	1	
12		Gas valve insert	1	
13		Lock nut	1	
14		Seal cap	1	
15		Valve protection cap	1	
16		O-ring	1	
20	799 945 73	Oil valve assy. (fig.21-28)	1	
21		Valve	1	
22		Anti-extrusionsring	1	
23		Washer	1	
24		O-ring	1	
25		Spacer	1	
26		Lock nut	1	
27		Vent screw	1	
28		Support ring	1	
29		O-ring	1	
30	999 544	Adapter	1	
35	799 946 73	Seal kit (fig.16; 23; 24 a. 27-29)	-2	
36	799 947 73	Repair kit (Pos.10 a. seal kit)	-2	

Reference: 090-0270b




Reference: 090-0415b

090-0415b Travelling Gear Brake Valve

Item	Part No.	Part Name	Qty	Options
01	358 611 40	Brake valve, assy. 310 bar	1	
02		Housing	1	
03		Pressure relief valve	2	
04	799 941 73	Plug assy.	2	
05	319 311 99	Screw	12	
06		Cover	2	
07		Support ring	2	
08		O-ring	2	
09		Spring	2	
10		Spring	2	
11		Spring plate	2	
12	799 940 73	Piston	2	
13	799 942 73	Seal kit fig-nos:07-08	1	

Reference: 090-0415b




Reference: 090-0502c

090-0502c Throttle Check Valve

Item	Part No.	Part Name	Qty	Options
01	576 159 40	Throttle check valve assy. (350 bar)	1	
02	621 730 40	Throttle check valve assy. (320 bar)	1	
03		Housing	1	
04		Mounting	1	
05	006 734 98	O-ring	1	
06		Pressure relief valve	1	
07	319 296 99	Bolt	4	

Reference: 090-0502c




Reference: 090-2886c

090-2886c Throttle Check Valve

Item	Part No.	Part Name	Qty	Options
01	621 231 40	Throttle check valve assy. (350 bar)	1	
02		Housing	1	
03		Mounting kit to fig.01	1	
04		O-ring	1	
05		Pressure relief valve	1	
06	319 296 99	Bolt	4	

Reference: 090-2886c




Reference: 090-5586

090-5586 Aeration Filter

Item	Part No.	Part Name	Qty	Options
01	440 479 40	Aeration filter, assy.	1	
02	334 627 99	Nut	1	
03	694 490	Cover	1	
04	696 257 73	Element with nut fig-no: 02	1	
05	694 489	Socket housing	1	

Reference: 090-5586




Reference: 112-1831-3

112-1831-3 Valve Block

Item	Part No.	Part Name	Qty	Options
01	506 222 40	Valve block fig-nos: 02-05	1	
02	399 216 40	Valve block	1	
03	951 803 40	Valve - mounting kit fig-nos: 11-19	1	
04	515 812 98	Coupling	1	
05	171 260 40	Plug	1	
11	319 277 99	Bolt	4	
12	255 694 40	Screw plug	2	
13	313 500 99	Eyebolt	2	
14		Bush	1	
15		Piston	1	
16		Compression spring	1	
17		O-ring	1	
18	951 791 40	Pressure relief valve	1	
19	313 404 99	Plug	1	

Reference: 112-1831-3




Reference: 113-2150

113-2150 Horn, Illumination

Item	Part No.	Part Name	Qty	Options
01	256 886 40	Compressor-single ton-horn consist. of fig.-no: 03-05 440Hz	1	
02	270 960 40	Compressor-two ton-horn consist. of fig.-no: 05-08 466/587Hz	1	
03	966 953	Acoustic funnel 440Hz	1	
04	966 954	Hose 1000 lg.	1	
05	966 955	Compressor	1	
06	966 956	Acoustic funnel 466Hz	1	
07	966 957	Acoustic funnel 587Hz	1	
08	966 958	Hose 1000 lg.	1	
09	604 289 40	Compressor-single ton-horn consist. of fig.-no: 04,05,12 880Hz	1	
10	307 752 99	Screw	4	
11	340 507 99	Washer	4	
12	766 970 73	Acoustic funnel 880Hz	1	

Reference: 113-2150



Reference: 113-3158

113-3158 Rotary Joint

Item	Part No.	Part Name	Qty	Options
01	962 425 40	Rotary joint assy.	1	
02	957 682 40	Housing	1	
03	910 196 40	Cover	1	
04	621 441 40	Race	1	
05	910 193 40	Breech block	4	
06	910 194 40	Breech block	2	
07	202 970 40	Plug	2	
08	940 536 40	Sealing element	5	
09	940 534 40	O-ring	5	
10	906 785 40	Lifetime seal	1	
11	414 939 40	Seal	1	
12	440 086 40	Rod guide ring	4	
13	517 759 98	O-ring	1	
14	516 654 98	O-ring	4	
15	906 789 40	Support ring	4	
16	511 224 98	O-ring	2	
17	906 788 40	Support ring	2	
18	308 437 99	Bolt	4	
19	316 216 99	Washer	4	
20	910 197 40	Rotor	1	
21	913 918 40	Plug	4	
22	913 919 40	Plug	2	
23	950 573 40	Turcon-Roto-Glyd-Ring	5	
24	950 574 40	O-ring	5	
25	798 066 73	Seal kit consist. of fig-nos: Bild-Nr. 08-17,23,24	1	

Reference: 113-3158

Get the complete PDF catalogue

Komatsu PC5500-6 S/N 15177

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.