





PJ82678

Reference: 101A01

030010 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0230	⊙ CYLINDER HEAD GROUP	1	SN: 83000-UP
		=====		
	6137-12-1020	CYLINDER HEAD ASSEMBLY,WITH VALVE	1	SN: 83000-UP
	6137-12-1200	• CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 83000-UP
1		• ☆ HEAD, CYLINDER	1	SN: 83000-UP
2	6136-11-1130	• SLEEVE, HOLDER	6	SN: 83000-UP
3	6138-12-1310	• SEAT,INTAKE VALVE (STD)	6	SN: 83000-UP
3	6138-19-1310	• SEAT, 0.25MM, INTAKE VALVE, 0.25MM (OS)	6	SN: 83000-UP
3	6138-18-1310	• SEAT, 0.50MM, INTAKE VALVE, 0.50MM (OS)	6	SN: 83000-UP
3	6138-17-1310	• SHEET, 0.75MM,INTAKE VALVE, 0.75MM (OS)	6	SN: 83000-UP
3	6138-16-1310	• SEAT, 1.00MM, INTAKE VALVE, 1.00MM (OS)	6	SN: 83000-UP
4	6136-12-1320	• SEAT, EXHAUST VALVE (STD)	6	SN: 83000-UP
4	6136-19-1420	• SEAT, 0.25MM, EXHAUST VALVE, 0.25MM (OS)	6	SN: 83000-UP
4	6136-18-1420	• SEAT, 0.50MM, EXHAUST VALVE, 0.50MM (OS)	6	SN: 83000-UP
4	6136-17-1420	• SEAT, 0.75MM,EXHAUST VALVE, 0.75MM (OS)	6	SN: 83000-UP
4	6136-16-1420	• SEAT, 1.00MM, EXHAUST VALVE, 1.00MM (OS)	6	SN: 83000-UP
5	6136-19-1430	• △ GUIDE, VALVE	12	SN: 83000-UP
6	07046-42816	• PLUG	13	SN: 83000-UP
7	07046-44016	• PLUG	4	SN: 83000-UP
8	07043-50108	• PLUG	7	SN: 83000-UP
9	6138-42-4110	• VALVE, INTAKE	6	SN: 83000-UP
10	6136-42-4210	• VALVE, EXHAUST	6	SN: 83000-UP
11	6136-42-4410	• SPRING, VALVE	12	SN: 83000-UP
12	6136-42-4510	• GUIDE, SPRING	12	SN: 83000-UP
13	6136-42-4520	• COTTER, VALVE	24	SN: 83000-UP
14	6136-41-4530	• SEAT, SPRING	12	SN: 83000-UP
15	6136-11-1813	GASKET	1	SN: 90022-UP
15	6136-11-1812	☒ GASKET	1	SN: (83000-90021)
16	6136-12-1610	BOLT	26	SN: 83000-UP
		=====		

Catalog signs: ⊙ part group ☆ not supplied separately: assembly only △ semi-finished: additional work required ☒ discontinued: use part above




PJ82674

Reference: 101A02

030020 CYLINDER HEAD

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0240	⊙ CYLINDER HEAD GROUP	1	SN: 83000-UP
		=====		
	6137-12-1010	CYLINDER HEAD ASSEMBLY,WITH VALVE	1	SN: 83000-UP
	6137-12-1101	• CYLINDER HEAD ASSEMBLY, WITHOUT VALVE	1	SN: 83000-UP
1		• ☆ HEAD, CYLINDER	1	SN: 83000-UP
2	6136-11-1130	• SLEEVE, HOLDER	6	SN: 83000-UP
3	6136-12-1310	• SEAT,INTAKE VALVE (STD)	6	SN: 83000-UP
3	6136-19-1410	• SEAT, 0.25MM, INTAKE VALVE, 0.25MM (OS)	6	SN: 83000-UP
3	6136-18-1410	• SEAT, 0.50MM, INTAKE VALVE, 0.50MM (OS)	6	SN: 83000-UP
3	6136-17-1410	• SHEET, 0.75MM,INTAKE VALVE, 0.75MM (OS)	6	SN: 83000-UP
3	6136-16-1410	• SEAT, 1.00MM, INTAKE VALVE, 1.00MM (OS)	6	SN: 83000-UP
4	6136-12-1320	• SEAT, EXHAUST VALVE (STD)	6	SN: 83000-UP
4	6136-19-1420	• SEAT, 0.25MM, EXHAUST VALVE, 0.25MM (OS)	6	SN: 83000-UP
4	6136-18-1420	• SEAT, 0.50MM, EXHAUST VALVE, 0.50MM (OS)	6	SN: 83000-UP
4	6136-17-1420	• SEAT, 0.75MM,EXHAUST VALVE, 0.75MM (OS)	6	SN: 83000-UP
4	6136-16-1420	• SEAT, 1.00MM, EXHAUST VALVE, 1.00MM (OS)	6	SN: 83000-UP
5	6136-19-1430	• Δ GUIDE, VALVE	12	SN: 83000-UP
6	07046-42816	• PLUG	13	SN: 83000-UP
7	07046-44016	• PLUG	4	SN: 83000-UP
8	07043-50108	• PLUG	7	SN: 83000-UP
9	6136-42-4110	• VALVE, INTAKE	6	SN: 83000-UP
10	6136-42-4210	• VALVE, EXHAUST	6	SN: 83000-UP
11	6136-42-4410	• SPRING, VALVE	12	SN: 83000-UP
12	6136-42-4510	• GUIDE, SPRING	12	SN: 83000-UP
13	6136-42-4520	• COTTER, VALVE	24	SN: 83000-UP
14	6136-41-4530	• SEAT, SPRING	12	SN: 83000-UP
15	6136-11-1813	GASKET	1	SN: 90022-UP
15	6136-11-1812	☒ GASKET	1	SN: (83000-90021)
16	6136-12-1610	BOLT	26	SN: 83000-UP
		=====		

Catalog signs: ⊙ part group ☆ not supplied separately: assembly only Δ semi-finished: additional work required ☒ discontinued: use part above



PJ32675


Reference: 101B01

030030 FRONT HANGER

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0010	⊙ FRONT HANGER GROUP =====	1	SN: 83000-UP
1	6136-11-1910	HANGA	1	SN: 83000-UP
2	6136-11-1821	GASKET =====	1	SN: 83000-UP

Catalog signs: ⊙ part group

Reference: 101B01



P J 3 2 6 7 6

Reference: 101C01

030040 REAR HANGER

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0020	⊙ REAR HANGER GROUP =====	1	SN: 83000-UP
1	6136-11-1930	HANGA	1	SN: 83000-UP
2	01010-31025	BOLT	2	SN: 83000-UP
3	01602-01030	WASHER, SPRING =====	2	SN: 83000-UP
G-2	6136-1X-0030	⊙ REAR HANGER GROUP =====	1	SN: 83000-UP
1	6136-11-1920	HANGA	1	SN: 83000-UP
2	01010-31025	BOLT	2	SN: 83000-UP
3	01602-01030	WASHER, SPRING =====	2	SN: 83000-UP

Catalog signs: ⊙ part group

Reference: 101C01




030050 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0290	⦿ HOUSING GROUP =====	1	SN: 83000-UP
	6138-42-5100	ROCKER ARM ASSEMBLY	1	SN: 83000-UP
1	6138-42-5110	• BRACKET	1	SN: 83000-UP
2	6138-42-5120	• BRACKET	5	SN: 83000-UP
	6138-42-5020	• ROCKER ARM SHAFT ASSEMBLY	1	SN: 83000-UP
3		• • ☆ SHAFT	1	SN: 83000-UP
4	6142-42-5550	• • PLUG	2	SN: 83000-UP
5	6136-42-5130	• ARM	12	SN: 83000-UP
6	6136-42-5140	• SCREW, ADJUST	12	SN: 83000-UP
7	01580-00806	• NUT, LOCK	12	SN: 83000-UP
8	6136-41-5310	• SPRING	5	SN: 83000-UP
9	6136-41-5320	• SPRING	2	SN: 83000-UP
10	6136-41-5330	• CLIP	2	SN: 83000-UP
11	6136-41-5131	STUD	4	SN: 83000-UP
12	01010-31280	BOLT	2	SN: 83000-UP
13	01602-01236	WASHER, SPRING =====	6	SN: 83000-UP

Catalog signs: part group not supplied separately: assembly only

Reference: 111A01



PJ32878


Reference: 111A02

030060 ROCKER ARM AND HOUSING

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0300	⊙ HOUSING GROUP =====	1	SN: 83000-UP
	6136-42-5100	ROCKER ARM ASSEMBLY	1	SN: 83000-UP
1	6136-42-5110	• BRACKET	1	SN: 83000-UP
2	6136-42-5120	• BRACKET	5	SN: 83000-UP
	6136-42-5020	• SHAFT ASSEMBLY	1	SN: 83000-UP
3		• • ☆ SHAFT	1	SN: 83000-UP
4	6142-42-5550	• • PLUG	2	SN: 83000-UP
5	6136-42-5130	• ARM	12	SN: 83000-UP
6	6136-42-5140	• SCREW, ADJUST	12	SN: 83000-UP
7	01580-00806	• NUT, LOCK	12	SN: 83000-UP
8	6136-41-5310	• SPRING	5	SN: 83000-UP
9	6136-41-5320	• SPRING	2	SN: 83000-UP
10	6136-41-5330	• CLIP	2	SN: 83000-UP
11	6136-41-5131	STUD	4	SN: 83000-UP
12	01010-31280	BOLT	2	SN: 83000-UP
13	01602-01236	WASHER, SPRING	6	SN: 83000-UP
		=====		

Catalog signs: ⊙ part group ☆ not supplied separately: assembly only

Reference: 111A02



PJ32678


Reference: 115A01

030070 HEAD COVER

Item	Part No.	Part Name	Qty	Options
G-1	6136-1X-0330	⊙ COVER GROUP, ROCKER ARM HOUSING =====	1	SN: 83000-UP
1	6136-11-8151	COVER, HEAD	1	SN: 83000-UP
2	6136-11-8814	O RING	1	SN: 83000-UP
3	6134-11-8120	NAT	4	SN: 83000-UP
4	6136-11-8130	WASHER	4	SN: 83000-UP
5	6136-11-8142	PACKING	4	SN: 83000-UP
6	6150-21-6750	BREATHER	1	SN: 83000-UP
7	6114-21-5190	O RING =====	1	SN: 83000-UP

Catalog signs: ⊙ part group

Reference: 115A01



PJ35653

Reference: 115B01

030080 BREATHER HOSE (115B02, 115B03)

Item	Part No.	Part Name	Qty	Options
G-1	6136-2X-0010	⊙ BREATHER HOSE GROUP =====	1	SN: 83000-UP
1	6136-11-8851	HOSE	1	SN: 83000-UP
2	07280-02523	CLAMP	1	SN: 83000-UP
3	6600-01-5950	CLIP =====	1	SN: 83000-UP
G-2	6136-2X-0020	⊙ BREATHER HOSE GROUP =====	1	SN: 83000-UP
1	6138-11-8860	HOSE	1	SN: 83000-UP
2	07280-02523	CLAMP	1	SN: 83000-UP
3	6600-01-5950	CLIP =====	1	SN: 83000-UP
G3	6136-2X-0200	⊙ BREATHER HOSE GROUP =====	1	SN: 83000-UP
1	6130-15-8850	HOSE	1	SN: 83000-UP
2	07285-00230	CLIP	1	SN: 83000-UP
3	6600-01-5950	CLIP =====	1	SN: 83000-UP

Catalog signs: ⊙ part group

Reference: 115B01

Get the complete PDF catalogue

Komatsu S6D105-1 (JPN) G.S6D105-1 FOR GENERATOR S/N 83000-UP (JAPANESE)

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.