




00041077


Reference: JA00003

JA00003 Cylinder Head

Item	Part No.	Part Name	Qty	Options
1	6217-11-1610	BOLT, HEAD	18	
2	6217-11-1620	BOLT, HEAD	18	
3	6210-17-1814	GASKET, STANDARD	6	
	6210-19-1814	GASKET, OVERSIZE 0.4MM	6	
	6210-11-1820	• GROMMET, OIL, STANDARD	1	
	6210-19-1820	• GROMMET, OIL, OVERSIZE 0.4MM	1	
	6210-11-1831	• GROMMET, OIL, STANDARD	1	
	6210-19-1831	• GROMMET, OIL, OVERSIZE 0.4MM	1	
	6210-11-1840	• GROMMET, OIL, STANDARD	1	
	6210-19-1840	• GROMMET, OIL, OVERSIZE 0.4MM	1	
	6210-11-1962	• GROMMET, WATER, STANDARD	1	
	6210-19-1962	• GROMMET, WATER, OVERSIZE 0.4MM	1	
	6210-11-1952	• GROMMET, WATER, STANDARD	4	
	6210-19-1952	• GROMMET, WATER, OVERSIZE 0.4MM	4	
	6210-11-1940	• GROMMET, WATER, STANDARD	4	
	6210-19-1940	• GROMMET, WATER, OVERSIZE 0.4MM	4	
	6210-41-5601	CROSSHEAD ASSEMBLY	12	
4	6210-41-5620	• CROSSHEAD	1	
5	6210-41-5641	• SCREW	1	
6	6162-43-5630	• NUT, LOCK	1	
7	6136-41-4520	COTTER, VALVE	48	
8	6210-11-1140	GUIDE, CROSSHEAD	12	
9	6210-41-4430	SPRING	24	
10	6210-41-4440	SPRING	24	
11	6210-41-4510	SEAT, UPPER	24	
12	6215-41-4220	VALVE, EXHAUST	12	
13	6217-41-4110	VALVE, INTAKE	12	
14	6217-41-4531	SEAT, LOWER	24	
15	6217-41-4540	SEAL	24	
	6261-11-1100	CYLINDER HEAD ASSEMBLY	6	
16		• HEAD	1	
17	6216-11-1330	• INSERT, INTAKE VALVE, STANDARD	2	
	6216-19-1330	• INSERT, INTAKE VALVE, OVERSIZE 0.25MM	2	
	6216-18-1330	• INSERT, INTAKE VALVE, OVERSIZE 0.50MM	2	

Item	Part No.	Part Name	Qty	Options
18	6216-17-1330	• INSERT, INTAKE VALVE, OVERSIZE 0.75MM	2	
	6216-16-1330	• INSERT, INTAKE VALVE, OVERSIZE 1.00MM	2	
	6217-11-1321	• INSERT, EXHAUST VALVE, STANDARD	2	
	6217-19-1321	• INSERT, EXHAUST VALVE, OVERSIZE 0.25MM	2	
	6217-18-1321	• INSERT, EXHAUST VALVE, OVERSIZE 0.50MM	2	
	6217-17-1321	• INSERT, EXHAUST VALVE, OVERSIZE 0.75MM	2	

Reference: |A00003




00041077

Reference: |A00004

|A00004 Cylinder Head

Item	Part No.	Part Name	Qty	Options
	6217-16-1321	INSERT, EXHAUST VALVE, OVERSIZE 1.00MM	2	
19	6266-16-1440	GUIDE	4	
20	6210-11-1150	PIPE	1	
21	07000-73025	O-RING	1	
22	6162-13-1150	PLUG, EXPANSION	13	
23	07043-70108	PLUG, TAPER	1	
24	708-21-12541	PLUG, STOCKING	2	
25	01438-01020	BOLT	6	
26	01643-51645	WASHER	36	

Reference: |A00004




GZD08110
(PV68635)

Reference: |A00005

|A00005 Cylinder Head Cover

Item	Part No.	Part Name	Qty	Options
	6217-11-8100	COVER ASSEMBLY	6	
1	6217-11-8110	• COVER, CYLINDER HEAD	1	
2	6217-11-8830	• GASKET	1	

Reference: |A00005




CZD08112
(JD008112)

Reference: |A00006

|A00006 Head Cover Mounting Bolt

Item	Part No.	Part Name	Qty	Options
1	01435-00855	BOLT	18	

Reference: |A00006



C2D84277
(JD094277)


Reference: |A00007

|A00007 Air Intake Manifold

Item	Part No.	Part Name	Qty	Options
1	6210-11-4811	GASKET	6	
2	6261-11-4111	MANIFOLD	1	
3	01436-01070	BOLT	20	
4	600-815-4280	HEATER, RIBBON	1	
5	6211-11-4821	GASKET	2	
6	6261-11-4330	CONNECTOR	1	
7	01435-01070	BOLT	6	
8	07042-A0108	PLUG	2	
9	6261-11-7210	HOUSING, JUNCTION	1	
10	6261-11-7220	BRACKET	1	
11	01435-01025	BOLT	4	
12	01435-01030	BOLT	4	
13	04020-00820	PIN,DOWEL	2	
14	6261-11-9710	NOZZLE, VENTURI	1	
15	01437-10816	BOLT	2	
16	6211-11-4821	GASKET	1	
17	6261-11-7410	CONNECTOR	1	
18	6261-11-7450	GASKET	1	
19	01435-01030	BOLT	2	
20	01435-01035	BOLT	2	
21	01435-01235	BOLT	4	
22	01436-01080	BOLT	4	
23	6560-61-7202	SENSOR, PRESSURE	1	
	6216-54-6320	• O-RING	1	
24	6560-61-7300	SENSOR, TEMPERATURE	1	
		• SENSOR	1	
	6735-21-1930	• O-RING	1	
25	6261-11-4420	CONNECTOR	1	
26	6631-11-5630	SPACER	2	
27	6261-11-4770	BRACKET	1	
28	6261-11-4760	BRACKET	1	
29	6261-11-4910	BRACKET	1	
30	01020-11040	BOLT	2	
31	01435-01025	BOLT	2	

Item	Part No.	Part Name	Qty	Options
32	01435-01030	BOLT	6	
33	01584-01008	NUT	2	
34	02895-77075	O-RING	2	
35	07042-A0108	PLUG	2	
36	6212-61-6662	GASKET	2	
37	6215-61-6670	PLATE	2	

Reference: |A00007




Reference: |A00008

|A00008 Air Intake Manifold

Item	Part No.	Part Name	Qty	Options
38	01435-01025	BOLT	2	

Reference: |A00008




PJ60691

Reference: |A00009

|A00009 Air Cleaner Mounting and Air Connection (Inner Parts)

Item	Part No.	Part Name	Qty	Options
1	6218-81-7202	AIR CLEANER ASSEMBLY	1	
		• BODY	1	
	600-185-6100	• ELEMENT ASSEMBLY	1	
2	600-184-1671	•• O-RING	1	
3	600-185-6110	•• ELEMENT, OUTER	1	
4		•• ELEMENT, INNER	1	
5	600-184-1621	• COVER ASSEMBLY	1	
6	600-184-1350	• VALVE, VACUATOR	1	

Reference: |A00009



Reference: |A00010

|A00010 Air Cleaner Mounting and Air Connection (Air Cleaner Related Parts)

Item	Part No.	Part Name	Qty	Options
1	6240-11-9910	BAND	2	
2	6643-11-4641	BOLT	2	
3	6218-11-4310	CONNECTOR, AIR	1	
4	6261-11-4570	HOSE	1	
5	6218-11-4320	HOSE	1	
6	07289-00160	CLAMP, HOSE	2	
7	07289-00170	CLAMP, HOSE	2	
8	6210-81-5540	BRACKET	1	
9	6631-11-5630	SPACER	1	
10	22D-62-12120	SPACER	1	
11	01010-E1035	BOLT	1	
12	01435-01035	BOLT	1	
13	01584-01008	NUT	1	
14	01436-01030	BOLT	1	
15	6124-61-5720	SPACER	1	
16	6261-11-4530	BRACKET	1	
17	01435-01030	BOLT	4	
18	01584-01008	NUT	4	
19	6261-11-4520	BRACKET	1	
20	01435-01025	BOLT	2	
21	01435-01035	BOLT	4	
22	6261-11-4510	BRACKET	1	
23	01435-01025	BOLT	2	
24	08672-01000	INDICATOR	1	
25	6218-11-8610	BLOCK	1	
26	01435-01025	BOLT	2	
27	8206-01-6160	PLUG	1	
28	6211-21-5560	BRACKET	1	
29	01435-01016	BOLT	1	
30	08671-60090	HOSE	1	
31	04434-51410	CLIP	2	
32	01643-31032	WASHER	2	
33	01435-01025	BOLT	1	

Get the complete PDF catalogue

Komatsu SAA6D140E-5F S/N 536267-up

\$89

with PayPal | Store cart: \$99

Buy this PDF on Manuals Komatsu

Check the model, serial range and language before payment.
Download instructions are emailed after payment confirmation.

This free sample contains 10 catalogue pages.